

Service Manual

3208 Diesel Truck Engine

221-UP

3208 DIESEL TRUCK ENGINE

2Z1-UP

SPECIFICATIONS (Section 1) _____

SYSTEMS OPERATION (Section 2) _____

TESTING AND ADJUSTING (Section 3) _____

TROUBLESHOOTING GUIDE (Section 4) _____

GENERAL INSTRUCTIONS (D & A) (Section 5) _____

DISASSEMBLY AND ASSEMBLY (Section 6) _____

AIR COMPRESSORS (Section 7) _____

RECONDITIONING PROCEDURES (Section 8) _____

in). pump adj. pg. 2-12

STANDARD TORQUE FOR METRIC FASTENERS

NOTE: Take care to avoid mixing metric and inch dimensioned fasteners. Mismatched or incorrect fasteners can result in vehicle damage or malfunction, or possible injury. Exceptions to these torques are given in the Service Manual where needed.

NOTE: Prior to installation of any hardware, be sure components are in near new condition. Bolt and nut threads must not be worn or damaged. Hardware must be free of rust and corrosion. Clean hardware with a non-corrosive cleaner and apply engine oil to threads and bearing face. If thread lock or other compounds are to be applied, do not apply engine oil.

METRIC NUTS AND BOLTS		
THREAD SIZE (mm)	STANDARD TORQUE	
	(N•m)	(lb ft)
M6	12 ± 3	9 ± 2
M8	28 ± 7	20 ± 5
M10	55 ± 10	40 ± 7
M12	100 ± 20	75 ± 15
M14	160 ± 30	120 ± 22
M16	240 ± 40	175 ± 30
M20	460 ± 60	340 ± 44
M24	800 ± 100	600 ± 75
M30	1600 ± 200	1200 ± 150
M36	2700 ± 300	2000 ± 225

METRIC TAPERLOCK STUDS		
THREAD SIZE (mm)	STANDARD TORQUE	
	(N•m)	(lb ft)
M6	8 ± 3	6 ± 2
M8	17 ± 5	13 ± 4
M10	35 ± 5	26 ± 4
M12	65 ± 10	48 ± 7
M16	110 ± 20	80 ± 15
M20	170 ± 30	125 ± 22
M24	400 ± 60	300 ± 45
M30	650 ± 80	480 ± 60
M36	870 ± 100	640 ± 75


STANDARD TORQUE FOR INCH FASTENERS

Exceptions to these torques are given in the Service Manual where needed.

INCH NUTS AND BOLTS		
THREAD SIZE inch	STANDARD TORQUE	
	(N•m)	(lb ft)
1/4	12 ± 3	9 ± 2
5/16	25 ± 6	18.0 ± 4.5
3/8	47 ± 9	35 ± 7
7/16	70 ± 15	50 ± 11
1/2	105 ± 20	75 ± 15
9/16	160 ± 30	120 ± 20
5/8	215 ± 40	160 ± 30
3/4	370 ± 50	275 ± 35
7/8	620 ± 80	460 ± 60
1	900 ± 100	660 ± 75
1-1/8	1300 ± 150	950 ± 100
1-1/4	1800 ± 200	1325 ± 150
1-3/8	2400 ± 300	1800 ± 225
1-1/2	3100 ± 350	2300 ± 250

INCH TAPERLOCK STUDS		
THREAD SIZE inch	STANDARD TORQUE	
	(N•m)	(lb ft)
1/4	8 ± 3	6 ± 2
5/16	17 ± 5	13 ± 4
3/8	35 ± 5	26 ± 4
7/16	45 ± 10	33 ± 7
1/2	65 ± 10	48 ± 7
5/8	110 ± 20	80 ± 15
3/4	170 ± 30	125 ± 22
7/8	260 ± 40	190 ± 30
1	400 ± 60	300 ± 45
1-1/8	500 ± 70	370 ± 50
1-1/4	650 ± 80	480 ± 60
1-3/8	750 ± 90	550 ± 65
1-1/2	870 ± 100	640 ± 75

O-RING FACE SEAL FITTINGS



STRAIGHT THREAD O-RING FITTING (FOR O-RING FACE SEAL FITTING ONLY)

THREAD SIZE inch	STANDARD TORQUE	
	(N•m)	(lb ft)
5/16 - 24	5.0 ± 1.5	45 ± 15 lb in
3/8 - 24	12 ± 2	110 ± 20 lb in
7/16 - 20	20 ± 4	15 ± 3
1/2 - 20	30 ± 5	22 ± 4
9/16 - 18	40 ± 5	30 ± 4
3/4 - 16	100 ± 15	75 ± 10
7/8 - 14	135 ± 15	100 ± 10
1 1/16 - 12	200 ± 25	150 ± 20
1 3/16 - 12	250 ± 25	185 ± 20
1 5/16 - 12	300 ± 40	225 ± 30
1 5/8 - 12	300 ± 40	225 ± 30
1 7/8 - 12	300 ± 40	225 ± 30
2 1/2 - 12	300 ± 40	225 ± 30

O-RING FACE SEAL FITTING NUT

THREAD SIZE inch	STANDARD TORQUE	
	(N•m)	(lb ft)
9/16 - 18	16 ± 3	12 ± 2
11/16 - 16	30 ± 4	22 ± 3
13/16 - 16	50 ± 7	37 ± 5
1 - 14	90 ± 10	65 ± 7
1 3/16 - 12	120 ± 15	90 ± 10
1 7/16 - 12	160 ± 20	120 ± 15
1 11/16 - 12	190 ± 20	140 ± 15
2 - 12	215 ± 25	160 ± 20


FITTING INSTALLATION

HYDRAULIC LINE INSTALLATION

1. For a metal tube to hose installation, install the tube and tighten all bolts finger tight.
2. Tighten the bolts at the rigid end.
3. Install the hose and tighten all bolts finger tight.
4. Put the hose in a position so that it does not make contact with the machine or another hose.
5. Tighten the bolts on both connections.
6. Start the engine.
7. Move the implement control levers to all positions.
8. Look at the hose during movement of the implement. Make sure hose is not in contact with the machine or other hoses.
9. Shut off the engine.
10. If necessary, put the hose in a new position where it will not make contact when the implement is moved.

ASSEMBLY OF FITTINGS WITH STRAIGHT THREADS AND O-RING SEALS

This type of fitting is used in many applications. The tube end of the fitting will be different in design so that it can be used in many different applications. However, the installation procedure of the fitting is the same. If the tube end of the fitting body is the same as in the illustration (either an elbow or a straight body) it will be necessary to assemble the sleeve on the tube before connecting the tube to the end.



ELBOW BODY ASSEMBLY

1. End of fitting body (connects to tube). 2. Fitting body. 3. Locknut. 4. Backup washer. 5. O-ring seal. 6. End of fitting that goes into other part.


1. Put locknut (3), backup washer (4) and O-ring seal (5) as far back on fitting body (2) as possible. Hold these components in this position. Turn the fitting into the part it is used on until backup washer (4) just makes contact with the face of the part it is used on.
2. To put the fitting assembly in its correct position, turn the fitting body (2) out (counterclockwise) a maximum of 359°. Tighten locknut (3) to the torque shown in the correct chart for the fitting used.

NOTE: If the fitting is a connector (straight fitting), the hex on the body takes the place of the locknut. To install this type fitting, tighten the hex against the face of the part it goes into.

TORQUES FOR FLARED AND O-RING FITTINGS


The torques shown in the charts that follow are to be used on the nut part of 37° Flared, 45° Flared and Inverted Flared fittings (when used with steel tubing), O-ring plugs, O-ring fittings and swivel nuts when used in applications to 3000 psi (20 700 kPa).

HOSE CLAMP - BAND TYPE



CLAMP WIDTH	TORQUE ON NEW HOSE	RETIGHTENING TORQUE
7.9 mm (.312 in)	0.9 ± 0.2 N•m 8 ± 2 lb in	0.7 ± 0.2 N•m 6 ± 2 lb in
13.5 mm (.531 in)	4.5 ± 0.5 N•m 40 ± 5 lb in	3.0 ± 0.5 N•m 25 ± 5 lb in
15.9 mm (.625 in)	7.5 ± 0.5 N•m 65 ± 5 lb in	4.5 ± 0.5 N•m 40 ± 5 lb in

37° FLARED AND STRAIGHT THREAD O-RING FITTINGS




37° FLARED AND STRAIGHT THREAD O-RING FITTINGS (EXCEPT O-RING FACE SEAL FITTINGS)

NOMINAL TUBE O.D.		THREAD SIZE inch	STANDARD TORQUE	
METRIC	INCH		(N•m)	(lb ft)
3.18	.125	5/16	5.0 ± 1.5	4 ± 1
4.76	.188	3/8	11.0 ± 1.5	8 ± 1
6.35	.250	7/16	16 ± 2	12 ± 1
7.94	.312	1/2	20 ± 5	15 ± 4
9.52	.375	9/16	25 ± 5	18 ± 4
9.52	.375	5/8	35 ± 5	26 ± 4
12.70	.500	3/4	50 ± 7	37 ± 5
15.88	.625	7/8	65 ± 7	48 ± 5
19.05	.750	1-1/16	100 ± 10	75 ± 7
22.22	.875	1-3/16	120 ± 10	90 ± 7
25.40	1.000	1-5/16	135 ± 15	100 ± 11
31.75	1.250	1-5/8	180 ± 15	135 ± 11
38.10	1.500	1-7/8	225 ± 15	165 ± 11
50.80	2.000	2-1/2	320 ± 30	240 ± 22

TIGHTENING OTHER FITTINGS


Hi Duty (Shear Sleeve) Tube Fittings

After tube has been put through the nut and makes contact against the tube shoulder in the fitting body, turn the nut with a wrench until a small decrease in torque is felt. This is an indication that the sleeve has been broken off the nut. Hold the tube to prevent turning and tighten the nut 1-1/2 turns.




Hi Seal Fittings

Put nut and sleeve over the tubing with the short heavy end of the sleeve facing the end of tubing. Put the tube end against the counterbore in the body of the fitting and tighten until nut is over the last thread on the body. The remainder of space is used whenever the fitting is removed and installed again.



45° FLARED AND 45° INVERTED FLARE FITTINGS





45° FLARED AND 45° INVERTED FLARE FITTINGS				
NOMINAL TUBE O.D.		THREAD SIZE inch	STANDARD TORQUE	
METRIC	INCH		(N•m)	(lb ft)
3.18	.125	5/16	5.0 ± 1.5	4 ± 1
4.76	.188	3/8	8.0 ± 1.5	6 ± 1
6.35	.250	7/16	11 ± 2	8 ± 1
7.94	.312	1/2	17 ± 3	13 ± 2
9.52	.375	5/8	30 ± 3	22 ± 2
11.11	.438	11/16	30 ± 3	22 ± 2
12.70	.500	3/4	38 ± 4	28 ± 3
15.88	.625	7/8	50 ± 5	37 ± 4
19.05	.750	1-1/16	90 ± 8	65 ± 6
22.22	.875	1-1/4	100 ± 10	75 ± 7

TIGHTENING OTHER FITTINGS

Ermeto Tube Fittings


Put nut and sleeve over the tube with head or shoulder end of sleeve next to nut. Push tube into counterbore of fitting body as far as possible. Turn nut clockwise until sleeve holds tube and prevents movement. Tighten the nut 1-1/4 turns more to seat sleeve and give a locking action. When necessary to assemble again, put sleeve over tube and tighten nut until a sudden increase in torque is felt. Then tighten 1/6 to 1/3 turn more to seat the sleeve.



Flex Fittings

Put nut and sleeve over the tubing and push tube into counterbore of fitting body as far as possible. Tighten the nut until it is against the hex part of the fitting body.

AIR CONDITIONING AND TAPERED PIPE THREAD FITTINGS



AIR CONDITIONING FITTINGS

O-RING FITTING END			45° FLARE FITTING END			
THREAD SIZE inch	STANDARD TORQUE		STEEL TUBES		ALUMINUM TUBES	
	N•m	(lb ft)	STANDARD TORQUE		STANDARD TORQUE	
	N•m	(lb ft)	N•m	(lb ft)	N•m	(lb ft)
5/8 - 18	18 ± 4	13 ± 3	30 ± 3	22 ± 2	23 ± 3	17 ± 2
3/4 - 16	37 ± 4	27 ± 3	52 ± 5	38 ± 4	33 ± 4	24 ± 3
7/8 - 14	40 ± 4	30 ± 3	60 ± 7	44 ± 5	38 ± 4	28 ± 3
1 1/16 - 14	45 ± 5	33 ± 4	75 ± 8	55 ± 6	50 ± 5	37 ± 4

TAPERED PIPE THREAD FITTINGS

PIPE THREAD SIZE inch	STANDARD TORQUE			
	THREADS WITH 1E2200E SEALANT		THREADS WITHOUT SEALANT	
	N•m	(lb ft)	N•m	(lb ft)
1/16 - 27	15	11	20	15
1/8 - 27	20	15	25	18
1/4 - 18	25	18	35	26
3/8 - 18	35	26	45	33
1/2 - 14	45	33	60	45
3/4 - 14	60	45	75	55
1 - 11 1/2	75	55	90	65

Important Safety Information

Most accidents involving product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alert to potential hazards. This person should also have the necessary training, skills and tools to perform these functions properly.

Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death.

Do not operate or perform any lubrication, maintenance or repair on this product, until you have read and understood the operation, lubrication, maintenance and repair information.

Safety precautions and warnings are provided in this manual and on the product. If these hazard warnings are not heeded, bodily injury or death could occur to you or other persons.

The hazards are identified by the "Safety Alert Symbol" and followed by a "Signal Word" such as "WARNING" as shown below.



The meaning of this safety alert symbol is as follows:

Attention! Become Alert! Your Safety is Involved.

The message that appears under the warning, explaining the hazard, can be either written or pictorially presented.

Operations that may cause product damage are identified by NOTICE labels on the product and in this publication.

Caterpillar cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product are therefore not all inclusive. If a tool, procedure, work method or operating technique not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the product will not be damaged or made unsafe by the operation, lubrication, maintenance or repair procedures you choose.

The information, specifications, and illustrations in this publication are on the basis of information available at the time it was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service given to the product. Obtain the complete and most current information before starting any job. Caterpillar dealers have the most current information available. For a list of the most current publication form numbers available, see the Service Manual Contents Microfiche, REG1139F.

SAFETY

 **WARNING**

Improper performance of lubrication or maintenance procedures is dangerous and could result in injury or death. Read and understand the lubrication and maintenance procedures, recommended by Caterpillar, that are outlined in the OPERATION MAINTENANCE GUIDE and/or OWNER'S MANUAL for this product before performing any lubrication or maintenance.

Do not operate this product unless you have read and understood the instructions. Improper operation is dangerous and could result in injury or death.

The serviceman or mechanic may be unfamiliar with many of the components and systems of this product. This makes it important to use caution when performing service work. A knowledge of the system and/or components is important before the removal or disassembly of any component.

Because of the size of some components, the serviceman or mechanic should check the weights noted in this Manual. Use proper lifting procedures when removing any components.

Following is a list of basic precautions that should always be observed.

1. Read and understand all Warning plates and decals before operating, lubricating or repairing this product.
2. Make sure the work area around the product is made safe and be aware of hazardous conditions that may exist.
3. Always wear protective glasses and protective shoes when working. In particular, wear protective glasses when a hammer or sledge is used for pounding to make repairs. Use welders gloves, hood/goggles, apron and other protective clothing appropriate to the welding job being performed. Do not wear loose-fitting or torn clothing. Remove all rings from fingers when working on machinery.
4. If an engine must be started to make pressure or speed checks, be sure all guards and shields are installed. To help prevent an accident caused by parts in rotation, work carefully around machinery that has been put into operation.
5. If an engine has been running and the coolant is hot, loosen the filler cap slowly and let the pressure out of the cooling system, before any caps, plugs or lines are removed or disconnected.
6. Corrosion inhibitor contains alkali. Avoid contact with eyes. Avoid prolonged or repeated contact with skin. Do not take internally. In case of contact, immediately wash skin with soap and water. For eyes, flush with large amounts of water for at least 15 minutes. **CALL PHYSICIAN. KEEP OUT OF REACH OF CHILDREN.**
7. Do not smoke when an inspection of the battery electrolyte level is made. Never disconnect any charging unit circuit or battery circuit cable from the battery when the charging unit is operating. A spark can cause an explosion from the flammable vapor mixture of hydrogen and oxygen that is released from the electrolyte through the battery outlets. Do not let electrolyte solution make contact with skin or eyes. Electrolyte solution is an acid. In case of contact, immediately wash skin with soap and water. For eyes, flush with large amounts of water for at least 15 minutes. **CALL PHYSICIAN. KEEP OUT OF REACH OF CHILDREN.**
8. Disconnect battery and discharge any capacitors before starting any repair work. Hang "Do Not Operate" tag in the Operator's compartment or on the controls.
9. Do not work on anything that is supported only by lift jacks or a hoist. Always use blocks or proper stands to support the product before performing any service work.
10. Relieve all pressure in air, oil or water systems before any lines, fittings or related items are disconnected or removed. Be alert for possible pressure when disconnecting any device from a system that utilizes pressure. Do not check for pressure leaks with your hand. High pressure oil or fuel can pierce the skin.

 **WARNING**

11. Never bend a fuel injection line, or install a line which has been bent. Keep the fuel injection lines and connections clean. Be sure to install caps and covers anytime a line is removed or disconnected.
 12. During service work, do not hit the fuel injection lines with wrenches or other tools. When lines are installed, use the correct torque to tighten connections and be sure all clamps and dampers are correctly installed.
 13. Make sure all fuel injection lines and pressure oil lines have enough clearance to prevent contact with any other component. Do not put any fuel or oil lines close to a hot component.
 14. To avoid back injury use a hoist or get help when lifting components which weigh 23 kg (50 lb.) or more. Make sure all chains, hooks, slings, etc., are in good condition and are of the correct capacity. Be sure hooks are positioned correctly. Lifting eyes are not to be side loaded during a lifting operation.
 15. To avoid burns, be alert for hot parts on products which have just been stopped and hot fluids in lines, tubes and compartments.
 16. Be careful when removing cover plates. Gradually back off the last two bolts or nuts located at opposite ends of the cover or device and pry cover loose to relieve any spring or other pressure, before removing the last two bolts or nuts completely.
 17. Be careful when removing filler caps, breathers and plugs on the product. Hold a rag over the cap or plug to prevent being sprayed or splashed by liquids under pressure. The danger is even greater if the product has recently been stopped because fluids can be hot.
 18. Always use tools that are in good condition and be sure you understand how to use them before performing any service work. Use only Caterpillar replacement parts.
 19. Reinstall all fasteners with same part number. Do not use a lesser quality fastener if replacements are necessary.
 20. Before doing electrical work, disconnect battery. Do not damage wiring during removal operations. Reinstall the wiring so it is not damaged nor will it be damaged in operation by contacting sharp corners, or by rubbing against some object or hot surface. Do not connect wiring to a line containing fluid.
 21. Repairs which require welding should be performed only with the benefit of the appropriate reference information and by personnel adequately trained and knowledgeable in welding procedures. Make reference to "Techniques of Structural Repair Course" form number SEGV2549. Determine type of metal being welded and select correct welding procedure and electrodes, rods or wire to provide a weld metal strength equivalent at least to that of parent metal.
 22. Be sure all protective devices including guards and shields are properly installed and functioning correctly before starting a repair. If a guard or shield must be removed to perform the repair work, use extra caution. After the repair is completed, reinstall any guard or shield that was removed.
 23. Caution should be used to avoid breathing dust that may be generated when handling components containing asbestos fibers. If this dust is inhaled, it can be hazardous to your health. Components in Caterpillar products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates and some gaskets. The asbestos used in these components is usually bound in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust which contains asbestos is not generated.
- If dust which may contain asbestos is present, there are several common sense guidelines that should be followed.
- a. Never use compressed air for cleaning.
 - b. Avoid brushing or grinding of asbestos containing materials.
 - c. For clean up, use wet methods or a vacuum equipped with a high efficiency particulate air (HEPA) filter.
 - d. Use exhaust ventilation on permanent machining jobs.
 - e. Wear an approved respirator if there is no other way to control the dust.
 - f. Comply with applicable rules and regulations for the work place (for example in the U.S.A., OSHA requirements as set forth in 29 CFR 1910.1001).
 - g. Follow environmental rules and regulations for disposal of asbestos.
 - h. Avoid areas where asbestos particles may be in the air.

