

Blue Bird wanderlodge®

WARRANTY SERVICE INFORMATION

As a service to Wanderlodge owners, Blue Bird Wanderlodge provides the following information:

On our 12 month - 12,000 mile warranty or coaches no longer under warranty, but needing service that our distributors cannot perform and needing to come back to the factory, it is very important that you or your distributor contact our customer service department and set up an appointment. Please bear in mind that our service calendar stays booked up about 45 days in advance.

When calling for an appointment the following information is important:

1. Name, address
2. Body number of your coach - length - year model
3. List of problems
4. Name of distributor from whom purchased

If you have any questions concerning service, please call Blue Bird Wanderlodge at 912-825-2021, extension 438.



WILLIAM L. BROWN

1871-1947

WILLIAM L. BROWN, 1871-1947

WILLIAM L. BROWN, 1871-1947, was a prominent figure in the history of the state of California, and his life and work are a testament to the spirit of the American West.

WILLIAM L. BROWN, 1871-1947, was a prominent figure in the history of the state of California, and his life and work are a testament to the spirit of the American West. He was a man of many talents, a leader, a writer, and a man of great vision. His life was a journey of discovery and achievement, and his legacy is a source of inspiration for all who seek to make a difference in the world.

WILLIAM L. BROWN, 1871-1947, was a prominent figure in the history of the state of California, and his life and work are a testament to the spirit of the American West. He was a man of many talents, a leader, a writer, and a man of great vision. His life was a journey of discovery and achievement, and his legacy is a source of inspiration for all who seek to make a difference in the world.

WILLIAM L. BROWN, 1871-1947, was a prominent figure in the history of the state of California, and his life and work are a testament to the spirit of the American West. He was a man of many talents, a leader, a writer, and a man of great vision. His life was a journey of discovery and achievement, and his legacy is a source of inspiration for all who seek to make a difference in the world.

WILLIAM L. BROWN, 1871-1947, was a prominent figure in the history of the state of California, and his life and work are a testament to the spirit of the American West. He was a man of many talents, a leader, a writer, and a man of great vision. His life was a journey of discovery and achievement, and his legacy is a source of inspiration for all who seek to make a difference in the world.

Blue Bird wanderlodge®

Owner Warranty Information

As a service to Wanderlodge owners, Blue Bird Body Company provides the following warranty information.

Whenever a Wanderlodge owner needs service, it is recommended that he contact his Wanderlodge Distributor. The Wanderlodge Distributor is an authorized warranty station and can make warranty repairs without charge to the owner.

In the event you are unable to get to your Wanderlodge Distributor for warranty repairs, you may have repairs performed by any local repair facility of your choice, pay for the repairs, and then write to Blue Bird for reimbursement. To enable Blue Bird to process your warranty promptly, we request that you do the following:

1. Write us a note giving owner's name, address, telephone number, body number of coach, and mileage.
2. Brief explanation of repairs.
3. Copies of all repair orders and/or parts invoices.
4. Hold all defective parts until requested to return them to Blue Bird.
5. Mail the above to:
Attn: Warranty
Blue Bird Service Parts
North Macon Road, Gate 10, Dock A
Fort Valley, Georgia 31030

If you have any questions concerning warranty, please call us here at Blue Bird 912/825-2021, Extension # 452.



1941 1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

1941-1942

Blue Bird wanderlodge®

NOTICE TO PURCHASER OF WANDERLODGE

Standard equipment on this coach includes an Escort radar detector. This unit is designed to detect radar speed traps that are in many small towns across the country. It is not to encourage speeding.

Some states have ruled these devices illegal. It is the responsibility of the driver or the owner to obey the laws of the various states regarding this device. There are two thumbscrews that are provided to loosen and detach the electrical connection for easy removal. Please remember, it is your responsibility to remove this device in states where it is illegal.



[illegible]



Chapter Number _____

APPLICATION FOR MEMBERSHIP

IN

BLUE BIRD WANDERLODGE CHAPTER OF FMCA

DATE _____

LAST NAME FIRST NAME WIFE'S FIRST NAME

HOME ADDRESS CITY STATE ZIP

YOUR FMCA NUMBER OCCUPATION

HOME PHONE OFFICE PHONE BODY SERIAL NUMBER
(ON RIGHT HAND WINDSHIELD POST)

FIRST NAME AND AGES OF CHILDREN (LIVING AT HOME)

NAME AGE NAME AGE

NAME AGE NAME AGE

NAME AGE NAME AGE

SIGNED _____

MAKE CHECK PAYABLE TO "BLUE BIRD WANDERLODGE CHAPTER"

INITIATION FEE - \$30.00 (THIS COVERS TWO JACKETS AND TWO NAMETAGS. SPECIFY
SIZE OF JACKETS, S, M, L, X, XX.)

Phil Rogers
Blue Bird Wanderlodge
One Wanderlodge Way
Fort Valley, GA 31030

YOU MUST BE A MEMBER OF THE FAMILY MOTOR COACH ASSOCIATION, OR HAVE MADE
APPLICATION FOR FMCA MEMBERSHIP, BEFORE BECOMING A MEMBER OF THE WANDER-
LODGE CHAPTER.

YOUR LIMITED WARRANTY ON YOUR NEW wanderlodge®

This sheet sets forth your Warranty on your new Wanderlodge®. You should read it carefully and keep it for future reference.

Who are the parties to this Warranty?

Blue Bird Wanderlodge, a division of Blue Bird Body Company, gives this Warranty. The terms "we," "us," and "our" in this Warranty refer to that division. The Warranty extends to the owner of the Wanderlodge®. The terms "you" and "your" in this Warranty refer to the owner.

What parts are covered?

This Warranty covers all parts of the Wanderlodge® that are made or bought by our factory and installed there, except those parts which are covered by separate warranties from other manufacturers. Those separate warranties are contained in the owner's package furnished to you by your dealer at the time of delivery. Our Warranty also does not include parts or accessories which you or your dealer bought or installed.

How long does this Warranty last?

Twelve months or 12,000 miles, whichever comes first, is the "Warranty Period." It begins on the date the vehicle is delivered to the first retail purchaser or first placed in service as a demonstrator or company vehicle, whichever is earlier. You must take your Wanderlodge® to the authorized dealer for repair during the Warranty Period.

What repair expenses does the Warranty cover?

We will pay for *all parts and labor* needed to make necessary repairs due to defects in factory material or workmanship. Those repairs must be made or arranged by an authorized dealer.

This Warranty does *not* cover maintenance services. You, as the owner, must see that the Wanderlodge® is properly maintained at your own expense. You must also pay for maintenance items, such as wiper blades, oil, spark plugs, positive crankcase ventilation valves, filters, and brake linings.

This Warranty also does *not* cover damage from things we could have no control over like collision, misuse, negligence, modifications and lack of maintenance. We do warrant that when the Wanderlodge® left our factory it was free from defects in factory material or workmanship. Repair or replacement of defective parts is your exclusive remedy under this Warranty."

Who may make a claim under the Warranty?

Whoever owns the Wanderlodge® during the Warranty Period may make a claim. In other words, the Warranty is transferred automatically when the Wanderlodge® is transferred.

What must the owner do to have defects repaired under the Warranty?

You should promptly take the Wanderlodge® to the dealer who sold it to you or to the nearest Wanderlodge® dealer. (You may obtain the name and address of the nearest dealer by writing or calling us at the address and number set forth below.) That dealer will make any needed repairs (or arrange for them to be made) within a reasonable time after you deliver the vehicle to him. You must take the vehicle to the dealer promptly after discovering any defect and, in any event, within the Warranty Period.

You are responsible for properly operating, maintaining and caring for your Wanderlodge® in accordance with the instructions contained in your Owner's Manual.

You are responsible for keeping maintenance records, since in some instances, it may be necessary for you to show that proper maintenance has been performed.

Where does the Warranty apply?

This Warranty applies to those Wanderlodge® which are legally registered and normally operated in the United States or Canada.

What if a Warranty matter is not handled to the owner's satisfaction?

Let the dealer know if you are not happy with his treatment of your claim. If you believe he hasn't treated you right, let us know the details. Write directly to the top:

General Manager
Blue Bird Wanderlodge
One Wanderlodge Way
Fort Vally, Georgia 31030

What does this Warranty not cover?

The preceding paragraphs describe everything that is covered by this Warranty.

Anything else is *not* covered. Without limiting this general statement about what is not covered, we point out as examples that telephone calls, loss of time, commercial loss, inconvenience, and loss of use of the vehicle are not covered. Similarly, equipment we do not manufacture or supply is not covered, and material separately warranted by other manufacturers is not covered. Nor does this Warranty cover any part of the vehicle which fails or malfunctions as a result of work by anyone besides us. Normal deterioration of paint and trim from weather and exposure (and damage to paint and trim after you accept delivery of the Wanderlodge®) are not covered.

Is there anything else important in this Warranty?

YES. ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY OR FITNESS, ARE LIMITED TO THE WARRANTY PERIOD OF THIS WRITTEN WARRANTY, AND WE WILL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM BREACH OF THIS WRITTEN WARRANTY OR ANY IMPLIED WARRANTY. Some states do not allow limitations on how long an implied warranty will last, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Any lawsuit for breach of this Warranty must be filed within one year of breach.

No one, including the dealer, is authorized to modify this Warranty or to make any other warranty on our behalf. There is no other express warranty on this vehicle. To the extent allowed by law, Georgia Law governs this Warranty and rights arising hereunder.

THE HISTORY OF THE UNITED STATES

OF THE

AMERICAN PEOPLE

FROM THE FIRST SETTLEMENTS
TO THE PRESENT TIME

BY

JOHN F. JOHNSON

OF THE

NEW YORK PUBLIC LIBRARY

ASTOR LENOX TILDEN FOUNDATION

100 N. 4TH ST. N. Y. C.

100 N. 4TH ST. N. Y. C.

1897

1897

NEW YORK

NEW YORK

1897

1897

NEW YORK

NEW YORK

1897

1897

NEW YORK

NEW YORK

1897

1897

NEW YORK

NEW YORK

1897

1897

NEW YORK

NEW YORK

1897

1897

NEW YORK

NEW YORK

FAMILY MOTOR COACH ASSOCIATION, INC.

Congratulations...

...you are now the proud owners of one of the finest motorhomes built in the world. The Family Motor Coach Association (FMCA) is composed of 20,000 motorhome owners such as yourselves, and we know very well the esteem in which the Blue Bird Wanderlodge is held!

The Family of FMCA members and I share your pleasure and anticipation of happy motoring days ahead. We invite you to join us and multiply the enjoyment of your motorhome by sharing in our goals of fun, family, fellowship and safe motorhome operation.

You will find a brief description of who we are and what we do in the enclosed brochure. If you would like further information, please call our National Headquarters (513/474-3622) and we will send you a copy of our monthly magazine, Family Motor Coaching. You may also prefer to meet some of us before making a decision on whether to join our family. A note or call will bring you a copy of our list of local chapter meetings in your area. These chapter activities are worthy of your consideration for membership in one because of the fun, fellowship and coaching information available when attending chapter rallies.

Happy coaching,



Harry Palmer
National President, FMCA

HP/lo

Enclosure



8291 Clough Pike, Cincinnati, Ohio 45244
Phone 513 474-3622



SECTION I

INTRODUCTION

CONTENTS

This section of your Owner's Manual contains general hints and recommendations for using your motorhome. Checklists and suggestions are offered which cover just about every phase of motorhome travel.

The remaining sections of this manual, Sections II through XI, describe in detail the operation and use of the individual items and systems which comprise your motorhome. The following paragraphs summarize the contents of these sections:

SECTION II OPERATION — Covers driver's instrumentation, operating controls, gauges and indicators. General data on operation of coach vehicular systems are also covered in this section.

SECTION III LIVING AREA FACILITIES — Covers operation of heating and air conditioning systems, use of accessories and appliances and related general coach facilities data.

SECTION IV ELECTRICAL SYSTEMS — This section describes operation of coach electrical systems, ac/dc operation and generator switching are also covered.

SECTION V WATER DISTRIBUTION SYSTEMS — Covers internal supply and distribution, plumbing, city water hookups, tank fill and sanitizing, holding tank dumping and operation of hot water supply system.

SECTION VI LPG SYSTEM — This section describes LPG internal supply and distribution, tank filling procedures, system component locations, and precautions to observe regarding LPG handling.

SECTION VII AIR BRAKE SYSTEMS — This section covers operation of the service brakes and spring brake systems, fail/safe features and general brakes system operation.

SECTION VIII OWNER MAINTENANCE

DATA — Includes information on maintenance procedures which may be within the scope of the owner. Coverage is provided for preventive maintenance schedules, specifications and system capacities, cold weather operation, storage and winterizing. Interior/exterior appearance care and emergency maintenance procedures are also described.

SECTION IX GENERAL INFORMATION — A list of major components, including model numbers, name and address of manufacturer.

SECTION X DIAGRAMS — Contains wiring, schematic, piping and general-purpose diagrams to assist in troubleshooting and understanding how these systems function.

SECTION XI OPTIONAL EQUIPMENT — This section provides you with information on optional equipment and features used in your motorhome.

We hope that this manual will answer any questions that may arise about the use, operation and maintenance of your motorhome. Any suggestions or recommendations that you might have for including or expanding on material of interest will be carefully considered for incorporation in periodic supplements. We are always interested in providing our coach owners with the most current and comprehensive information about our product.

Your satisfaction is our assurance that we are fulfilling our responsibilities to our owners.



CHECKLISTS

A little preliminary planning will go a long way to help make your trips successful and enjoyable. As an aid to planning your travels, review the following checklists. If there are any additional items that you should be reminded of, add them where you see fit. These lists are only recommendations based on the experience and suggestions of sources well-versed in motor-coach expertise. You will eventually find that a short "walk-around" the coach, outside and inside, will be adequate and comprehensive enough to ensure that you're ready for travel.

BEFORE YOU LEAVE:

- Store valuables and important papers in a safe place.
- Arrange care for your pets.
- Cover all food to keep out mice and insects.
- Store oil, gasoline, matches and other inflammables properly; get rid of newspapers, magazines and oily rags.
- Connect timers to several inside lamps and outside lights; keep some shades open for a lived-in look.
- Discontinue newspaper, milk and other deliveries; store trash cans and outside equipment.
- If weather permits, shut down hot water and heating systems; close main water supply.
- Ask the Post Office to hold your mail.
- Have your lawn, garden and house plants cared for.
- Arrange with the Telephone Company for discontinued or "Vacation Service".
- Lock all windows and doors securely.
- Leave your key with your neighbor; let him know your basic itinerary.
- Notify police.

CHECKOUT YOUR COACH -- OUTSIDE:

- Disconnect and stow:
 - a. Electrical hook-up cord.
 - b. Sewer hose hook-up (flush out).
 - c. Water hook-up hose.
- Check all exterior lights for damage.
- Check wheel lug nuts for tightness.
- Check tires for correct pressure.

- Check that all external compartments and filler openings are properly closed and/or locked.
- Check that items stored on exterior of coach are secured. (Be sure that these items present no clearance problems.)

NOTE

If the trip you are planning will take the coach well past suggested maintenance intervals listed in Section VIII, it may be advisable to perform these procedures before leaving. This may avoid unscheduled stops or interruptions during your trip.

- Check that there are no obstacles to avoid above or under the coach. Be sure that there is sufficient clearance front and rear.

CHECKOUT YOUR COACH -- INSIDE:

- Turn off water pump switches.
- Close windows and vents.
- Check that cabinet doors and drawers are closed.
- Check that refrigerator door is fastened.
- Check that no heavy items are stored in overhead cabinets.
- Store large items in base cabinets.
- Check that counter tops, range top, table tops and shelves are clear of unsecured items.
- Turn off interior lights; check that step is in closed position.
- Secure and lock the entrance door.
- Adjust exterior and interior mirrors.

CHECK YOUR AUTOMOTIVE SYSTEMS:

- Check that fluid levels are normal (oil, power steering, engine coolant, battery electrolyte, windshield washers, transmission, etc.).
- Check generator oil level, coolant level, battery condition.
- Check operation of turn signals, emergency flasher, stoplights and backup lights.
- Check that headlight high- and low-beams operate.
- Check horn operation.
- Check fuel gauge.



- Start engine and check gauges for signs of trouble.
- Check operation of foot brakes, emergency brake. (See that brake pressure builds up and steadies at about 90 to 105 psi.)
- Check tire pressure.

AND, BEFORE DRIVING AWAY:

- Check operation of appliances and special equipment.
- Check that fire extinguisher is fully charged.
- Check operation of interior and exterior lighting.
- Start generator and check 120v ac system and wall outlets.
- Adjust driver's seat so that all controls are within easy reach.
- Make sure that seat is locked in position. Do not adjust driver's seat swivel or fore-aft mechanism while vehicle is moving or seat could move unexpectedly, causing a loss of control.
- Check that front passenger's seat is locked in position.
- Fasten seat belts. Belts should be placed as low as possible around the hips. This places the load of the body on the strong hip bone structure instead of around the soft abdominal area and prevents sliding out in case of an accident.
- Check that warning lights are lit when the ignition key is turned to ON or START position.

SOME ITEMS YOU MIGHT WANT TO TAKE ALONG ON YOUR TRIP

NOTE

You may find that many items taken were not needed and that some items that were needed were overlooked during planning of your last trip. Make note of these items to prevent duplicating the same errors.

- Spare water filter element.
- Adequate supply of prescription medicines.
- Prescription sunglasses or reading glasses.
- Camera equipment and film supply.
- Heating pads, ice bags, etc.
- Stationery, envelopes, stamps.

- Telephone number list.
- Reading material.
- Special pet supplies.
- Extra toilet chemical and toilet articles.
- Spare belts for engine-operated equipment.
- Spare parts for generator: suggested spares include sparkplugs, oil filter, fuel pump, air filter, solenoid. Four quarts of approved generator oil.
- A professional-type double-action tire pressure gauge.
- Under the heading of "Emergency Equipment", it is advisable to consider outfitting your coach with these items:
 - a. First-aid kit
 - b. Emergency highway flares
 - c. Flashlight or lantern (with extra batteries)
 - d. Tool kit
 - e. Replacement lamp assortment
 - f. Replacement fuse assortment
 - g. A trouble light with a long cord

AND SOME OTHER THOUGHTS TO CONSIDER

- Automobile insurance to cover you and your family.
- Avoid cash. Use traveler's checks and credit cards wherever possible.
- Confirm reservations well in advance of arrival.
- Make a clothing check list for everyone.

CITIZEN'S BAND TRANSCEIVER

You might also bear in mind that your coach is equipped with a CB unit (Citizen's Band receiver-transmitter). In the event of an emergency situation which requires outside assistance, remember to call for help on Channel 9. This channel is restricted to emergency use only and it is monitored 24 hours per day! Be a "Good Buddy" — don't hesitate to use your CB if you see someone else in need of assistance. Remember that you will need a Canadian license to operate your CB radio during your travels in Canada.

HOT WEATHER OPERATION

Wherever possible, choose a shaded parking site so that the coach will be cooler during the hottest part of the day. The full-length side awning will



be especially useful in lowering inside temperature. Roof-mounted air conditioners are indispensable in hot climates. Keep in mind that their proper operation depends on adequate line voltage. Low voltage causes motors to run hotter and reduces compressor motor life. Supply voltage in some campgrounds may not be as high as necessary, especially when there are heavy loads on the lines from other air conditioners. Check the wall-mounted voltmeter when in doubt.

COLD WEATHER OPERATION

LPG appliances, furnace, and gas refrigerator are designed with sealed combustion areas. This is for your protection to prevent danger from carbon monoxide or depletion of oxygen. Your motorhome is equipped with Lifeguard One, a highly accurate and sensitive propane gas detector. Heed alarm indications!

If frost or condensation accumulate in closets or cabinets during long periods of cold weather operation, leave the doors to these areas slightly ajar to provide air circulation. Be sure that roof vents are open when using oven or burners.

CAMPGROUND COURTESY

Don't forget the "Golden Rule". Being considerate of your neighbors will help make friends. A few of the "Do's" and "Don'ts" are:

- Good housekeeping — put all litter in the proper receptacles and leave your site neat and clean.
- Don't allow your water or sewer hook-ups to leak.
- Respect your neighbor's desire to retire at an early hour. Avoid loud noises and bright lights after dark.
- Drive slowly through camp areas at any hour for the safety of pedestrians.

INSURANCE

As with your automobile, it is important that you have adequate protection with insurance coverages for personal liability, theft, collision, overturn, property damage, etc.

CANADIAN AND MEXICAN INSURANCE

Insurance for travel in Canada can usually be covered by your present U.S. policy for the recreational vehicle, often at no extra cost. Consult your individual insurance company for procedures and be sure of your coverage before entry.

For travel in Mexico (at the present time) there are no U.S. insurance companies that can provide recognized Mexican coverage, with the exception of that required for travel through a narrow strip of Mexican territory in and around ports of entry and the U.S./Mexican border.

Mexican insurance is controlled, and rates are set, by the Mexican government. There are several reliable companies handling Mexican insurance, with similar rates for the necessary coverages. The principal differences between them are the "fringe benefits", received in the form of informational travelogs and other helpful information, such as dining places considered acceptable for sanitary conditions, fuel stations, and so on.

Some insurance services include detailed route maps with "where to stay" recommendations and "things to see" mile-by-mile (or kilometer-by-kilometer post). While the rates set by Mexico may seem quite expensive at first glance, you usually end up not spending quite as much as expected because you can usually arrange to hold your state-side policy in abeyance during the same period you are in Mexico, thus not having to pay unnecessarily for double coverage. In addition, you may be able to obtain substantial refunds on the Mexican collision insurance after your return to the U.S. Be sure to obtain a certification from the park operator at each location in Mexico to certify the dates that your coach was parked there. If your coach is parked for most of the time, instead of constantly traveling, your refund may be a major portion of the original cost. This feature is referred to as the "in-storage" credit. (It is a good idea to always check with your insurance company before taking a trip to find out whether applicable insurance rules and regulations have changed. Keep up to date on your coverage.)

Carry insurance papers at all times!



SAFETY CONSIDERATIONS

USING LP GAS

Check for leaks at the connections on the LP gas system soon after purchase and initial filling of LP tank; continued periodic checks of the system are recommended. Even though the manufacturer and dealer have already made tests for leakage, this check is advisable because of the vibrations encountered during travel. The coach construction provides access to all gas line connections. Apply a soapy water solution to the outside of gas piping connections to find gas leakage (bubbles). Usually, tightening of connections will close leaks. (Be sure to first shut off the gas supply!) If not, ask your authorized dealer service to make the needed repairs.

Liquified Petroleum Gas (LPG) is heavier than air. Leaking gas tends to flow to low places, such as does water. It will sometimes pocket in a low area. LP gas can usually be detected by an identifiable odor characteristic to onions or garlic.

CAUTION

Never light a match or allow any open flame in the presence of leaking gas!

Be sure that the main LP gas supply valve is closed during refueling to prevent accidental ignition of gasoline fumes by appliance pilot lights.

Do not exceed the rated liquid capacity of the LPG tank. Overfilling may cause LPG to flow through the regulator causing it to freeze and create excessive gas line pressure. It is a good practice to watch while the tank is being filled to insure that this safety precaution will not be violated.

ELECTRICAL SYSTEMS

Your coach has been engineered and checked for your complete electrical system safety. Circuit breakers and fuses are installed to protect electrical circuits from overloading. Before making modifications or additions to the electrical system, consult your dealer for assistance in obtaining a safe and secure installation.

Do not "jump" circuit protectors!

BUILT-IN POWER CORD ADAPTER

Approved power supply cords are supplied with the coach for hookup to external power sources. One cord is intended for hookup to 110-volt ac 30 ampere power, and a 20-ampere adapter is also supplied with this cord. A second cord is supplied for hookup to 220 volts ac, single-phase, 50 ampere power. Note that each cord has a ground pin which provide proper electrical system grounding. The ground pin is your personal protection from electrical shock hazards. Do not use any adapter, cheater, or extension cord that will break the continuity of the grounding circuit. NEVER remove the grounding pin for convenience of being able to make a connection to a non-grounded receptacle!

NEVER operate your coach with a "hot skin"! If you can feel even a slight "tingling" shock from touching the coach body while standing outside on the ground, immediately disconnect the electrical hookup until the trouble is located. This fault is usually caused by a break in the grounding circuit, which should be continuous from the coach skin or frame to the distribution panel board to the third (ground) pin on the power supply cord, and from there to the park receptacle and earth ground. Your motorhome is equipped with dual polarity-protector alarm panels, located on the galley wall. These panels are for your protection in ensuring against improper grounding or reversed hookups, both of which will be indicated by an alarm condition. Heed alarm signals.

A power cord adapter is also supplied which will allow connection of two 30-ampere 120-volt lines (from separate external circuits) to the shore-line plug in the rear of your coach. This will allow use of all motorhome appliances without overload of the supply lines.

EMERGENCY STOPS

Always carry road flares and/or reflective triangular highway warning markers for emergency warning display. Pull off the roadway as far as possible when changing flats or for other emergency situations. Turn on your hazard warning flashers when parked alongside a roadway, even if only for a short while. Have your coach occupants leave the vehicle and stand clear of the area when parked on the edge of a highway.



ENGINE EXHAUST GAS(CARBON MONOXIDE)

Avoid inhaling exhaust gases because they contain carbon monoxide, which by itself is colorless and odorless. Carbon monoxide is a dangerous gas that can cause unconsciousness and is potentially lethal. If at any time you suspect that any exhaust fumes are entering the passenger compartment, have the cause determined and corrected as soon as possible. If you must drive under these conditions, drive **ONLY** with **ALL** windows fully **OPEN**!

The best protection against carbon monoxide entry into the vehicle body is a properly maintained engine exhaust system, body and ventilation system. It is a good practice to have the exhaust system and body inspected by a competent mechanic each time the vehicle is raised for lubrication or oil change. It should also be inspected whenever a change is noticed in the sound of the exhaust system and if the exhaust system, underbody or rear of the vehicle has been damaged.

To allow proper operation of the vehicle's ventilation system, keep ventilation inlets clear of snow, leaves, or other obstructions.

Sitting in a parked vehicle with the engine on for extended periods, without proper ventilation, is not recommended!

MORE SAFETY CONSIDERATIONS

- Sanitize fresh water supply system periodically.
- Prevent water connection fittings from contacting the ground or drain hose to reduce chances of contamination.
- Consider using a qualified technician for repairing gas or electrical appliances.
- Check fire extinguisher periodically for proper charge.
- Avoid overloading your vehicle.
- Be careful not to cause an improper load distribution which can adversely affect roadability.
- Insure that tires are in good condition and properly inflated at all times. Under-inflated tires overheat and are blowout-prone!
- Check and tighten wheel lug nuts regularly.
- Check brake operation in a safe area — not

while traveling on a busy highway!

- Use seat belts!

VEHICLE LOADING

WEIGHT DISTRIBUTION AND LOAD RATING

The Federal Certification Label, located beneath the hood ledge, and to the rear, describes the maximum weight-carrying capacities of your motorhome and for each axle, respectively abbreviated by "GVWR" and "GAWR". A typical identification plate is shown in figure 1-1.

MANUFACTURED BY BLUE BIRD BODY COMPANY			
GVWR	DATE OF MFR. _____		
	GAWR: FRONT	INTER	REAR
	_____	_____	_____
THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE			
V.I.N. _____	CLASSIFICATION _____		

Figure 1-1. Identification Plate

The Gross Vehicle Weight Rating (GVWR) is the maximum motorhome weight allowable with all systems filled and with passengers and supplies aboard.

Each axle also has a maximum load-bearing capacity referred to as the Gross Axle Weight Rating (GAWR).

A typical motorhome rating might be as follows:

GVWR 31,700 lbs	<i>1980 Brochure - 34,000</i>
GAWR (Front)	... 12,000 lbs	<i>13,200</i>
GAWR (Rear) 18,500 lbs	<i>23,000</i>

Generally, a 31-foot unit will weigh about *31 - 25,500* 24,000 pounds; a 33-foot unit will weigh about 25,000 pounds; and a 35-foot unit will weight *33 - 35 - 28,000* about 26,500 pounds. If optional equipment is installed, add the weight of the these items to determine the total weight.

The load capacity is the difference between the GVWR and the actual weight. This means the total weight of all food, clothing, other supplies and passengers, must not exceed the difference in load capacity.



When loading your motorhome, store heavy gear first, keeping it on or as close to the floor as possible. Heavy items should be stored centrally so as to distribute the weight more or less evenly between the front and the rear axles. Store only light objects on high shelves. Distribute weight to obtain even side-to-side balance of the loaded unit. Secure loose items to prevent weight shifts that could adversely affect the balance and roadability of the vehicle.

To find the actual weight, with the motorhome fully loaded, drive to a scale and read the weight on the front and on the rear wheels, separately, to determine axle loading. The load on each

axle should not exceed its GAWR. If weight ratings are exceeded, move or remove items to bring all weights below the ratings.

Additional data plates located underneath the hood table provide information useful for identifying your coach if you are planning on ordering parts. A typical identification plate, figure 1-2, provides the following information:

1. Body Serial Number
2. Chassis Serial Number
3. Model, Year
4. Model Number of Axle (if axle parts are to be ordered)

FURNISH INFORMATION BELOW WHEN ORDERING AXLE PARTS	
CHASSIS SERIAL	ENGINE SERIAL
FRONT AXLE	
BRAKE LINING KIT NO.	
REAR AXLE	
BRAKE LINING KIT NO.	
RATIO	
CHASSIS SERVICE NO.	

BLUE BIRD BODY CO.		
BODY NO.	CAP.	MODEL YR.
FORT VALLEY, GEORGIA		
BRANTFORD, ONT. - MT. PLEASANT, IOWA - GUATEMALA, C.A. - BUENA VISTA, VA.		
FACTORY SERVICE NUMBER 128746		

Figure 1-2. Typical Identification Plate

ECONOMICAL DRIVING

How you drive, where you drive and when you drive — these factors all have an effect on determining how many miles you can get from a gallon of fuel. The careful attention you give your vehicle, as far as maintenance and repairs are concerned, will also contribute to fuel economy.

ENGINE OPERATING HINTS

It is recommended that you use Number 2 diesel fuel for your diesel engine. In the event that emergency assistance is required, contact Caterpillar Tractor Company, Engine Division, Peoria, Illinois, via this emergency number:

(800) 447-4986

[In Illinois, call: (800) 322-2806.]

"JACKRABBIT" STARTS

Fuel can be conserved — and engine and tire life prolonged — by avoiding unnecessarily rapid acceleration away from lights and stop signs.

STOP-AND-START DRIVING

Frequent stops and starts during a trip diminish miles per gallon. Plan even short shopping trips to take advantage of through-streets to avoid the traffic lights. Pace your driving like the professional drivers to avoid unnecessary stops.

EXCESSIVE IDLING

An idling engine also consumes fuel. If you are faced with more than a few minutes wait, and you are not in traffic, it may be advisable to shut off the engine and re-start later on.



LUBRICATION AND MAINTENANCE

A properly lubricated vehicle means less friction between moving parts. Consult the maintenance schedules in Section VIII for proper lubricants, lubrication intervals and general coach maintenance scheduling.

AIR CLEANER

The mixture of fuel and air which powers the engine is taken into the system through the air cleaner. Replace the air cleaner at required intervals to maintain peak engine efficiency.

EXCESS WEIGHT

Fuel economy is also related directly to the amount of work accomplished by the engine. Heavier loads require more power. Keep excess weight to a minimum.

TIRE INFLATION

Under-inflation causes needless tire wear and promotes excess fuel consumption. Check tire pressures on a regular basis. (Michelin recommends that front tires be inflated to 105 pounds; rear tires should be inflated to 75 pounds.)

TRAVELING IN YOUR MOTORHOME

OVERNIGHT STOPS

There are many modern recreational vehicle parks with good facilities, including State, County and Federal Parks, where electrical, water and sewer connections are readily available. Directories are published which describe these parks in detail and list available services and hookups.

On overnight or short weekend trips, your motorhome has more than adequate holding tanks and water supply capacity in the event that campgrounds or parking sites are not equipped with these facilities.

On longer trips, where sewer connections and utility hookups are unavailable, it will be necessary to stop from time to time to dispose of holding tank wastes and replenish the water supply. Many gas stations (chain and individually-owned) have in-

stalled sanitary dumping stations for just this purpose.

When stopping for the night, park the coach in a location that is relatively level and where the ground is firm. This will ensure your comfort as well as the leveling of your refrigerator (for most efficient operation).

EXTENDED STAYS

Making a long trip is not very different from making a weekend excursion since everything you need is right at hand and you are home wherever you travel. When packing for an extended trip, try to avoid taking non-essential items.

When planning to stay in the same location for several days, weeks, or even months, be sure to maintain the motorhome level. To be sure of this, check the attitude (level) with a small bubble level set on the refrigerator freezer shelf, or on the work counter. If corrections are necessary, level the coach from side to side first. This can be done most easily by driving the coach up a small ramp consisting of 2" x 6" boards, about 4 feet long, tapered at both ends. Do not place tires in a hole to level the coach!

Hook up to the water supply by attaching the water hose to the commercial water supply inlet.

Plug the electrical cable into the shoreline receptacle. Be sure to observe all grounding and connection precautions!

Attach sewage and waste hookup into the disposal facility.

WINTER TRAVELING

Certain precautions should be taken when traveling in your motorhome during the cold winter months. Keep these suggestions in mind:

- Provide heat in the coach at all times.
- Have a plentiful supply of LPG.
- If your stay is longer than overnight, and you do not use the generator, try to have a shoreline hooked up to outside ac power.
- Minimize your use of electricity if 120v ac is unavailable.



SECTION II


OPERATION

INTRODUCTION

This section provides information on the operation and function of the controls, indicators and gauges used in connection with the coach automotive systems. Figure 2-1 illustrates the driver's compartment, highlighting the instrumentation and panels covered in later paragraphs in this section.



Figure 2-1. Driver's Compartment, Instrumentation Panels



1. ACCESSORY Position
2. ENG. HOUR Meter
3. ENG. OIL PRESSURE Gauge
4. FUEL LEVEL Gauge
5. AIR PRESSURE FRONT Gauge
6. LEFT TURN Indicator
7. Speedometer/Odometer
8. ENGINE ALARM Indicator
9. HIGH BEAM Indicator
10. LOW AIR Indicator
11. RIGHT TURN Indicator
12. Engine RPM Gauge
13. AIR PRESSURE REAR Gauge
14. ENG. AMP METER
15. ENG. WATER TEMP. Gauge
16. ENG. VOLTMETER
17. A/T Switch
18. L.H. WIPER Switch
19. R.H. WIPER Switch
20. LIGHTER
21. WINDSHIELD WASHER Switch
22. AUX. BATTERY Switch
23. WIPER HEATER Switch
24. FRONT HEAT Switch
25. RH Front HEAT Fan Switch
26. LEVELING SYSTEM Switch
27. AUX. PUMP Switch
28. LH Front HEAT Fan Switch
29. LEVELING SYSTEM Indicators

30. LEVELING WARNING SYSTEM Indicators
31. HORN SELECTOR Switch
32. DEFROST Fan Switch
33. GENERATOR VOLTMETER
34. RH Front AIR CONDITIONER Fan Switch
35. LH Front AIR CONDITIONER Fan Switch
36. GENERATOR WATER TEMP. Gauge
37. HEAT SELECTOR Switch
38. Digital Clock Panel
39. Electronic Horn Panel
40. REAR LANDING Lights Switch
41. GENERATOR OIL PRESSURE Gauge
42. HEADLIGHTS Switch
43. DASH LIGHTING DIMMER Control
44. GENERATOR HOUR METER
45. FRONT LANDING Lights Switch
46. Spotlight AIM Control
47. ACCESSORY WARNING Indicators
48. FUEL MONITOR Indicators
49. REAR PARKING LIGHTS Switch
50. Spotlight SPEED Control
51. SPOTLIGHT Selector Switch
52. DRIVING LIGHTS Switch
53. MARKER LIGHTS Switch
54. AUXILIARY STEP Switch
55. COMP. LIGHT MASTER Switch
56. BURGLAR ALARM Switch
57. FUEL LEVEL Switch
58. COMP. DOORS Switch
59. ENTRY DOORS Switch

Figure 2-2. Dashboard Instrumentation



TABLE OF CONTENTS (continued)

Preparing Drainage System for Storage	5-6	Batteries	8-3
Battery Storage in Freezing Weather	5-6	Fluid Level Checks	8-4
General Storage Notes	5-6	Water Pump Maintenance	8-5
		Windshield Washers	8-7
		Generator	8-7
		Maintenance Schedule	8-7
SECTION VI LPG SYSTEM		Battery	8-8
Introduction	6-1	Air Cleaner Maintenance	8-8
LPG Tank and Controls	6-1	Crankcase Breather Cap	8-8
Fuel Requirements	6-1	Lubrication	8-8
LP Gas and Vapor Detectors	6-2	Cooling System	8-9
LPG Regulator	6-2	Generator Troubleshooting	8-10
Operation	6-2	Refrigerator	8-11
LPG Consumption	6-2	Air Conditioning Systems	8-12
		Tub/Shower Mixing Valve	8-12
		Toilet Maintenance	8-13
		Furnace Maintenance	8-13
SECTION VII AIR BRAKE SYSTEMS			
Introduction	7-1	SECTION IX GENERAL INFORMATION	
Operation	7-1		
		SECTION X DIAGRAMS	
SECTION VIII OWNER MAINTENANCE DATA			
Introduction	8-1	SECTION XI OPTIONAL EQUIPMENT	
Specifications and Data	8-1		
Changing Tires	8-2		

LIST OF ILLUSTRATIONS

Figure 1-1. Identification Plate	1-6	Figure 3-5. Gas Range and Oven	3-4
Figure 1-2. Typical Identification Plate	1-7	Figure 3-6. Food Center	3-5
Figure 2-1. Driver's Compartment Instrumentation Panels	2-1	Figure 3-7. Tub/Shower	3-5
Figure 2-2. Dashboard Instrumentation	2-2	Figure 3-8. Toilet	3-6
Figure 2-3. Digital Clock	2-5	Figure 3-9. Bathroom Vent/Exhaust Fan	3-6
Figure 2-4. Musical Horn	2-6	Figure 3-10. Hallway Lighted Vent/Exhaust Fan	3-6
Figure 2-5. Steering Column Controls	2-7	Figure 3-11. Exhaust Fan Control Panel	3-6
Figure 2-6. Speed Control	2-7	Figure 3-12. Heater Thermostat	3-6
Figure 2-7. CB Transceiver Unit	2-8	Figure 3-13. The Thermometer and The Clock, and The Monitor	3-9
Figure 2-8. Upper Panel	2-10	Figure 3-14. Switching and Monitor Panel	3-10
Figure 2-9. FM/AM Stereo Tuner/Cassette Player	2-10	Figure 3-15. LP Gas Leakage Detector	3-10
Figure 2-10. Floor and Side Controls	2-12	Figure 3-16. Power Line Monitor	3-10
Figure 2-11. Radar Detector	2-13	Figure 3-17. Lifeguard One	3-11
Figure 2-12. Seat Controls	2-14	Figure 3-18. Electronic Door Chime Controls	3-11
Figure 2-13. TV Controls	2-14	Figure 3-19. Digital In/Out Thermometer	3-12
Figure 2-14. Transmission Shift Selector	2-16	Figure 3-20. Portable Oscillating Fan	3-12
Figure 3-1. Vacuum Cleaner System	3-1	Figure 3-21. Security Timer	3-12
Figure 3-2. Dinette Area	3-1	Figure 3-22. Air Conditioner Controls	3-13
Figure 3-3. Galley Facilities	3-2	Figure 4-1. Circuit Breaker Panels (12V)	4-1
Figure 3-4. Refrigerator Operating Controls	3-2	Figure 4-2. Battery Compartment	4-2



LIST OF ILLUSTRATIONS (continued)

Figure 4-3.	Location of Battery Chargers .. 4-2	Figure 8-3.	Oil Dipstick Location, Engine Hood Removed 8-4
Figure 4-4.	AC Power Selector Switch. 4-3	Figure 8-4.	Power Steering Reservoir. 8-5
Figure 4-5.	Load Center Circuit Breakers .. 4-3	Figure 8-5.	Transmission Dipstick Location 8-5
Figure 4-6.	Over-Current Circuit Breakers .. 4-3	Figure 8-6.	Generator Component Locations 8-7
Figure 4-7.	Generator Compartment 4-4	Figure 8-7.	Air Cleaner 8-8
Figure 4-8.	Shoreline Hookups 4-5	Figure 8-8.	Oil Dipstick. 8-9
Figure 5-1.	Location of Commercial Water Hookup. 5-1	Figure 8-9.	Generator Cooling System. 8-9
Figure 5-2.	Under-Sink Plumbing 5-2	Figure 8-10.	Cleaning Gas Burner Orifice .. 8-11
Figure 5-3.	Front Right Side Compartment 5-2	Figure 8-11.	Tub/Shower Mixing Valve 8-12
Figure 5-4.	Water Purifier 5-3	Figure 10-1.	12V Dc Supply System, Overall Wiring Diagram 10-3
Figure 5-5.	Location of Holding Tanks Drain Valves 5-4	Figure 10-2.	120/240V Ac Supply System, Overall Wiring Diagram ... 10-19
Figure 6-1.	Location of LPG Tank and Controls 6-1	Figure 10-3.	Potable Water System 10-21
Figure 8-1.	Generator Gas Tank Access Panel 8-2	Figure 10-4.	Plumbing Drainage System .. 10-23
Figure 8-2.	Locating Tire Jack. 8-2	Figure 10-5.	Heater Piping Diagram. 10-25
		Figure 10-6.	LP Gas Piping Diagram 10-27

LIST OF TABLES

Table 4-1.	Electrical Ratings for Motorhome Appliances 4-5	Table 8-3.	Motorhome Capacities and Specifications 8-1
Table 8-1.	Engine Capacities and Specifications 8-1	Table 8-4.	12-Volt Lighting and Equipment, Current Usage .. 8-1
Table 8-2.	Generator Capacities and Specifications 8-1	Table 8-5.	Water Pump Troubleshooting Guide 8-6

TOWING 7500
TONGUE 750



INSTRUMENTATION

All essential operating controls and gauges used to monitor and control the engine, generator and coach systems are conveniently grouped on the electro-luminescent dashboard panel, figure 2-2.

Additional instrumentation, accessible on the bulkhead above the driver, includes stereo AM/FM radio/cassette player, TV, generator ON-OFF switch, altimeter and diesel fuel filter monitors. Controls for TV operation are located on the left side bulkhead above the driver. The upper right panel mounts a digital inside/outside thermometer. Refer to figures 2-2 through 2-14 and the following paragraphs for locations and functions of operating controls and indicators.

DASHBOARD INSTRUMENTATION

Controls and indicators are shown in figure 2-2.

ENG. OIL PRESSURE GAUGE — Indicates the pressure of the oil, not the amount of oil in the engine reservoir. This gauge will normally read on the high side during cruising speeds; and drop to the low side when the engine is idling.

Approx 75psi

Approx 20psi

CAUTION

No oil pressure, or low oil pressure readings when engine is operating are trouble indications! Check oil level. **DO NOT OPERATE THE ENGINE UNDER THESE CONDITIONS!**

FUEL LEVEL GAUGE — Indicates amount of diesel fuel remaining in fuel tank (approximately 250 gallons for all units, except rear bath, which holds a maximum of 150 gallons). This gauge reads only when the ignition switch is in ON or set to ACCESSORY position. The fuel gauge used on 31- and 33- foot units is a dual-function gauge; it displays diesel fuel tank supply when the FUEL LEVEL GAS/DIESEL switch is set to DIESEL position; and displays the fuel remaining in the generator fuel tank when the switch is set to the GAS position.

Doesn't Agree

*31-33 50
235
35 50
265
33-36 150*

ENGINE WATER TEMP. GAUGE — Shows engine coolant temperatures from 100 to 240 degrees.

Normal is a little over 180°

CAUTION

If the temperature gauge consistently indicates excessively high engine temperatures (100 degrees higher than the outside temperature), engine is overheating and should be stopped to prevent damage. Allow engine to cool before checking the radiator and/or reservoir coolant level.

TURN SIGNALS — The left or right green turn signal lights blink in conjunction with the outside directional lights when the turn signal lever is set to the corresponding position. Both turn signals blink in unison when the emergency flasher switch on the steering column is pressed inward (ON).

HIGH BEAM INDICATOR — Lights when headlights dimmer floor switch is pressed for high beam operation and **HEADLIGHTS** switch is ON.

LOW AIR WARNING LIGHT AND BUZZER — Warning indicator is lit whenever system air pressure is below 60 psi; a buzzer, located behind the panel, also sounds for low-pressure conditions.

CAUTION

IT IS NOT SAFE TO DRIVE THE UNIT IF LOW AIR PRESSURE WARNING LIGHT IS ON AND AIR PRESSURE GAUGES DO NOT INDICATE WITHIN SAFE LIMITS (100 psi to 120 psi).

AIR PRESSURE FRONT/REAR GAUGES — The dual air service brakes pressure systems are engine-operated and supply independent brake system air pressure for front and rear service brake systems, parking brake and air-operated accessories. During normal operation, each air pressure gauge reading will build up to approximately 100 psi to 120 psi shortly after the engine is turned on. The parking brake cannot be released until air pressure readings are at least 60 psi.

ENG. AMP METER — Center-reading ammeter graduated from -100 amperes to +100 amperes shows whether battery is charging or discharging while engine is operating. Normally, the pointer reads center-scale, or slightly to the right (charge).



This meter also indicates battery current drain when the ignition is off. It does not indicate the charging current supplied by the battery chargers when the engine is off and the coach is connected to ac power. (This charging current is shown on the ammeter ~~behind the stepwell access panel~~) If the engine is off, and ac power is available, the dashboard meter shows current drawn by any 12-volt appliances, while the stepwell meter displays charging current supplied to the battery and 12-volt loads. Starting the engine allows the engine alternator to provide the charging current source, indicated on the dash meter, and automatically shuts off the battery chargers. Excessive charging or discharging can indicate charging system problems. Check battery electrolyte levels, terminals and cables for looseness or corrosion. (*Reads when ignition switch off & 12v master switch on*).

ENG. HOUR METER — Indicates total hours of engine operation. (*Will run up time with ignition switch on & engine not running*).

ENG. VOLT METER — Expanded-scale voltmeter graduated from 10 to 16 volts shows condition of battery charge when ignition is ON. Normally, battery voltage varies from 12 to 13 volts. With the engine operating, and no heavy battery loads, the battery charging voltage is about 14.7 volts. Battery voltage readings of less than 10.5 or more than 15 are usually a symptom of battery or electrical system failures. (*Reads when ignition switch off & 12v master switch on*).

SPEEDOMETER/ODOMETER — Indicates speed and accumulated mileage. *Solid state, electric, 14 gauge wire, sensor on inside RH rear dual.*

TACHOMETER — Indicates actual diesel engine RPM (revolutions per minute) X 100 on a 0 to 4,000 RPM scale. Use this gauge as an overall engine performance indicator.

NOTE

Diesel engines normally idle ~~at about~~ *between* 500 to 700 RPM. During normal running, maintain 2,000 RPM for optimum performance. Normal operating range is 2,000 to 2,800 RPM. *Engine is governed at 2,800 - Turbo 2,650.*

CIGARETTE LIGHTER — Depress to heat the element, which pops out when hot.

FRESH AIR CONTROLS — Controls in front of co-pilot's seat adjust air flow to the co-pilot's side; driver's side air flow is controlled by a *similar push/pull lever*

control located to the right of the steering column.

AIR CONDITIONER CONTROLS — Dual three-speed blower controls set the speed of the automotive air conditioner blowers for the front left and right sides of the coach. The AIR CONDITIONER thermostat, located below the steering column, controls cooling air temperature. ~~Cycling the air conditioner compressor.~~

HEAT SELECTOR SWITCH — Operates solenoid valves in engine coolant line to divert coolant flow through water heater and chassis heaters when this switch is in WINTER position. Setting the switch to SUMMER position causes the coolant to flow through the hot water supply heater coil.

FRONT HEAT SWITCHES — The FRONT HEAT ON-OFF switch which operates solenoid valves to provide heat to front heater cores. *The adjacent in back of co-pilot's kick panel* HEAT HI-LOW switches control blower air speed to the right and left sides.

AUXILIARY PUMP SWITCH — Controls the auxiliary water pump ^{up} (under left rear corner of ^{FB} coach) *behind LH rear wheels on RB coach* that circulates water through the heat exchanger, hot water heater and under-seat heaters.

DEFROST SWITCH — The DEFROST HI-LOW switch controls operation of the dual blower motors that direct defroster air to the front windows. Note that the automotive air conditioner blowers may also be used for defrosting when thermostat is in OFF position.

ELEC./AIR HORN SELECTOR SWITCH — This switch allows selection of air, electrical or musical horns on coaches so equipped. *Option 5928*

WIPER, WASHER AND HEATER CONTROLS — Separate dual ON-OFF HI-LOW switches control the operation of L.H. and R.H. WIPERS. To the right of these controls is the WIPER HEATER switch, which activates a heating element built into each wiper blade assembly. These heaters are controlled thermostatically to operate whenever the temperature falls below 39 degrees F and they maintain wiper assembly temperature between 70 and 110 degrees to prevent dangerous ice build-up. The WINDSHIELD WASHER switch operates a pump which directs streams of water to each windshield surface.



REAR, RIGHT FRONT, RIGHT REAR) will also extinguish.

CAUTION

If the jacks are not withdrawn before driving away (LEVELING switch set to OFF) the alarm will sound and the LEVELING WARNING SYSTEM indicators will be lit.

STEERING COLUMN CONTROLS

The steering column contains the horn button, turn signal lever/speed control, emergency flasher, throttle control and air conditioner temperature control. The parking brake is located below the dash, to the right of the steering column.

HORN — Operate the horn by pressing in on the center section of the wheel. Select air or electric horn with the ELEC./AIR HORN SELECTOR switch on the dash.

TURN SIGNAL LEVER — Move lever upward to signal a right turn; move downward to signal a left turn.

EMERGENCY FLASHER SWITCH — The emergency flasher switch is located on the right side of the steering column. Push the switch inward to turn on the flashing warning lights; pull switch outward to shut flashers off. Note that the dash directional lights flash in unison.

THROTTLE CONTROL — Adjust the engine idle speed by pulling this control outward (increase), or pushing inward (decrease).

A.C. TEMP. CONTROL — Operates in conjunction with AIR CONDITIONER L.H. and R.H. blower controls to set auto air cooling temperature.




Figure 2-5. Steering Column Controls

SPEED CONTROL — The speed control, figure 2-6, is part of the turn signal lever. Before the speed control can be operated to lock in the coach speed, the coach must be traveling at least 35 to 40 miles per hour. Slide the switch left to the ON position and press in the SET SPEED button at the end of the lever to set the speed into the automatic controls. Note that the accelerator can be used to increase the speed of the coach, but the speed cannot be decreased unless the brake pedal is pressed, or the speed control switch is set to OFF. If you want to resume the speed you were traveling at just before the brake was pressed, just slide the switch left to the RESUME position and the coach will automatically return to the previous speed. Be sure to set the speed control OFF when it is not being used.



Figure 2-6. Speed Control

PARKING BRAKE — The PARKING BRAKE is located on the lower dash, to the right side of the steering column. Note that the parking brake cannot be released unless the system air pressure is at least 60 psi.

CB TRANSCEIVER UNIT

Operation of the CB transceiver unit, figure 2-7, is regulated by the Federal Communications Commission (FCC). According to FCC rules, the transceiver is designed for licensed Class D operation on any of the 40 channels designated as the Citizen's Band and you are required to read and understand Part 95 of the FCC regulations prior to operating your unit. (A copy of this document is supplied with the CB unit.) Also, you MUST obtain a Class D Station License before operating the CB. Transmitting without a license can result in penalties. If you do not have a license, fill in the application provided with the CB and mail it to the FCC. No oral or written examinations are required.




Figure 2-7. CB Transceiver Unit

CONTROLS AND INDICATORS — The functions of the controls and indicators shown in figure 2-7 are described in the following paragraphs:

PRESS-TO-TALK SWITCH (7) — Used during operation to control reception and transmission. Press the switch in to transmit; release to receive.

ON-OFF/VOLUME CONTROL (8) — During normal CB operation, turns unit on and off and controls speaker volume.

SQUELCH CONTROL (9) — Allows operator to set receiver squelch so that only signals above the set level are heard. Weaker signals and background noise are eliminated.

RF GAIN CONTROL (2) — Adjusts the receiver sensitivity to reduce interference from weaker transmitters on a busy channel. When turned fully clockwise, the receiver is at maximum sensitivity. As the control is turned counterclockwise, the receiver becomes less sensitive to interference from weaker transmitters, resulting in clearer reception of the desired signal. The RF GAIN control is very effective when used in a crowded urban area.

ANL CONTROL (11) — Reduces ignition noise and other man-made noises that may make the received signals unintelligible.

TX/RX INDICATOR (6) — The transmit/receive indicator lights red when transmitting, green when receiving.

CHANNEL INDICATOR (4) — Displays selected channel.

PA/CB SWITCH (10) — When the public address switch is in PA position, the operator can use the transceiver as a PA system through the roof-mount speaker. Keep switch in CB position for normal operation.

S/RF METER (3) — S/RF scale of meter indicates strength of received signals in "S" units. Relative RF output power of the transmitter is also shown.

CHANNEL SELECTOR (5) — This switch selects the desired channel for transmission and reception. All channels, except channel 9, may be used for communications between stations operating under different licenses. Channel 9 has been reserved by the FCC for emergency communications involving the immediate safety of individuals or immediate protection of property. Channel 9 may also be used to render assistance to a motorist. This is an FCC rule and applies to all operators of CB radios.

DIMMER SWITCH (12) — This switch is used to adjust the brightness of the LED channel display and the meter.

CH9/OFF SWITCH (13) — Placing this switch in CH9 position switches the receiver and transmitter to Channel 9 regardless of the channel selector position. Set to OFF position to restore normal operation.

CH9 INDICATOR (14) — Indicator lights red to show that CH9 switch is activated.

MIC GAIN CONTROL (1) — Varies the modulation level for best possible transmission. When CB is used in PA mode, this control allows adjustment of PA volume.

OPERATION

1. Set OFF/VOLUME control (8) clockwise and note that these indicators light:

- S/RF meter (3)
- Channel indicator (4)
- TX/RX indicator (6) lights green

Radio will not operate unless microphone is connected.



A/T SWITCH — Activates anti-theft circuits.

MARKER LIGHTS SWITCH — Operate this control to turn on the clearance lamps located on the top, sides and ends of the coach.

LANDING LIGHTS SWITCHES — Controls ON—OFF operation of FRONT and REAR LANDING LIGHTS. *Option 5940 + 5939*

REAR PARKING LIGHTS SWITCH — Controls ON—OFF operation of rear parking lights. *Rectangular Halogen Light right above rear bumper. Add lighting*
DRIVING LIGHTS SWITCH — Controls front and rear driving lights. *that are recessed in front bumper.*

HEADLIGHTS SWITCH — Varies *dash gauges* headlights intensity from off to full brightness. *Three position switch that operates exterior lights & dash gauge lights like in an automobile.*

COMP. LIGHT MASTER SWITCH — ON—OFF switch controls operation of all exterior compartment lights.

Temporarily Not Being Used

COMP. DOORS SWITCH — Operates solenoid latches to secure exterior compartment doors by setting switch to LOCK; allows doors to be opened (key-operated) when switch is set to UNLOCK.

FUEL MONITOR INDICATORS — Three in-line indicators monitor diesel fuel supply flow (MAX FUEL FLOW), low fuel level (LOW FUEL) and the accumulation of condensate (WATER IN FUEL).

ACCESSORY WARNING INDICATORS — Three warning indicators alert the driver to the following:
SUSP. DUMP — lights to indicate that suspension system has to be pressurized before coach is driven;
GEN. DOOR LOCK — indicates that generator tray is extended; and, **HEADLIGHT ALERT** — to indicate that the headlights have been left on after the ignition has been turned off.

ENGINE ALARM INDICATOR — Indicator lights and buzzer sounds to alert driver when associated engine monitors detect an abnormal operating condition.

ENTRY DOOR SWITCHES — Dual switches to LOCK and UNLOCK entry door.

DASH LIGHTING DIMMER CONTROL — Adjusts intensity of electroluminescent panel markings.

AUXILIARY STEP SWITCH/INDICATOR — This indicator is lit whenever the entry step is extended. Use the switch to withdraw or extend the step.

AUX. BATTERY SWITCH — Operating this momentary switch connects the generator and engine batteries in parallel to provide a greater current source for hard-starting situations. Release switch after engine starts.

BURGLAR ALARM SWITCH — Activates coach burglar alarm system.

DIGITAL CLOCK/ELAPSED TIMER — The digital clock and elapsed time digital readout is located in the center of the dash, figure 2-3. Four controls to the left of the display set clock timing. To set TIME DISPLAY, press HR.SET/MIN. SET switch to HR.SET position and hold until correct hour is displayed; repeat with switch in MIN.SET position until correct minutes are displayed.

The ELAPSED TIME display will show elapsed time in terms of hours and minutes, or in minutes and seconds, depending on the position of the HRS./MIN.—MIN./SEC. switch. Set this switch as desired, press ZERO to reset the display to a 00:00 readout, and the elapsed time will count. Use the HOLD/GO switch to suspend operation of the elapsed time display when desired by setting this switch to HOLD position. For elapsed time operation leave switch in GO position.




Figure 2-3. Digital Clock/Elapsed Time Display



GENERATOR VOLTMETER — Expanded-scale voltmeter, with scale graduations from 10 to 16 volts, shows the condition of the generator battery. Normally, the battery voltage varies from 12 to 13 volts; under starting load it may drop to about 10.5 volts and then rise to about 14.7 when the generator starts and begins charging the battery. Battery voltage readings less than 10.5 or more than 15 are usually a symptom of a battery or an electrical system failure.

GENERATOR WATER TEMP. GAUGE — Shows generator engine coolant temperature from 100 to 240 degrees. If consistently high temperatures are indicated, shut down the generator, wait for the engine to cool, then check radiator coolant level.

GENERATOR OIL PRESSURE GAUGE — Shows the oil pressure, not amount of oil in the generator engine reservoir. This gauge will normally read mid-scale (about 40). Low oil pressure indications are often a symptom of possible generator failure. Oil level should be checked on a regular basis.

GENERATOR HOUR METER — Indicates total hours of generator operation.

MUSICAL HORN — The Bluebird Musical Horn is a solid-state self-programmed electronic horn which can play a number of tunes available from the integral computer storage “library”. This unit is located in the dash beneath the digital clock, as shown in figure 2-4.

All of the music, and the programs for playing the tunes, are stored in a “Read Only Memory” (ROM). The selections contained in this ROM can be chosen by setting the two thumbwheel **SELECT** switches to the appropriate selection number, then depressing the **PLAY** button to play out the tune. The **POWER** switch must be **ON** for the horn to

function. Note that the digital memory is not erased when power is disconnected from the unit, or if the **POWER** switch is set to **OFF**.

To play a tune of your own choosing, plug the auxiliary keyboard into the **KEYBOARD** connector and select the musical tones manually. Note that the thumbwheel switches must first be set to 0,0 for the keyboard to function.

REMOTE SPOTLIGHT CONTROLS

The roof-mounted remote-control high-intensity spotlight is operated by the **SPOTLIGHT** controls located on the left side of the dash. The spotlight produces 100,000 BCP (beam candle-power) and can be turned on and off, positioned horizontally or vertically at an adjustable rate of speed, and can be used for spot- or flood-lighting. The following controls operate the spotlight:

SPOT-OFF-FLOOD SWITCH — Selects type of beam desired and controls **ON-OFF** operation.

SPOTLIGHT AIM CONTROL — Controls horizontal and vertical beam position.

SPOTLIGHT SPEED CONTROL — Adjusts speed of rotation.

LEVELING JACKS CONTROLS

Four electrically-operated leveling jacks, one at each corner of the coach, are controlled at the dashboard by operation of the **LEVELING MASTER** switch. Each of the leveling jacks is independently operated and provides visual and audible status signals to the dashboard indicators and alarms to show that the jacks are down and the coach has been leveled automatically.

Use the following procedures to operate the leveling jacks:

1. Set **LEVELING MASTER** switch **ON**, note that four red **LEVELING WARNING SYSTEM** indicators are lit (**LEFT FRONT**, **LEFT REAR**, **RIGHT FRONT**, **RIGHT REAR**) indicating that the jacks are being lowered. If the ignition is **ON**, the alarm will also sound.

2. When the jacks are down and the coach has been automatically leveled, the four green **LEVELING SYSTEM** indicators (**LEFT FRONT**, **LEFT**



Figure 2-4. Musical Horn



2. Adjust **VOLUME** control (8) for desired listening level. Be sure that **PA/CB** switch (10) is in **CB** position.

TO RECEIVE —

1. Select desired channel. Note that the **S/RF** meter (3) indicates the relative strength of the received signals.

2. Adjust **RF GAIN** control (2) for clearest reception of selected signal, reducing unwanted signals in strong signal areas.

3. Adjust **ANL** control (11) to reduce unwanted noise and maintain minimum audio distortion.

4. Set **SQUELCH** control (9) fully counterclockwise, then advance control clockwise until background noise and undesired weak signals are eliminated.

TO TRANSMIT —

NOTE

Remember that Channel 9 has been designated as an emergency channel and that its use is primarily restricted to communications involving the immediate safety of life and protection of property; and, secondarily, to provide assistance to motorists. Many **CB** clubs, police, rescue units, hospitals and garages monitor Channel 9. Emergency calls made on any channel must be given priority!

Before transmitting, make sure that the channel is clear.

1. Position microphone close to your mouth and at a slight angle.

2. Monitor the channel and, when clear, press and hold the **PTT** switch (7). The pointer on the **S/RF** meter (3) will deflect into the red area, indicating normal relative power output.

3. Contact the party you wish to speak with. Speak clearly and in a normal voice. To hear a reply, release the **PTT** switch.

INTERPRETING S/RF METER READINGS —

The **CB** unit is equipped with a multi-function meter. The **S/RF** scale indicates both the relative transmitter output power and the received signal strength. By interpretation, the meter can also indicate the condition of the **CB** antenna circuit.

The received signal strength scale is calibrated in **S** units, the stronger the received signal, the more the meter deflects to the right. For example, **S1** represents a very weak signal, **S5** is an average signal, and **S9** is an extremely strong signal. When using **RF GAIN** control (2) these readings apply when the control is clockwise (maximum gain). The meter will still show relative signal strength when **RF** gain is used and it should be used as a monitor when setting the **RF GAIN** to the correct level. As an example, the desired voice signals may be received at an **S9** level but, at the same time, interfering signals are being received at an **S3** level. (Strength of the interference can be read on the meter during a break in transmissions of the higher signal.) To cut down on the weaker signals, adjust receiver sensitivity with the **RF GAIN** control so that the strength of the **S9** signal drops to an **S6** level, and this will eliminate the interference.

For best performance and system reliability, the antenna **SWR** (Standing Wave Ratio) must be as low as possible. A low **SWR** ensures that most of the **RF** output energy is being radiated through the antenna, instead of being reflected back into the transmitter. A high **SWR** reduces communications range and, if sustained, can shorten the life of the equipment.

USING SQUELCH CONTROL — With the control fully open (counterclockwise), the receiver is so sensitive that even very weak signals from low power "Walkie-Talkies" and distant radio sets may be received. Many of these signals will be unintelligible due to range and atmospheric conditions. As the **SQUELCH** control is advanced clockwise, stronger and stronger signals are required to "unsquelch" the receiver. In this way, the operator can establish the desired level that a signal must exceed before it is audible.

PUBLIC ADDRESS OPERATION — The **PA** feature allows the operator to hear messages from outside the coach, as well as make announcements over the **PA** speaker.

1. To hear received signals over the **PA** speaker instead of the internal **CB** speaker, place **PA/CB** switch in **PA** position. Adjust loudness with the **VOLUME** control.

2. To use the **PA** speaker for public announcements, or as a one-way intercom, place the **PA/CB** switch in **PA** position, press **PTT** switch and speak




Figure 2-8. Upper Panel

into the microphone. Speaker loudness depends only on voice level and microphone gain setting. In this mode, the **VOLUME** control has no effect on voice level. To silence received signals that may be heard when the **PTT** switch is released, turn the **VOLUME** control fully counterclockwise, but do not turn it off.

OVERHEAD INSTRUMENTATION

The upper panel, figure 2-8, located on the bulkhead directly over the driver, contains the FM/AM stereo tuner/cassette tape player, Safeline Alarm panel, generator start-stop switch, altimeter, water-in-filter gauge and test switch, speaker fader controls and closed-circuit TV/receiver. The digital thermometer panel is located on the center bulkhead.

FM/AM STEREO TUNER/CASSETTE PLAYER

OPERATING CONTROLS (Figure 2-9)

VOLUME/ON—OFF/BALANCE/TREBLE CONTROL — In the normal position, this control is a

conventional volume/power on-off control. To use for balancing the stereo outputs, push the control inward and adjust as required; to adjust treble response, pull the control outward to adjust.

BASS CONTROL — Turn this outer ring clockwise to increase bass response; turn counterclockwise to decrease bass response.

TUNING CONTROL — Provides manual and automatic station selection. For manual selection, turn the control until the digital readout shows the desired station, then adjust for fine tuning. To use for automatic station selection, just depress the control momentarily and it will advance upward in frequency to the next clear station. Note that the control works automatically only in an increasing range; it will not select downward. (This control is also used in setting the time display, described later on.)

FADER CONTROL — Balances front/rear speakers.

FM/AM SWITCH — Depress inward for FM operation; release outward for AM operation.




Figure 2-9. FM/AM Stereo Tuner/Cassette Player



LOC/DX SWITCH — Increases tuning sensitivity for long-range (DX) stations when released to out position; push inward for local (LOC) stations.

FMO SWITCH — When pressed inward, this switch improves reception of “noisy” signals” in weak signal areas.

1 THROUGH 6 PRESET STATION SWITCHES — These switches operate with the MEMORY button to store stations for memory selection.

DOLBY NR SWITCH — Depress to ON position when playing tapes recorded by the Dolby Noise Reduction system; leave switch in outward position for other tapes.

METAL/CRO2 SWITCH — Press this switch inward when playing metal or CrO2 tapes; leave switch in the outward position for all other tapes.

INQ SWITCH — Press switch inward for “Impulse Noise Quieting” to eliminate impulse-type noises on FM stations.

DISPLAY SWITCH — Depress this switch momentarily to display the selected radio station on the digital readout. After five seconds the display reverts back to a time readout.

MEMORY SWITCH — Depress this switch to use the MEMORY function and insert the selected AM or FM station into memory. This switch is also used to set the display time, together with the TUNING control.

EJECT, TAPE SLOT, PROGRAM SELECT — Insert cassette into slot with exposed tape on right side. To eject tape, push EJECT button; to reverse tape, press both PROGRAM SELECT buttons at the same time.

RADIO OPERATION —

1. Turn POWER switch ON and adjust the VOLUME control. Select AM or FM operation.
2. Adjust TUNING control for desired station. Note that digital display shows station frequency. For automatic station selection, depress TUNING control inward to tune radio to the next available higher-frequency station. Note that stations can be selected only in an increasing range, not in a decreasing frequency range.

3. Adjust BASS, TREBLE and BALANCE controls as desired.

4. To insert a selected station into MEMORY (up to six may be chosen), tune into the station and push in the MEMORY switch. Note that the MEMORY indicator will light for five seconds to show that the memory is functioning. During this five-second period, press in one of the six memory pushbuttons to lock the station into memory. Repeat with the remaining five pushbuttons for the additional stations to be selected.

TAPE OPERATION —

1. Insert the tape into the tape slot with the open side of the tape to the right.
2. Turn POWER switch ON, adjust VOLUME, tone and BALANCE controls.
3. Select the DOLBY NR and METAL/CRO2 switches as desired to match the tape used.
4. Push either PROGRAM SELECT switch for the desired direction of tape play. To rewind, in either direction, the switch must be pressed inward fully. Note that the tape deck can be reversed at any time by pressing both switches simultaneously. Otherwise, the tape will automatically reverse at the end.

DIGITAL CLOCK OPERATION — To set the time into the clock, push in and hold MEMORY switch while turning the TUNING CONTROL counter-clockwise to set hours; or counterclockwise to set minutes. Keep operating the MEMORY button until the correct time is set, then release.

ALTIMETER — Indicates coach height above sea level. (Zeroing adjustment can be used to calibrate unit at known elevations.)

FILTER ELEMENT GAUGE — Shows condition of Racor filter in terms of fuel line vacuum. High vacuum readings indicate restricted fuel flow.

WATER-IN-FILTER SWITCH/INDICATOR — The indicator portion of this switch will light when excessive condensate has accumulated in the Racor filter bowl.

SAFELINE CONNECTION ALARM — Contains a buzzer, ON-OFF switch and dual alarm indicators, one red and one amber. The Safeline alarm operates whenever the shoreline is connected to the coach and the ignition switch is in ON position,



as a reminder to disconnect the shoreline before driving away. The alarm is given when the buzzer sounds and red indicator lamp lights. The buzzer alarm can be disabled in favor of the blinking amber indicator lamp by setting the buzzer switch to the OFF position.

SPEAKER CONTROLS — Adjust sound distribution between front and rear speakers.

GENERATOR START/STOP SWITCH — Provides local control for generator operation. Press this center-off momentary switch to **START** position and hold until generator starts, as indicated by the switch indicator illuminating. If generator does not start within 15 to 20 seconds, release switch, wait 30 seconds, then try again. To shut down the generator, press to **OFF** position and hold until light extinguishes.

CAUTION

Do not start the generator when a heavy circuit load is on-line, such as the air conditioners. This can cause an excessive strain on the generator rotating components and may result in equipment damage.

NOTE

When starting a diesel-type generator during extreme cold weather, press the switch in to **OFF** position for a minute. This activates the pre-heater in the fuel supply line to aid in easier starting.

FLOOR AND SIDE CONTROLS (Figure 2-10)

HIGH BEAM SWITCH — Press switch once to turn on high beams (when normal headlights are on). Note that **HIGH BEAM** light on dash is lit. Press the switch again to restore normal headlights.

AIR HORN FOOT SWITCH — Operates 'highway' horns.

BRAKES — The coach is equipped with a dual air brake system which includes two independent systems for the front and rear service brakes. A separate reservoir and panel-mounted pressure gauge is provided for each service brake system.




Figure 2-10. Floor and Side Controls

ACCELERATOR — The accelerator pedal controls the speed of the coach by opening and closing the engine control fuel flow line. This pedal also controls the transmission low-gear kick-down mechanism which provides rapid acceleration from slow speeds.

IGNITION SWITCH—The ignition switch is a four-position, standard-type key switch. In **OFF** position (center), ignition and accessory positions are disabled and the key can be inserted or removed. In **ON** position (right) the battery is connected to the ignition circuits and the key can be advanced to **START** to start the engine. **ACCESSORY** position (left) allows operation of accessories without activating the ignition circuits. Note that **CCTV** operation occurs only in **ON** position; setting the ignition to **OFF** allows use of standard TV.

NOTE

The engine can be started only when the transmission selector is in the **N** (neutral) position.

VOLT MASTER SWITCH — Set this switch **OFF** to turn off all 12-volt supplies except the digital clocks, monitoring panels and burglar alarm.

DUMP SWITCH — This switch controls the inflation of the coach air suspension system. When the



coach is parked for any period of time, set switch to ON to dump the air bags. Note that the SUSP. DUMP ACCESSORY WARNING light is lit. Set the switch to the OFF position to re-inflate the air bags before driving away. (System air pressure must be at least 65 psi.)

WHEEL TILT SWITCH — Controls air-operated steering wheel tilt mechanism to allow positioning of steering wheel to one of three detent positions. Flip lever back to lock wheel into position.

CAUTION

Always make sure that lever is in the fully locked position in whichever detent setting is used. Do not change the wheel tilt setting while the coach is in motion.

COMPASS UNIT

The compass, mounted above the dash panel, is a high-precision automotive-type unit, accurate to within 5 degrees. The compass mechanism is floated in a special fluid that is unaffected by temperature extremes. If it is necessary to re-calibrate the unit, follow manufacturer's directions.

RADAR DETECTOR

A radar detector is installed as standard equipment on your coach. This unit, shown in figure 2-11, is designed to activate when transmissions are received from radar-type speed detection equipment. Please remember: the purpose of the radar is to encourage caution — not speeding!

NOTE

Because some states have ruled radar detection equipment illegal, it is the responsibility of the driver or owner to obey the appropriate laws. (There are two thumbscrews that are provided which may be loosened for easy removal of the unit.)

CONTROLS AND INDICATORS — Operating controls and indicators are listed below:

CHECK SPEED Indicator — Provides flashing red warning light indicating radar detection.

ON-OFF Sensitivity Control — Applies power




Figure 2-11. Radar Detector

to unit and adjusts sensitivity threshold for maximum response.

VOLUME Control — Sets volume of audible warning signal.

POWER Indicator — Lights when power is on.

OPERATION — Although the detector is designed to prevent reception of false alarms, microwave telecommunications towers can sometimes cause a false alarm. The extreme sensitivity of the unit makes it most important for the driver to heed ALL warnings. Reflected radar scatter from a moving radar, going in the same direction ahead of you, or behind you, can be detected by your unit. Remember, the unit can detect up to 10 times the effective distance of police radar!

Operate the radar detector as follows:

1. Turn on unit by rotating the ON/OFF sensitivity control clockwise past the "click". The green POWER indicator will light. The unit may beep a few times, then it will stop as it warms up.

2. After initial beeping has stopped, turn the sensitivity control clockwise again until a constant beeping is audible. Then back off the control in a counter-clockwise direction, slowly, until the beeping stops. The unit is now set at its highest sensitivity level.

3. Should the unit start beeping constantly at non-police radar signals (false alarms) turn sensitivity control counter-clockwise until the beeping stops. This de-sensitizing of the unit allows for its operation in heavily microwave-concentrated areas without excessive false alarms.



SEAT CONTROLS

Electrically- and air-operated seat adjustments are built into the driver's and co-pilot's seats. A typical control panel is shown in figure 2-12.

Three **ELECTRIC SEAT CONTROLS** are used to control seat bench tilt; up-down and front-back seat movement; and seat back tilt. The **SIDE SLIDE** switch operates an air cylinder which locks the position of the slide mechanism beneath the seat. Set switch **ON** to disengage the seat slide lock, adjust side-to-side position, then set to **LOCKED** to re-engage lock mechanism. This switch must be kept **LOCKED** to secure the seat during travel.




Figure 2-12. Seat Controls

CLOSED-CIRCUIT TV/RECEIVER SYSTEM

Besides the TV receiver on the upper panel, the CCTV/receiver system also includes:

- CCTV camera, located in the rear bulkhead;
- VHF/UHF tuning and TV receiver controls, on the side panel above and to the left of the driver;
- Roof-mounted TV antenna/rotator, remotely operated by controls in the side compartment above and to the rear of the co-pilot.

CCTV OPERATION — When the system is used for CCTV operation, the rear-facing CCTV camera transmits images directly to the monitor via coach cabling. CCTV operation can only occur when the ignition is **ON**. For normal operation, when the ignition is **OFF**, the system functions as a conventional TV receiver, via the controls shown in figure 2-13. Also, it is normal for the system to

require a brief warmup period before achieving full resolution. Note that CCTV camera controls are preset and the standard lens supplied with the unit is designed to focus from about two feet to infinity.



Figure 2-13. TV Controls

TV OPERATION — Use the monitor as a standard TV, with ignition **OFF**, via the TV panel controls.

TV ANTENNA AND ROTATOR SYSTEM

The control components of the antenna and rotator are a hand-held switch-operated rotator, radome-type TV roof antenna, and a coupler-switcher for the antenna or cable inputs.

The A-C switch on the coupler selects antenna (A) or cable (C) input via connections in shoreline compartment at the rear of the coach. Additional switches on the coupler route the antenna/cable inputs to the TV receiver.

The antenna rotator controls the position of the TV antenna within the radome. The three-position momentary switch (center OFF) provides right/left antenna rotation, with antenna position displayed on the control unit. The rotator power supply is also located in the radome, which, in addition to the antenna, also includes an amplifier and rotator mechanism. The remote power supply is designed to operate from either 120 volts ac or 12 volts dc. A 30-foot length of low-loss coaxial cable and three-wire rotator control cable interconnect the antenna and power supply. Both of these cables are contained within a prefabricated, single-jacketed cable assembly, included with the unit.



Note that a .8 ampere fuse is connected in series with the 12-volt dc supply line to the unit. In the event that the TV set exhibits problems relating to low antenna input ("ghosts", etc.) check this fuse before servicing the TV set.

OPERATION

With the TV on and a station tuned in, rotate the antenna by pressing the rocker switch located on the control unit. Press the right side of the switch to turn the antenna clockwise; press the left side to turn the antenna counter-clockwise. Although the actual antenna movement is not visible, the indicator arrow on the control unit lights and shows the direction of the antenna. When the antenna has made one full turn (360 degrees), the End of Rotation light comes on. Observe the picture while rotating the antenna, first in one direction, then the other, to obtain best picture quality.

DIESEL ENGINE OPERATION

Proper operation and maintenance are key factors in determining the useful life and operating economy of a diesel engine. Follow these directions for trouble-free, economical engine operation.

TO START ENGINE — Caterpillar diesel engines will start at temperatures above 10 degrees F (-12 degrees C) without using a starting aid. However, for temperatures below 10 degrees F it may be necessary to activate the engine block heater (120 v ac-operated) to heat the crankcase oil. The engine block heater switch, located near the engine hood on the co-pilot's side, should be set ON; the adjacent indicator lamp will light. Remember to set switch OFF when the heater is no longer needed.

1. Place transmission in NEUTRAL.
2. Push accelerator pedal to half-speed.
3. Turn ignition switch to START. If engine fails to start within 30 seconds, release the starter switch and wait 60 seconds to allow the starter motor to cool before trying again.
4. As soon as the engine starts, reduce engine speed to low idle. Use throttle control on steering column as necessary to set idle speed.
5. Do not apply a load to the engine or increase engine speed until oil pressure gauge indicates

normal. Oil pressure should rise within 15 seconds after engine starts.

6. Operate the engine at low load until all systems reach operating temperatures. Check all gauges during warmup period.

AFTER ENGINE STARTS —

1. Reduce speed to low idle, with no load. When normal oil pressure is reached, run engine at low load for 5 minutes before applying full load. Rapid acceleration causes heavy exhaust smoke and high fuel consumption.
2. Accelerate to near-governed RPM. To avoid lugging, operate in a gear range low enough to permit the engine to accelerate under load.
3. Continue to accelerate until cruising speed is reached. Under load, maintain engine speed between 80% and 100% of rated RPM.
4. On upgrade, downshift if engine starts to labor. Downshift until a gear is reached in which the engine will pull without lugging.
5. **DO NOT LUG ENGINE.** Lugging results in excessive smoke and high fuel usage. A lug condition exists when an increase in engine speed cannot be achieved with an increase in accelerator pedal position; or when the engine speed decreases with the accelerator pedal floored. Do not lug engine below 2,000 RPM for more than several seconds.
6. On downgrades, do not coast or put transmission in NEUTRAL. Select the correct gear to keep the engine speed below high idle and retard the vehicle. A simple rule to follow is to select the same gear that would be used to go up the grade.
7. Before stopping the engine, operate at low idle for 30 seconds. This will allow hot areas in the engine to cool gradually, extending engine life.

DO NOT OPERATE THE ENGINE AT LOW IDLE FOR LONG PERIODS

TO STOP ENGINE — Turn ignition switch OFF.

TRAILER HITCH CAPACITY

Hitch capacity is 7,500 pounds tow; 750 pounds tongue. Refer to figure 10-1 for electrical wiring.



TOWING

CAUTION

Do not tow a vehicle equipped with Allison automatic transmission unless the rear drive shaft has been removed, or the rear wheels raised from the ground. Use caution when towing unit by front axle or cross-member. Damage to wiring and/or air lines can result because of proximity of these items to front cross-member.

TRANSMISSION START-UP INSPECTION

No Longer Applicable

All Allison automatic transmissions delivered to an original retail purchaser of highway vehicles are eligible for a Transmission Start-Up Inspection if presented to an authorized Detroit Diesel Allison Service outlet within 90 days after delivery, or within 10,000 miles, whichever comes first. This inspection includes a complete check of the transmission installation and a road test to ensure that the transmission is operating satisfactorily. The inspection will be performed at no additional charge except for filter elements, lubricants and other maintenance materials. It is recommended that you take advantage of this service to realize the maximum benefits from your Allison-equipped vehicle. (Check the Yellow Pages under Transmissions - Truck or Engines - Diesel, for your nearest authorized service outlet.)

OPERATION

The Allison transmission provides four forward gears and one reverse gear. Speed selection is provided through the transmission shift lever located on the side wall, shown in figure 2-14.

The selector lever must be in N (neutral) position when the engine is started. If the engine can start in any other position, the neutral start switch is defective and should be replaced as soon as possible. Use D (drive) position for all normal driving conditions so that the coach begins moving in first gear and, as the accelerator is depressed, the transmission upshifts automatically into 2nd, 3rd, and

4th gears. As the coach slows down, the transmission automatically downshifts to the correct gear. Use a low gear (2nd or 3rd) when road, load or traffic conditions make it desirable to restrict automatic shifting to a lower range. When conditions improve, return range selector to normal D position. These positions also provide progressively greater engine braking action (the lower the gear range, the greater the braking effect). Use 1st gear when pulling through mud and snow or driving up steep grades. This position provides the maximum engine braking power. Use R (reverse) for backing the vehicle. The vehicle should be completely stopped before shifting from a forward gear to reverse. Reverse gear provides the greatest tractive advantage.

NOTE

In the lower ranges, 1st, 2nd and 3rd, the transmission will not upshift to the highest gear selected unless the recommended engine governed speed for that gear is exceeded.




Figure 2-14. Transmission Shift Selector



DRIVING TIPS

ACCELERATOR CONTROL — Foot pressure on the accelerator pedal influences the automatic shifting. When the pedal is fully depressed against the floor pedal stop, the transmission automatically upshifts near the recommended governed speed of the engine. A partially-depressed position of the pedal causes the upshifts to occur sooner at a lower engine speed. Shift timing is accomplished by using a cam and cable from the throttle. This method provides the accurate shift spacing and control necessary for maximum performance.

DOWNSHIFT CONTROL — The transmission can be downshifted or upshifted, even at full throttle, and, although there is no speed limitation on upshifting, there is a limitation on downshifting and reverse. Good driving practices indicate that downshifting should be avoided when the vehicle is over the maximum speed attainable in the next lower gear. Therefore, the good driving habits have been designed into the Allison transmission shift pattern for your benefit. The downshift inhibitors within the valve body prevent those harmful shifts when the vehicle is traveling too fast for the next lower gear.

If downshifts are attempted at excessive speeds, the inhibitors prevent the selected downshift until the vehicle reaches an acceptable speed.

USING THE ENGINE TO SLOW THE UNIT —

To use the engine as a braking force, shift the range selector to the next lower gear range. If the vehicle exceeds maximum speed for a lower gear, use the brakes to slow the vehicle to an acceptable speed until the transmission may be downshifted safely.

An automatic transmission, compared with a manual-shift transmission, has a longer "coast-down" time. Until becoming accustomed to this characteristic, it may be necessary to manually downshift to reduce speed.

With a little experience in driving with the automatic transmission, you will learn to decelerate a bit sooner, or brake until automatic downshift occurs. This will reduce the need for manual downshifting.

TRANSMISSION OIL TEMPERATURE

Extended operation at low vehicle speeds, with the engine at full throttle, can cause excessively high temperatures in the transmission. These temperatures may tend to overheat the engine cooling system as well as cause possible damage to the transmission. If excessive temperature is indicated by the engine coolant temperature gauge, stop the vehicle and determine the cause. If the cooling system appears to be functioning properly, the transmission is probably overheated. Shift to N and accelerate the engine to 1,200 to 1,500 RPM. This should reduce the oil sump temperature to operating level within a short time. If high temperatures persist, stop the engine and have the overheating condition investigated by service personnel.

CAUTION

Do not operate the engine for more than 30 seconds at full throttle with the transmission in gear and the unit stationary. Prolonged operation of this type will cause the transmission oil temperature to become excessively high and may result in severe overheating damage to transmission components.

If the transmission overheats during normal operation, check transmission oil level.

GENERAL INFORMATION — CATERPILLAR DIESEL ENGINES

Check crankcase oil level before starting and when refueling. Always check oil level with engine stopped. The dipstick has 2 markings, and the distance between them represents 3 quarts (2.8 litre). Use oils that meet any of the following engine service classifications:

- SC and SD (MS - Motor Severe Oils)
- CB (Supplement 1 Oils)
- CC (MIL-L-2104B Specification Oils)
- CD (MIL-L-2104C; Recommended Usage)

Use SAE 10W, 10W/30, 10W/40 or -30 grade oils, depending on the temperature.

CHECK (with engine stopped) fan, water pump and accessory drive belts for cracks, breaks and



frayed edges. Belts for multiple-groove pulleys are sold in matched sets. Replace, as a set, if one belt is defective. While checking belts, look for oil, water or fuel leaks.

CHECK (with engine stopped) for water in the fuel. Drain a cupful of fuel from the bottom of the tank to remove water or sediment. Fill fuel tanks after completing a run. Partially-filled tanks will collect moisture if the coach is allowed to sit for an appreciable length of time. Use Number 2-D diesel fuel (with a minimum cetane number of 40) in Caterpillar 3208 Diesel engines. Keep fuel clean. Inspect Racor filter bowl periodically and observe **WATER-IN-FUEL** indications on the dashboard gauge. Remove and clean filter bowl as necessary.

Use Number 1-D diesel fuel in cold temperatures when white smoke must be minimized on starting up.

CHECK coolant level (with engine cool and off). Fill to the proper level with water and permanent-type anti-freeze. Adding Caterpillar Cooling System Conditioner to permanent-type anti-freeze is recommended if protection is above -20 degrees F (-29 degrees C). Use clean water that is low in scale-forming minerals, not softened water. Leave space for expansion.

AIR SUSPENSION SYSTEM

Your motorhome is equipped with a dump system for the air suspension bags. Dumping these air bags when the vehicle is parked allows the rubber bumpers to come together and eliminate vehicle "springiness". Dump the suspension system by turning **ON** the air switch located just below the 12 volt electrical **MASTER** switch on the transmission shift housing.

NOTE

The accessory air tank must contain at least 65 PSI pressure for the air switch to function. The accessory air tank pressure does not register on the dash air pressure gauges.

When the switch is turned **ON** it applies air pressure to three air pilot-operated valves on the suspension system. Two of these valves are located

on the rear axle; and one is located on the front axle. The pilot air shifts the valves, cutting off the air supply to the air bags and allows the air in the bags to escape. After the suspension system has been dumped, and the ignition is turned on, a warning pilot light is illuminated on the dash to warn the driver that the system is dumped and not to drive the vehicle until the air switch is set to the **OFF** position.

NOTE

If the leveling jacks are to be used while the coach is parked, the jacks must be lowered to level the vehicle **BEFORE** the air bags are dumped. If the air bags are dumped before the jacks are down, the vehicle comes too close to ground level for the jacks to fold outward properly, which could damage the jacks.

RACOR FUEL FILTER

A Racor fuel filter/preheater (shown in figure 6-1) is incorporated in the diesel fuel supply line and processes the fuel supply for maximum purity. The primary stage of the filter separates liquid and solid contamination down to 30 microns by centrifugal action. Because contaminants are heavier than the liquid they fall to the bottom of the bowl and can be drained off by operating a petcock at the bottom. The second stage, coalescing, functions when minute particles of liquid contaminants (lighter than the fluid) remain in suspension and flow up with the fluid into the lower part of the filter/separator shell. Here the minute particles tend to bead on the inner wall of the shell and fall to the bottom of the replaceable cartridge due to their weight. The third and final stage is filtration, where the fluid enters the replaceable cartridge and the remaining solids (down to one micron) are removed. The fuel is then supplied to the engine.

The fuel filter also includes a built-in preheater, which operates from the 12-volt battery supply; and a water sensor, which lights a dashboard indicator when the water level in the filter bowl is high enough to require drainage. Note that the terminals for the electrical hook-ups are imbedded in the filter bowl. The upper terminals are for the heater connection; the lower terminals connect to the water level sensor probe.



SECTION III

LIVING AREA FACILITIES

INTRODUCTION

This section provides information on operation of the appliances and systems which contribute to the comfortable living conditions within your motorhome.

SOFA

To convert your sofa into a large double bed, on coaches that are so equipped, pull platform outward, lower and lock the supporting legs at each corner, and arrange rear cushions to completely cover platform area.

VACUUM CLEANER

The vacuum cleaner system, figure 3-1, is completely self-contained and supplied with a long flexible hose and wand, carpet, upholstery and crevice tools. Install the flexible hose end-fitting into the corresponding intake hole, accessible when the spring-loaded door is swung aside. The disposable paper bag, located in the compartment to the right of the intake, is easily removed and replaced when the compartment door is opened (vacuum cleaner should be off when changing bags). A new bag is installed by sliding the cardboard ring on the bag over the intake tube. Clean or replace foam filter

periodically to keep system operating efficiently. Note that vacuum cleaner will shut off automatically when the bag is full.

Need New Photo




Figure 3-1. Vacuum Cleaner System

DINETTE AREA

The dinette area, figure 3-2, includes a convertible dinette, thermostat, door chime, Lifeguard One and Weather Center, on the rear wall. The table is wall-mounted by two hooks and brackets and supported by a single folding leg. To convert the dinette to a bed, fold leg upward, lift table upward and outward from wall brackets and carefully lower it to rest on overhang edges at front of each dinette seat. Unhook seat back cushions from each dinette seat and place sideways across the gap formed by the table surface, completing the bed conversion.




Figure 3-2. Dinette Area



GALLEY FACILITIES

The galley, figure 3-3, includes a double sink, toaster compartment, food center, refrigerator/freezer, gas range and oven. The dual Power Line monitor, The Thermometer and Clock, and The Monitor panels are located on the left galley wall. A monitoring and switching panel is also located in this area. The refrigerator operates from the LP gas supply or from the 120 volts ac supply. The range and oven also operate from the LP gas supply. Operating procedures for these appliances, given in the following paragraphs, assume that the main LP valve is on. An LP leak detector, located under the refrigerator, continuously monitors the area for LP leakage, shutting off the LP supply and sounding an alarm if leaks are detected.

REFRIGERATOR

Understanding just how the refrigeration process operates will help to explain one of the important reasons why it is necessary to level a parked motorhome. The gas-fired (or electrically-heated) boiler converts the ammonia-water solution to distilled ammonia vapor, which is carried to the finned condenser, where it liquifies. The liquid flows to the evaporator, where it creates a cooling effect by evaporating into a circulating flow of hydrogen gas. If the evaporator coil is not level, the liquid accumulates, forming pockets which do not readily evaporate and impair or block gas circulation, inhibiting the cooling process.

When the coach is parked, it must be leveled to assure comfortable living accommodations. If the refrigerator is properly installed, with the freezer shelf parallel to the ground level, the refrigerator will then also perform well. This can easily be checked by placing a bubble level on the freezer shelf. When the vehicle is moving, the continuous rolling and pitching movement will not affect the refrigerator as long as the movement passes either side of level; but when the coach is parked, the refrigerator must be leveled.

The operation of a thermostatically-controlled fan in the refrigerator compartment is controlled by the REFRIG FAN ON-OFF switch located on the wall panel above the sink. Refer to figure 3-4 for location of refrigerator controls for gas and electric operation.




Figure 3-4. Refrigerator Operating Controls

Need New Photo




Figure 3-3. Galley Facilities



GAS OPERATION — Proceed as follows:

1. To start the refrigerator, set **ELECTRIC/GAS** switch to **GAS** position. This opens the LP valve and disables the electric circuits.

2. Set **THERMOSTAT** position to number 4 setting.

3. Operate **IGNITION** switch to **ON** position and observe that **FLAME INDICATOR** signal is lit when pilot is ignited. Note that the pilot ignition is automatic and will re-light in the event of flame-outs.

4. Adjust the **THERMOSTAT** to the desired setting after the refrigerator has been operating for a while.

NOTE

After LPG tank has been refilled, or after a long shutdown period, gas lines may become filled with air. If this occurs, repeat step 3 until the air has been evacuated from the lines and gas reaches the burner.

ELECTRIC OPERATION — The refrigerator will operate from the 120-volt ac generator or shoreline supply, whichever is available.

To operate, set the **ELECTRIC/GAS** switch to **ELECTRIC** position and adjust **THERMOSTAT** as desired.

USING THE REFRIGERATOR

FOOD STORAGE COMPARTMENT — To maintain required low temperatures for food storage, the food storage compartment is completely closed and unventilated. Consequently, foods having a strong odor, or foods liable to absorb odors, should always be covered. Cover vegetables and salads to retain crispness. The coldest locations within the refrigerator are beneath the cooling evaporator and on the lowest shelves; the least cold locations are on the upper door shelves. Consider this when storing different types of food.

DEFROSTING — Keep the refrigerator operating at maximum efficiency by periodic defrosting and cleaning. Wash ice trays and shelves with warm water. **DO NOT** use strong chemicals or abrasives. During extended periods of storage, empty and

clean refrigerator and leave door slightly ajar to reduce buildup of musty odors.

After a period of operation, frost may gradually accumulate on the freezer plate and cooling fins in the food compartment. If frost accumulations are not removed periodically, refrigerator operation may be impaired. Frost buildup on the freezer plates acts as an insulator and prevents the cooling plates from efficiently removing the heat created by door openings and the storage of foods. It is a good practice to defrost the refrigerator on a regular basis, or as needed, to maintain efficient operation.

To defrost, set **THERMOSTAT** to **OFF**, empty the ice cube trays and refill with hot water, placing them on the cooling plate (for fast defrost). When all frost has melted, empty the drip tray from beneath the finned evaporator and wipe up excess moisture with a clean cloth. Replace the drip tray, all food stuffs and place the refrigerator back into operation. Set **THERMOSTAT** to coldest setting and allow the refrigerator to operate continuously for a few hours at maximum cooling before the **THERMOSTAT** is returned to normal position.

FROZEN FOOD COMPARTMENT — Quick-frozen soft fruits and ice cream should be placed in the coldest part of the compartment, at the bottom of the aluminum liner or, in models with a shelf, on or just below the shelf. Frozen vegetables may be stored in any part of the compartment.

The freezer compartment is not designed for deep or quick freezing of foodstuffs. Meat or fish foods, whether raw or prepared, provided they are pre-cooled in the refrigerator, can be stored in the frozen food storage compartment about three times as long as in the normal temperature compartment. To prevent dehydration, keep food in covered dishes, in plastic bags, or wrapped tightly in aluminum foil.

ICE MAKING — Place ice trays in direct contact with freezer shelf for fastest ice making. Fill trays with water to within $\frac{1}{4}$ inch from the top. To release ice cubes pull handle upwards. Return unused cubes to the tray. Refill tray with water, dry outsides, replace in frozen storage compartment. Clean compartment with dry cloth.



The ice-making process can be accelerated if the thermostat is set to MAX position. It is a good idea to do this for a few hours before an anticipated need for ice, but be sure to turn back the thermostat to its original setting when the ice is formed, or the foodstuffs in the cabinet may also become frozen. (Ice-making time is also reduced if unused cubes are left in ice trays when they are refilled with water.)

REFRIGERATOR SHUTDOWN — For temporary shutdown, set thermostat to zero position and turn off the gas valve. If the cabinet is to be shut down over a period of weeks, it should be emptied and cleaned, and the door left ajar. Ice trays should also be dried and kept outside the cabinet.

CAUTION

If the refrigerator is used only intermittently it should be checked at least once each year.

CLEANING — Clean cabinet interior lining with a lukewarm weak soda solution. Clean evaporator, ice trays and shelves with warm water only. DO NOT use strong chemicals or abrasives to clean these parts or protective surfaces may be damaged. Always keep cabinet clean.

CAUTION

Do not use refrigerator for storage of flammable fluids.

GAS RANGE AND OVEN

The gas supply for the range burners and oven, figure 3-5, is provided from the LPG tank. Make sure that the main valve (on tank) is turned ON before lighting pilots.

CAUTION

It is a good safety practice to leave oven control in TOP AND OVEN PILOTS OFF position (maximum counter-clockwise) when oven is not in use or while unit is in motion.

LIGHTING PILOTS — To light range and oven pilots, set oven control to OVEN OFF position then hold a match near range pilot (lift up burner

top surface to gain access to burner pilot); and then hold a match to oven pilot (located above and to the right of oven main burner).

LIGHTING RANGE BURNER — Once the range pilot is lit, light the desired range burner by pushing in and turning the respective burner control knob counter-clockwise.

NOTE

The oven in your motorhome has an automatic lighting device. There will usually be a short delay (30 to 40 seconds) after the oven is turned on before the burners will light. This is a normal condition and is not a sign of an oven malfunction.

LIGHTING OVEN BURNER — Once the oven pilot light is lit, turn oven control to desired temperature setting and oven burner will light automatically and maintain correct temperature.




Figure 3-5. Gas Range and Oven.



SHUT OFF RANGE AND OVEN BURNERS —
Turn oven control to **TOP AND OVEN PILOTS OFF** position (maximum counter-clockwise).

GALLEY SINK

The heavy-gauge stainless steel sink provides maximum durability with minimum care. After use, rinse sink thoroughly with warm water and wipe dry with a cloth to avoid streaks and spots. For stubborn stains, a mild abrasive cleaner can be used with care. Be sure to wipe in the direction of the steel finish to help maintain the original appearance. Always wash counter surfaces before applying a complete wax coating; regular cleaning prevents wax buildup.

CAUTION

Abrasive cleaners will scratch sink counter top surface.

Boiling water will not harm stainless steel; however, salt, mustard, mayonnaise, ketchup and other similar food acids can cause pitting. If any of these are spilled on the surface, clean off immediately.

FOOD CENTER

A built-in variable-speed motor-driven counter unit, figure 3-6, may be used with mixing and blending attachments for a large variety of food preparation tasks. The food center is designed for




Figure 3-6. Food Center

ac operation and is operable only when the generator is on; or when coach systems are connected to an external shoreline hookup.

BATHROOM

WATER PUMP SWITCH

Two **WATER PUMP ON-OFF** switch/indicators are provided for separate control of water pump operation. One switch is located on the monitor and control panel in the galley area; the second is located in the bathroom. The pump may be operated **ON** or **OFF** from either location. The indicator is lit whenever power is being supplied to the pump. Setting either switch **ON** pressurizes the water system, with the pump operating on demand to maintain system pressure constant. Continuous or erratic pump operation can indicate an empty water tank, system leakage, or air lock in hot or cold water lines. (Air locks are normally caused by movement of water in the tank during pump operation.) Since tank water level and water pressure can vary with road movement, leave water pump switch OFF while the coach is moving. The water pump and air accumulators are located under the bath vanity, in side-bath units; or under the left bed, in rear-bath units.

TUB/SHOWER UNIT

The combination tub/shower unit, figure 3-7, includes a pressure-balancing single mixing valve, tub water outlet with shower head diverter button, shower head and drain lever.




Figure 3-7. Stall Shower



TOILET

The toilet (marine type), figure 3-8, operates from the fresh water supply, flushing wastes directly into the sewage holding tank. Two foot pedals are located at the bottom of the bowl. The smaller right-hand pedal (bowl fill) controls the amount of water delivered into the bowl; while the left-hand pedal (bowl drain) opens the sliding valve to the tank. To prepare the toilet for use, depress the bowl fill pedal until the water level in the bowl is as high as needed. After use, depress bowl drain pedal until water swirls, draining wastes into tank, then release pedal. A water-saver feature, consisting of a manually-operated spray hose, is located at the side of the bowl.




Figure 3-8. Toilet

ROOF VENTS AND EXHAUST FANS

BATHROOM — To operate the combination vent/exhaust fan in the bathroom ceiling, figure 3-9, turn handle to open roof vent, then press switch to turn on fan motor.




Figure 3-9. Bathroom Vent/Exhaust Fan

HALLWAY — Lighted exhaust fans in the hallway, figure 3-10, are controlled by separate switch panels above the driver and above the oven. A typical panel, shown in figure 3-11, includes switches for LID, LIGHT and FAN control.




Figure 3-10. Hallway Lighted Vent/Exhaust Fan

The LID UP-DOWN switch raises or lowers (closes) the outside vent; the FAN ON-OFF switch controls fan operation; and the LIGHT ON-OFF switch controls the operation of the built-in ceiling light.



Figure 3-11. Exhaust Fan Control Panel

HEATING SYSTEMS

Three gas/hot air furnaces are used in the coach, each with a separate zone thermostat, figure 3-12.




Figure 3-12. Heater Thermostat



One furnace is located in the living room; another is in the galley area; and the third in the bedroom. The living room furnace is also used to supply hot air to the bathroom via a separate duct booster fan controlled by a thermostat in the bathroom. In addition, separate heating is also provided by circulating hot-water heaters which function through engine coolant heat exchange when the engine is operating and the **WINTER-SUMMER HEAT SELECTOR** dash switch is in **WINTER** position.

HOT AIR FURNACE OPERATION

To operate the furnace, proceed as follows:

1. Turn manual valve to **OFF** position and wait five minutes. Set thermostat to lowest setting.
2. Open manual valve. Correct operating characteristics depend on this valve being fully opened; never operate with valve partially open!
3. Set thermostat at desired position. Main burner will light within 15 seconds and furnace will then operate automatically.

When coach temperature drops below the thermostat setting, the internal relay contacts close to operate the main burner. The air flow created by the blower closes an air-actuated switch that, in turn, energizes the main burner gas line solenoid valve which then lights from the electronic ignition.

CAUTION

Do not store items in or near the burner compartment.

When the coach temperature exceeds the thermostat setting, the relay contacts open. This shuts off the burner gas supply but the blower continues to operate until residual heat within the furnace is dissipated, when a thermostatically-controlled relay turns off the blower. Air for the sealed combustion chamber is pulled in from outside the coach, routed around the heat exchanger, then exhausted through the same vent. Recirculated fan-forced air blowing across the heat exchanger is used to heat the coach interior.

HOT-WATER HEATING SYSTEMS

Two sources of hot-water heating are provided which depend on heat generated from engine

operation. A hot-water heater, at the right front corner of the coach, is controlled by the **FRONT HEAT** switch on the dashboard; and three chassis heaters, (50,000 BTU) under the front dinette seat, front sofa and curb-side bed, are controlled by the **CHASSIS HEAT** thermostat, located on the curb-side wall, above the half-closet, nearest the entry door.

The engine coolant is normally routed through the engine cooling system and the hot water heat exchanger, which also can be heated electrically to provide the hot water supply for the coach. However, by operating the **WINTER-SUMMER HEAT SELECTOR** switch, the engine coolant can also be diverted through the previously-mentioned area heaters, via solenoid valves. Note that the coolant level in the engine radiator should be checked after these valves are opened. If the coolant in the heater lines has evaporated during the summer, the radiator will lack sufficient coolant and may overheat.

Chassis heater blower motors (dinette seat, front sofa and curb-side bed) are controlled by **ON-OFF HEAT** switches adjacent to the heater louvers. The front heater is equipped with three squirrel-cage dual-speed blowers, operated from separate dash controls. One blower provides defroster air; one provides air to the driver's side; the third provides air to the co-pilot's side. Use **DEFROST HI-OFF-LOW** switch for setting the defroster blower speed; use the left and right **HI-OFF-LOW HEAT** switches to control air flow to the driver's and co-pilot's sides, respectively. To supply heat, the dash **FRONT HEAT** switch must be **ON**.

NOTE

If additional defrosting action is needed, turn auto air conditioning temperature control to **OFF** and turn auto air conditioning fans to high-speed. This will circulate additional warm air about the windshield area.

Engine heat is picked up by the engine coolant which is pumped through the heaters inside the body and back into the engine. A typical heater (inside the body) consists of a heat exchanger, or core, and fans which move the air across the core. Air moving across the core picks up heat from the



engine coolant and transfers it into the living room.

HEATING SYSTEM OPERATION

Satisfactory performance of this type of heating system depends on the following basic factors:

1. **Engine Coolant Temperature** — This can be altered by thermostat rating, which should never be higher than that recommended by the engine manufacturer.

2. **Coolant Flow** — This varies with the engine speed. Setting the **AUX. PUMP** dash switch to **ON** turns on the auxiliary pump in the coolant lines to increase the coolant flow through the system. (This feature may also be used to reduce engine overheating.)

3. **Proper Fan Operation** — All fan motors are two-speed and can easily be checked for proper operation by listening to the motor speed change as the switch is operated.

Under extremely cold weather conditions, turning on the heater fans will lower the engine temperature noticeably as heat from the engine is being transferred into the body. However, as the air temperature within the body rises, the engine temperature will also increase. More heat will be generated by the engine which it is also used to move the coach. Be sure that the engine radiator is full and that all coolant flow valves are open. Warmup engine to operating temperature and set heating system switches as follows:

- a. **WINTER-SUMMER HEAT SELECTOR** to **WINTER** position;
- b. **AUX. PUMP** to **ON**;
- c. **FRONT HEAT** switch to **ON**;
- d. Left and right **HEAT** blower switches to **HI** or **LOW**;
- e. **Thermostat** to desired temperature.

The engine is designed to operate on a continuous duty cycle and may be used to provide a constant heat supply. This, however, should be done only if no other source of heat is available.

DUCT BOOSTER

The duct booster system, installed in the hot air duct between the living room furnace and bathroom, is controlled by a separate thermostat in the bathroom. Note that the living room furnace must

be on for the duct booster to operate.

HOT WATER SUPPLY HEATER

The hot water supply heater core is also a part of the engine cooling system loop. When the engine is operating, the heat exchanger ensures a constant supply of hot water. In addition, the water supply can be electrically heated by electric coils in the heater unit. The 120 volt, ac-operated, heater is controlled by an **ON-OFF** switch/indicator on the bottom of the roadside bed; or by the circuit breaker in the rear curbside closet. This heater can operate only when the shoreline is connected, or when the generator is on.

CAUTION

Be sure that the electric heater core is turned **OFF** if there is insufficient water in the tank.

ROOF-AIR CONDITIONING

Conditioned air is maintained throughout the coach by ceiling-mounted air conditioner units. Each unit provides dual low- and high-speed fan or cooling operation for high velocity air movement through individually-controlled outlets. Air conditioning cool-down occurs faster if all windows, doors and vents are closed.

Maximum air conditioning efficiency also depends on the outside temperature and operating voltage level. Because the air conditioners represent the largest load for the electrical system, never start more than one unit simultaneously. (Air conditioner starting current can be two to three times the normal operating current.)

CAUTION

To ensure the full efficiency of the air conditioning units, periodic removal and washing of the air conditioner filters is recommended. This is easily done by removing the filters from the retaining screens, washing in a warm soapy solution, rinsing and drying with paper toweling, then replacing filters and screens.

If an external ac hookup is being used, and the system is not operating efficiently, this may be



caused by lower shoreline supply voltage. (Check power line voltage monitors.) Turning the generator on and switching over to generator operation will supply enough power to ensure correct air conditioner operation.

Before starting the generator, check that each air conditioner is off to prevent the generator from starting under load. Allow generator to warm up to the proper voltage and frequency before turning on the air conditioner(s).

Two remote ON/OFF switches for REAR and FRT. A.C. operation are located on the wall next to the driver.

SYSTEMS MONITORING AND CONTROL PANELS

Systems monitoring and control panels are located in the galley walls, above and to the side of the sink, figure 3-3. Additional monitoring equipment is provided on the dinette wall, figure 3-2, and beneath the refrigerator.

THE THERMOMETER AND THE CLOCK, AND THE MONITOR PANELS

Both of these units, figure 3-13, are solid-state with large digital LED readouts. Operating procedures for each unit follows:

THE THERMOMETER AND THE CLOCK

The Thermometer and The Clock panel provides a digital display of inside and outside temperature; digital time display; and an alarm function. (The temperature monitoring section of this unit is the same as The Thermometer, located on the bulk-head panel over the driver.) Operate the panel controls as follows:

1. Monitor inside or outside temperature (F) by pressing the TEMP IN or TEMP OUT buttons. Note that there is an internal adjustment, at the rear of the unit, which may be used to calibrate the temperature readings.

2. Set alarm as follows: press ALARM DISPLAY button then operate the FAST and SLOW buttons to set the alarm time. Note that this is a 24-hour alarm, so observe the lit PM indicator to the left of the display. After setting the alarm,




Figure 3-13. The Thermometer and the Clock, and The Monitor

press ALARM DISPLAY button again to return to the normal time mode. To activate the alarm feature, press the ALARM ON/OFF button in to ON; to shut off the alarm, press ALARM ON/OFF button out to OFF.

THE MONITOR

The Monitor panel provides an illuminated readout of the content level of the pure water, gray and waste water tanks, and the LPG tank level. Operate The Monitor as follows:

1. Monitor PURE, GRAY or WASTE TANK levels by pressing in the respective button. The content level remaining in the tank is indicated by five sets of lit readings. The E lamp, at the left of the display, is lit all the time; if the next indicator is lit, the level is approximately $\frac{1}{4}$ tank; if the center indicator is lit, tank level is between $\frac{1}{2}$ and $\frac{3}{4}$ full; if the $\frac{3}{4}$ indicator is lit, tank level is between $\frac{3}{4}$ and full; and if the F indicator is lit, tank level is full. If only the E indicator is lit, the tank level is between empty and $\frac{1}{4}$.

2. LPG tank level can be monitored in the same manner as the water tanks level by pressing in the PROPANE TANK button. Note that this display is pre-calibrated. However, if it is necessary to re-calibrate the display, this can be done when the tank is full by setting a rear-panel adjustment.



SWITCHING AND MONITOR PANEL

The switching and monitor panel, figure 3-14, monitors the battery voltage level, activating an audible alarm if a low-voltage condition is present (BATTERY LOW VOLTAGE). It also monitors the refrigerator temperature when the REFRIG. ALERT switch is ON. Normally, the ON indicator is lit; if the refrigerator temperature increases to an unsafe level, the WARM indicator lights to indicate an alarm condition. The thermostatic refrigerator fan is controlled by the REFRIG. FAN ON-OFF switch. The indicator above the switch is lit when power is being supplied to the fan. However, the fan will not operate until vent column temperature reaches approximately 100 degrees F.

Water pump operation may also be controlled from this panel with the WATER PUMP ON-OFF switch; the ON indicator will be lit when power is being supplied to the pump. GENERATOR START-STOP operation is controlled by depressing the switch upward to start the generator, operation being indicated by the indicator in the center of the switch being lit; press switch downward to STOP operation and hold until light is off.




Figure 3-14. Switching and Monitor Panel

LP GAS LEAKAGE DETECTOR

The Control 4 LP gas leakage detector, figure 3-15, is located beneath the refrigerator. In the event of an LP leak, the unit sounds an alarm and closes down the main LPG supply by activating a solenoid valve located in the gas line just after the low pressure regulator. If it is necessary to reset the solenoid (red band is visible inside clear plastic valve housing), open the refrigerator vent air intake door, remove plastic housing by gripping locking levers and lifting upward, push valve plunger down

until it remains down, then replace the cover. For continuous operation, set OFF-ON switch ON; to test alarm operation, press PUSH AND HOLD TO TEST switch.




Figure 3-15. LP Gas Leakage Detector

POWER LINE MONITOR

A dual-channel power line monitor, figure 3-16, on the side galley wall, continuously monitors ac line voltage and shoreline hookup(s) polarity. Each channel includes an expanded-scale ac voltmeter, reading from 90 to 130 volt ac; a POLARITY NORMAL indicator, lit whenever the shoreline hookup is properly connected and grounded and line polarity is compatible with coach wiring; and a POLARITY REVERSED indicator which lights when hookup is reversed. Note that shaded area on the meter face indicates normal voltage range.




Figure 3-16. Power Line Monitor

LIFEGUARD ONE

Lifeguard One, figure 3-17, is a gas leak detector designed to sense dangerous concentrations of LP gas or carbon monoxide within the coach. Propane has a Lower Explosive Level (LEL) of 21,000 PPM and butane has an LEL of 18,000 PPM. Threshold Level Value (TLV) is the maximum permitted level of toxic gas in a work area, as published by safety and health authorities (OSHA). The allowable TLV for propane is 1,000 PPM; the TLV for carbon monoxide is only 50 PPM!



Figure 3-17. Lifeguard One Gas Level Alarm

Lifeguard One has been factory-calibrated to an alarm point of 2,000 PPM propane for standard conditions (temperature, 20 degrees C \pm 2 degrees; relative humidity 65% \pm 5%). This provides for a minimum of false alarms consistent with providing reasonable safety.

Carbon monoxide, a product of combustion, is also sensed by Lifeguard One and, for this reason, a sensor is also placed at the load center to provide an alert in the event of a short circuit causing an electrical fire. The sensors have a long life and high reliability. In normal use, recalibration or replacement will not be necessary for 5 years or longer.

To turn on the unit, set ON-OFF switch to ON and observe that POWER ON indicator is lit. Propane level sensors are located in key areas through the coach, in the vicinity of the gas appliances being monitored. Excessive propane PPM conditions are indicated by the sounding of the audible alarm and lighting of an indicator associated with the danger area. Lifeguard One, if left turned off for a period of time, has a warmup period of about one minute. During this time, the alarm may sound. This is a normal response and should stop once the unit has warmed up.

ELECTRONIC DOOR CHIME

The door chime is located on the dinette wall beneath Lifeguard One. It is a highly sophisticated musical tone generator similar to The Horn.

The unit contains a circuit board micro-computer "chip" which is programmed with both music for the tunes, and the play-out program.

When the entry door button is pressed, the micro-computer is activated and tests the selection switches to find out which tune is required. When this is done, it proceeds to retrieve the tune from "memory" and then generates the audio/tune output. Since this is all done electronically (in a fraction of a second) the unit cannot go out of tune. The audio signal is amplified and processed to sound similar to a chime, and then connected to the speaker. When the end of a tune is reached, as long as the entry button is not being pressed, the micro-computer shuts down to save power use.

The operating controls are concealed behind the lower access panel, as shown in figure 3-18. The panel may be removed at any time to change the tune played, or the speed, volume, or tone.




Figure 3-18. Electronic Door Chime Controls

TUNE SELECTION — The desired tune is selected by setting the two operating controls to the positions corresponding to the following selections:

Tune	Set
Greensleeves	A1
God Save the Queen	B1



Tune	(continued)	Set
Rule Britannia		C1
Land of Hope and Glory		D1
Oh Come All Ye Faithful		E1
Oranges and Lemons		F1
Westminster Chimes		G1
Sailor's Hornpipe		H1
Cook House Door		A2
Star Spangled Banner		B2
Beethoven's Ode to Joy(9th)		C2
William Tell Overture		D2
Soldier's Chorus (Faust)		E2
Twinkle, Twinkle Little Star		F2
Great Gate of Kiev		G2
Maryland/Tannenbaum		H2
Beethoven's Fate Knocking		A3
The Marseillaise		B3
Glorious Things/Deutschland		C3
Bach's Tocata in D Minor		D3
Mozart Sonata		E3
Colonel Bogie (Bridge Over River Kwai)		F3
Mendelssohn's Wedding March		G3
The Lorelei		H3

On all selections, except A1 and A2, the second pushbutton will only play tune A3. If A1 or A2 is selected, then it will play B3.

The knob designated S sets playing speed for the selected tune; the T knob sets the tone and may be adjusted for a pizzicato sound (plucked strings); or, set for normal audio tones. The knob marked V sets the volume. When set to the fully counter-clockwise position, no sound will be heard, but the unit will still be operational.

After setting all controls, replace access panel.

DIGITAL INSIDE/OUTSIDE THERMOMETER

The digital thermometer on the center panel above the driver, figure 3-19, is a "slave unit", with digital readout based on the output received from The Thermometer and The Clock panel. A rear-panel adjustment assures that both readings correspond. Depending on whether INSIDE TEMP. or OUTSIDE TEMP. is selected, either one or both readings can be displayed separately or alternately. The temperature reading displayed is indicated by the associated light being illuminated.




Figure 3-19. Digital Inside/Outside Thermometer

PORTABLE FAN

The portable oscillating fan is shown in figure 3-20. The 12-volt hookup cable is coiled within the base section when the fan is not in use.




Figure 3-20. Portable Oscillating Fan

SECURITY TIMER

The "Watchdog" security timer, figure 3-21, is a randomly-switched electrical timer which can be used to control the on-off operation of an appliance, light, etc., to give your coach that "lived-in" look when it is unoccupied. The three-position switch may be set to OFF, to shut off the controlled appliance; to ON, for manual control; or to SECURITY, for random operation.




Figure 3-21. Security Timer



BURGLAR ALARM/ANTI-THEFT FEATURES

The security of your motorhome and contents are assured by an intruder alarm system which protects windows and entry door. Each window is protected by a magnetic proximity switch which triggers an alarm if the window is opened. The entry door uses a door jamb switch which operates when the door is opened. When the system is "secured" it may be activated from outside the coach by a key-switch adjacent to the entry door. From inside the coach, a master burglar alarm switch may be operated at the front instrument panel.

In addition to the alarm system, an anti-theft switch for the ignition circuits (A/T switch on dashboard) can be operated so that the unit cannot be started.

FIRE EXTINGUISHER

A portable, multi-purpose dry chemical fire extinguisher is located beneath the forward part of the dinette seat, in side-bath units; and in back of the driver's seat, in rear-bath unit. A second fire extinguisher is located in an outside coach compartment. To use, release the clamp and remove the fire extinguisher from the bracket, pull safety pin from handle, squeeze handle and apply chemical under flame.

CENTRAL AIR-CONDITIONING SYSTEM

The controls for the central air-conditioning

system (used in 35-foot coaches) are shown in figure 3-22. Operation is as follows:

OFF-START-RUN Switch — Applies power to system for fan operation (START position); and next activates compressor (RUN position).

NOTE

Do not turn the compressor off and on without allowing a few-minutes delay between switching. This will prevent overloading the compressor motor.

FAN Switch — Variable-speed fan motor control. Set as desired for normal operation; set between mid-range and HIGH for higher cooling capacity.

THERMOSTAT Control — Clockwise rotation provides greater cooling; set as desired.




Figure 3-22. Air Conditioner Controls

6

6

6



SECTION IV

ELECTRICAL SYSTEMS

INTRODUCTION

There are actually two interrelated electrical systems used in your motorhome: the 12-volt dc supply system; and the 120-volt ac supply system. The 12-volt dc supply system is divided into several branches, or zones, each functioning from the common 12-volt battery source. One branch provides the 12 volts required for the automotive starting, ignition and charging systems; remaining branches supply those motorhome circuits and appliances which require 12 volts dc for operation.

The 120-volt ac system includes those motorhome appliances which require 120 volts for their operation, supplied from either the internal generator plant; or from the external 120-volt ac (or a split 240-volt ac) supply, via the shoreline hookup.

12-VOLT DC SUPPLY SYSTEM

The 12-volt dc supply is furnished to the standard automotive starting, ignition and charging system; and to the motorhome distribution circuits.

A degree of interface exists between these systems in that the motorhome distribution circuits also provide some circuit breaker protection for certain automotive lighting functions. Each of these circuits relies on the 12 volts provided from the four series-parallel connected 6-volt batteries located in the compartment on the left side of the coach. An overall wiring diagram of the 12-volt supply and distribution system is included in Section X.

MOTORHOME 12-VOLT CIRCUITS

The 12 volts supplied to all motorhome appliances, outlets and accessories is routed from the batteries through a main 12-volt bus and routed to the individual branches, or zones, that are serviced from this supply. Circuit breakers are located behind the access panel at the front left side of the coach, and at each of the branches. Refer to figure 4-1 for location of circuit breakers within the outer access panel; figure 4-2 shows the fuses in the battery compartment. Refer to figure 10-1 for location and wiring data for the 12-volt distribution system and individual zone service.

** Photo Upside
Down **




Figure 4-1. Circuit Breaker Panels (12 Volt DC)



BATTERY HEATERS

Thermostatically-operated 120 volt ac battery heater pads, figure 4-2, protect batteries from cold-weather deterioration. Heaters operate only from the ac supply line, requiring that the coach remain connected to shoreline power during cold weather.




Figure 4-2. Battery Compartment

BATTERY CHARGER

The 12-volt battery supply is maintained in a fully-charged condition by either the engine alternator (when engine operates); or by two 50-ampere battery chargers, located in the left side mid-mount storage compartment, figure 4-3. These automatic electronic battery chargers operate whenever a source of 120 volts ac is supplied to the coach circuits (either shoreline or generator operation). When the battery chargers are operating, the batteries are effectively placed off-load and charged, while the battery chargers also supply 12 volts dc to the motorhome circuits. This makes it possible to use all 12-volt systems while still charging the storage batteries. The two chargers ensure rapid recharging of the main batteries and furnish a

total of 100 amperes of service to the coach.

NOTE

When using battery power only for operation of heavy-load circuits, such as lighting, motors and furnace, check battery condition periodically to prevent batteries discharging. If battery condition is marginal, operate generator plant to keep batteries charged.

DC SUPPLY MONITORS

There are two locations within the coach where the condition of the 12-volt dc supply can be monitored. The compartment just inside and to the left of the step-well contains a center-reading $-100-0+100$ ammeter which indicates the battery charging (+) current. The driver's dashboard instrumentation includes a voltmeter and an ammeter for monitoring battery condition during on-road and ac operation. Because battery condition is so vital to the proper operation of 12-volt motorhome appliances, use these meter readings to be constantly aware of the battery status to avert possible inconvenience or battery/component damage.

AC SUPPLY SYSTEM

Motorhome ac-operated appliances are supplied from either an external shoreline hookup; or from the internal generator plant. Selection of which power source is to be used is determined by a four-position ac power selector switch located in




Figure 4-3. Location of Battery Chargers



a compartment just inside and to the left of the stepwell, as shown in figure 4-4. Set this switch to either GEN, SHORE 50A, SHORE 30A or OFF, depending on the power source availability. Leave this switch in OFF position to completely disconnect the motorhome 120-volt ac circuits.




Figure 4-4. Ac Power Selector Switch

POWER LINE MONITOR

A dual power line monitor is located on the galley wall to monitor the ac shoreline supply (or generator supply) voltage. If the shoreline is "split", one monitor is connected to each side. Each monitor has polarity and ground detector circuits to indicate possible electrical hazards due to incorrect hookups.

AC CIRCUIT BREAKER PANELS

Two main ac circuit breaker panels are located within the rear closet. Refer to figures 4-5 and 4-6 for identification and location of load center and over-current circuit breakers, respectively.

GENERATOR OPERATION

The generator plant has its own 12-volt starting battery so that it can operate independently of the coach 12-volt batteries and can be started even if the motorhome batteries are discharged.

The generator can be started and stopped from either of two locations within the coach: at the driver's instrument panel; or at the galley wall monitor switch panel. In addition, the generator can also be started at the remote panel located in the generator compartment.




Figure 4-5. Load Center Circuit Breakers



Figure 4-6. Over-Current Circuit Breakers



To start the generator, push the **GENERATOR** switch forward to the **ON** position and hold until the generator starts, as indicated by the generator **ON** indicator lighting. **DO NOT HOLD SWITCH ON FOR LONGER THAN 15 SECONDS AT A TIME!** If the generator does not start the first time, wait a minute and try again. Release the switch when the **ON** lamp glows. The generator may be stopped at any time, from either of the two locations in the coach, by holding the switch down to the **STOP** position until the generator stops (light in switch extinguishes). However, if the generator is started with the **REMOTE START** switch directly at the generator compartment, figure 4-7, it can only be stopped at that location, with the **STOP** switch.

It is not advisable to start the generator under a heavy load, especially with the high current demands made by the air conditioners. This may cause hard starting and possible damage to the generator electrical system. It is a good practice to remember to set the **MAIN SELECTOR** switch to **OFF** (figure 4-4) before turning on the generator so there will be no electrical load on the line. Also, remember to set the selector switch to **GEN** position when the generator is being used; and to reset the switch to either **OFF** or to **SHORE** position, as appropriate.

The generator is housed within an air-operated extendable tray, shown in the opened position in figure 4-7. The tray is normally locked into place by a hand-latch located underside. To open, unlock the latch and extend the tray outward by operating the **OUT-IN GEN. TRAY** switch in the stepwell compartment. Note that the tray is air-operated via an electrical solenoid and that the air pressure must be up for tray operation.

CAUTION

The generator tray is **HEAVY** and moves in and out with a great deal of force. **KEEP HANDS OFF TRAY WHEN OPERATING SWITCH!**

AC SHORELINE OPERATION (COMMERCIAL POWER)

Set the power selector switch, figure 4-4, to the




Figure 4-7. Generator Compartment Extended

proper **SHORE** position **BEFORE** the motorhome electrical system and external supply are joined. For purposes of safety, observe all precautions when making these connections. First, connect the shoreline to the coach; then connect it to the power source. Poor grounding or incorrectly-wired receptacles can cause personal harm as well as equipment damage or fire hazards. Check power line monitors on galley side wall to verify correct supply voltage, polarity and grounding of hookup.

NOTE

Your motorhome has been wired in accordance with the National Electrical Code. All 120-volt ac wiring is two-wire service with ground; all 220-volt wiring is three-wire service with ground. If the motorhome is connected to an external hookup which has only a two-wire circuit, ground the third wire on the adapter to the external supply metal junction box or conduit. Utilize the polarity detector indicators on the power line monitors to be sure that lines are properly connected and grounded.

For commercial power (120 v ac), the coach is equipped with a 25-foot 10-3 shore line; for 220 volts ac, a heavier 6-3 cable is used.



Before completing the shoreline hookup, shut off the ac appliances and set the power selector switch to the appropriate SHORE position. Connect the shoreline, stored in the compartment shown in figure 4-8, between the external power source and the coach shoreline receptacle. (The coach receptacles are located in the same compartment as the water hookups, in the rear next to the left side tail light, figure 5-1.)

In many instances, the shoreline hookups will not be rated to operate all electrical appliances in your coach. Check with facility personnel to determine the maximum current capability of the hookup. Usually, only one air conditioner or electrical hot water heater may be operated at a time. The current ratings for appliances designated for standard or optional (identified by *) usage in your coach are listed in table 4-1.

Table 4-1. Electrical Ratings for Motorhome Appliances

Item	Current Rating (Amperes)
Air Conditioners	
13,500 BTU	17.5
Hot Water Heater	10.0

Television Receivers	
Black-and-white	.5
Color	1.0
Battery Chargers (depends on battery condition/load)	0 to 12.0
Engine Block Heater	10.0
Electric Heaters	
"Cheater Heater"	12.5
Battery Heaters	-----
Heat Tapes	-----
*Microwave Oven	15.0
Food Center	4.0
Vacuum Cleaner System	9.0
Refrigerator	2.5
*Ice Maker	2.5
*Washing Machine/Dryer	25.0
*Instant Hot Water	-----

SAFELINE ALARM

Your coach is equipped with a shoreline disconnect alarm, which is located on the bulkhead panel over the driver. This device will provide an audible or visual alarm whenever the shoreline is left connected to the coach at the same time that the ignition switch is turned ON. This assures that the coach is not inadvertently driven away while still connected to the shoreline hookup.




Figure 4-8. Shoreline Hookups (Storage Compartment)



SECTION V

WATER DISTRIBUTION SYSTEMS

INTRODUCTION

Your motorhome is equipped with a completely self-contained water system which includes piping, heating and drainage facilities similar to those used in home installations. The water supply and distribution system includes three networks: (1) a potable water supply system, which includes the water tank, pump, air accumulators, pressure switch, water purifier and input supply lines; (2) water heater and interior hot water heating systems; and (3) waste, winterizing, quick drain and sewage drainage systems. Refer to Section X for potable water system and plumbing drainage system piping diagrams.

WATER SUPPLY AND DISTRIBUTION SYSTEM

As shown in figure 5-1, the dual-purpose tank water fill/COMMERCIAL WATER inlet connection is located in the left rear utility compartment. The TANK FILL ON-OFF switch controls a solenoid-actuated water valve to divert the commercial water input to the pure water storage tank to fill the tank. Located beneath the rear bed, the tank is a non-pressurized type so that system water pressure is developed by pumping action directly into the supply lines, rather than by tank pressurization. A bacteriostatic water purifier system purifies all the drinking-supply water used in the coach.

COMMERCIAL WATER HOOKUP

When facilities are available, the COMMERCIAL




Figure 5-1. Location of Commercial Water Hookup

WATER hookup can be used to supply all coach water system requirements. In this manner, the coach water tank and pump system is bypassed and the supply line water pressure is developed by the external connection. Water input pressure is regulated by a 45-pound in-line reducer valve. A supply line check valve automatically bypasses the pump and tank.

NOTE

The TANK FILL switch is ON only when the water tank is being filled. This switch must be in OFF position at all other times to prevent the water pump from operating continuously.

WATER SUPPLY FILLING AND SANITIZING

FILLING THE TANK — To fill the water supply tank, connect the water hose to the commercial water inlet, set TANK FILL switch to ON, then turn on the water supply. When the tank is full, as indicated by water overflow beneath the coach, set the TANK FILL switch to OFF position, shut off the water supply and disconnect the hose. At this time, check that The Monitor panel readout on the galley wall indicates a full water tank. To check, press the PURE tank switch and observe that the E and F indicator segments are lit.

SANITIZING THE WATER SYSTEM — Since the only source of potable water in the motorhome is contained in the supply tank, it is extremely important that this water supply be as free as possible of impurities and contamination. Accordingly, water tank sanitizing procedures should be followed before the tank is filled for the first time; after long idle periods, where water may become stagnant; or after any suspected contamination of the water supply. Whenever possible, use a commercially-approved tank sanitizer and follow the procedures on the product package. If it is not possible to use a commercial product, prepare your own mixture and sanitize the tank in accordance with the following procedures:

1. Empty the Water Tank — To drain the entire



water system open the drain valve under the sink, figure 5-2 and open all faucets.

If a complete system drainage is required, such as that normally performed before placing the motorhome in cold-weather storage, refer to the procedures for "Draining the Fresh Water System", at the end of this section. Be sure to close the valves after draining is completed, and turn off the water pump and faucets.

2. Prepare the Sanitizing Solution — Prepare a concentrated sodium hypochlorite solution from a mixture of water and household bleach (Clorox, for example, 5½ to 6% solution). The proportions are ¼ cup bleach to one gallon of water so that a 100-gallon water tank would require 25 cups of bleach.

3. Add Sanitizing Solution to Water Tank — Using the prepared sanitizing solution, pour into the tank one gallon of solution for each 15 gallons of tank capacity. Since the water tank will hold about 96 gallons, 6-½ gallons of the solution will be required for a thorough sanitizing of the tank.

4. Fill Tank to Capacity — Connect the hose to the commercial water inlet, set the TANK FILL switch to ON and fill the water tank completely. Shut off and remove hose, set TANK FILL switch to OFF and allow the system to stand for several hours.

5. Drain System — Open several faucets, open the drain valve beneath the sink and allow the sys-

tem to drain completely.

6. Refill System — Close the drain valve and faucets, connect the water hose to the commercial water inlet, set TANK FILL switch to ON and fill tank completely. When the tank is full, set TANK FILL switch to OFF, shut off water supply and disconnect hose, replace fill cap and turn on water pump. When water flows from opened faucets, close them and open other faucets until water flows. This flushes the system, removing trapped air from the piping and ensures that the fresh water supply is ready for use.

NOTE

Residual tastes or odors can be removed by again draining and rinsing the system with a vinegar solution mixed to the ratio of one quart of vinegar to five gallons of water.

Rediline Generator Option 5949





Figure 5-3. Front Right Side Compartment



Bath Base Cabinet
Figure 5-2. Under Sink Plumbing



POTABLE WATER DISTRIBUTION SYSTEM

The major components of the potable water distribution system, shown in Section X, are the water tank, water pump, air accumulators, hot water heater, piping and fixtures. In addition, a bacteriostatic water purifier is connected in the cold water supply line to the galley sink, lavatory, constant hot tap (option) and ice-maker (option). Note that heating coils in the hot water heater are also a part of the heat exchanger loop for the engine coolant system, shown in the heater piping diagram in Section X.

For side-bath models, the hot and cold water piping is routed first to the galley sink, then to the shower, bathroom sink and the toilet. (For rear-bath models, the hot and cold water piping is routed first to the toilet water supply shut-off valve located beneath the sink.) Note that the drain valves are also located beneath the sink, as shown in figure 5-2. These valves are used only when it is necessary to drain out the lines prior to winterizing the unit; or for draining the system completely for sanitizing. Keep valves closed at all other times.

The water pump is equipped with a factory-calibrated pressure control switch which is preset to turn the pump on when the system pressure falls below 25 psi; and turn the pump off when the pressure reaches 35 psi. If the pump has been out of service for a period of time, it is advisable to open a faucet before turning the pump on. This will allow for easier starting by reducing the pump starting load. When water flows steadily from the opened faucet, close faucet and observe that pump shuts off when system becomes pressurized. (It may also be necessary to bleed the air from the other faucets as well.) When the potable water supply tank level is low, or empty, shut the pump off to prevent possible damage to the pump motor. In addition to integral motor overload protection, the pump mechanism is also protected from jamming by the presence of an inline filter (pump guard) between the pump and the supply tank.

WATER PURIFIER

The bacteriostatic water purifier filters and




Figure 5-4. Water Purifier

purifies the potable water supply to eliminate tastes, odors and coloration produced by chlorine, rust, insecticides, detergents, sediment and other foreign objects. All water-borne disease-carrying bacteria are neutralized and removed from the water supply through bacteriostatic action. This is accomplished by a hygienic filter bed which consists of silver ions absorbed on sponge silver metal which is deposited in a finely divided form on activated carbon of high surface area.

The water purifier, located beneath the galley sink, figure 5-4, is a self-contained unit, requiring no routine or periodic maintenance.

Each time you use the filtered water supply for drinking or cooking purposes, it is recommended that you run the tap for a few seconds to clean out the line prior to using the water. This is particularly important if the water tap is not used on a daily basis. If the water supply has not been in use for extended periods, allow the water to flow for five to ten minutes before use.

FILTER CARTRIDGE REPLACEMENT — Refer to the manufacturer's service manual for filter cartridge maintenance and replacement procedures.



HOT WATER HEATER

The hot-water heater is a fibreglas-jacketed coil-type heat exchanger which ensures a continuous supply of hot water through heat exchanger action with the automotive coolant system and auxiliary pump. When the engine is off, the hot water heater can still supply hot water through the use of an electrical heater. The electrical heater is on all the time that the ac supply is available. The electric heater circuit breaker, located in the circuit breaker panel in the rear closet, should be switched OFF when heated water is not needed; or, use the ON-OFF pilot light/switch located in the side of the rear left bed base. For electrical operation, a source of 120 volts ac must be available, either from the shore line, or from the internal generator plant.

PLUMBING AND DRAINAGE SYSTEM

A diagram of the plumbing and drainage system is provided in Section X. Separate holding tanks for gray water (32 gallons) and waste (52 gallons) are located beneath the coach mid-section. In side-bath units, the gray water holding tank is closer to the front of the coach and is the receiver for the gray water from the kitchen sink and the shower. The waste holding tank, located toward the rear of the unit, stores toilet wastes and waste water from the bathroom sink. In rear-bath models, the 32 gallon holding tank is located in the right rear; and the 52 gallon holding tank is located in the left rear. Each holding tank has a separate drain valve, dumping gray water and wastes through a common single discharge connection. A common

wet vent system connects both holding tanks to the vent stack located on the coach roof.

DRAINING THE HOLDING TANKS

The holding tanks drain valves are located under the left side of the coach, as shown in figure 5-5. The waste drain valve is on the right side, near the drain cap; and the gray water drain valve is on the left side, near the wheel. Each drain valve operates in the same manner. Drain the holding tanks as follows:

1. Check that both drain valves are in closed position before proceeding any further. Note that the valve handles will be turned clockwise to close the valve.
2. Drain the waste holding tank first.
3. Remove the safety cap from the single discharge connection by turning the locking ring in a counter-clockwise direction and connect the 3-inch sewer hose coupling to the end of the valve. Tighten locking ring securely, in a clockwise direction. The sewer hose is stored within a pipe located to the right of the drain cap, on side-bath units; and under the bottom skirt panel, left rear, on rear-bath models. Place the discharge end of the hose into the sewer connection and check that all connections are secure to prevent accidental spillage.
4. Open the drain valve by turning the handle to the left (counter-clockwise), then pull the valve stem straight outward. This will discharge the holding tank contents into the sewer connection.




Figure 5-5. Location of Holding Tanks Drain Valves



5. Periodically, after contents are emptied, flush out holding tank to dislodge remaining solids. [Connect a water hose to the "swisher" connection (water saver hose connection adjoining the toilet) and turn on the water supply. A check valve keeps contents from running back into water hose.]

NOTE

To clean the holding tank, add a cup of detergent into the tank after it is emptied. The agitating action from vehicle movement will clean the tank.

6. Close drain valve by pushing valve inward and turning handle to the right (clockwise) into the locked position.

7. Drain gray water holding tank in the same manner, following steps 4, 5, and 6, as applicable.

8. Disconnect and wash out drain hose and replace safety cap securely.

TANK LEVEL DETECTORS

Each of the holding tanks and the potable water supply tank has a level detector which provides an electrical input to The Monitor panel on the side galley wall. Activate the display to read the level of liquid remaining in each tank by pressing the appropriate pushbutton switch inward.

WINTERIZING

To prevent freezing of water pipe supply lines, pipes are wrapped with heat tapes that operate automatically when the temperature drops below 38 degrees F. The holding tanks are also wrapped with heat tapes that activate at the same temperature point. Note that the heat-tapes operate from the ac supply; the water pipe tapes are connected to the ac outlet in the rear of the refrigerator compartment; the tank heater tapes are connected to the ac outlet beneath the bath sink.

If your motorhome is to be stored outside during cold weather, it will be necessary to winterize the water system to prevent damage from sub-freezing conditions. Winterizing procedures are covered in the following paragraphs.

DRAINING THE FRESH WATER SYSTEM

The potable water system is designed so that it can be completely drained within 30 minutes, with a full water tank and heater, by using the water pump, one drain valve and the air blowout system. Use the following procedure for draining and winterizing the system:

1. Turn water heater element OFF.

2. Open hot water heater drain valve (under left-hand bed) by turning the control knob to the OPEN position, connecting the hot and cold water lines together. (This knob is located behind a small door in the vertical wall of the bed, in the aisle.)

3. Open the drain valve beneath the bathroom vanity. (This 1/4-turn valve is accessible by lifting a door in the floor of the vanity cabinet.)

4. Open all faucets (kitchen sink, shower and lavatory) to center position, opening both the hot and cold water lines.

5. Turn water pump ON and allow to pump until only air is being pumped through faucets. Leave all faucets open. Note that the amount of time this step requires will depend on the amount of water remaining in the water tank.

6. When only air is being pumped through the faucets, close the water heater drain valve under the bed by setting the knob to CLOSE position.

7. Flush the toilet and prop open the toilet water valve.

8. Turn the air blow-out switch to ON (located behind the same door as the water heater drain valve knob). This opens the solenoid valve that allows chassis air supply to enter the water lines and blow out any water that may remain after the water pump would no longer pump water through the faucets. Note that it may be necessary to idle the chassis engine to maintain the air supply until the water lines are blown out. Inject the air only until the air again comes through the faucets then turn the air switch to OFF. The water lines are now drained.



9. Because the air volume is insufficient to blow all the water from the water filter under the kitchen sink, remove filter element and pour out any remaining water. Replace element.

10. Close all faucets, including the valve on the toilet. Flush any water that may have blown into toilet bowl.

11. Close drain valve under vanity.

12. Drain both holding tanks. This completes the winterizing procedure.

PREPARING DRAINAGE SYSTEM FOR STORAGE

The entire drainage system should be thoroughly drained and flushed with fresh water. The following procedures are recommended:

1. Completely drain holding tanks of waste material.

2. Flush sinks, shower and lavatory with a solution of hot water, water softener and soap. Rinse well and allow solution to drain into tanks. Flush with clean water.

3. Agitate water in tank by rocking vehicle or, for a more thorough cleaning, drive vehicle for a few miles. Drain tanks again.

4. Alternatively, use a chemical deodorant, let mixture stand a few days, and then drain.

5. Flush with fresh water and again drain.

6. Fill traps and partially fill tanks with an anti-freeze approved for use in plastic pipes. Normally, a cupful of anti-freeze poured into each drain will

fill the trap. Do not use anti-freeze solution with an alcohol base!

BATTERY STORAGE IN FREEZING WEATHER

Batteries that are not kept fully-charged must be given protection against freezing. Partially-charged batteries will freeze at low temperatures, so batteries must either be left connected to a trickle charger or removed from the vehicle and stored in a warm location. Alternatively, the motorhome can be left connected to the shoreline ac supply and the thermostatically-controlled battery heater pads will protect the batteries from freezing. At the same time, the coach converter will keep the batteries charged. Note that even in a warm location it is advisable to keep the batteries charged so that they are ready for use. Add water as required.

NOTE

Remove all items from the coach which may freeze, including canned foods, miscellaneous liquids, etc. Remove all contents of the refrigerator/freezer, clean unit and leave doors ajar.

GENERAL STORAGE NOTES

Drawing draperies will reduce fading of rugs and upholstery. Leaving an air freshener agent will minimize odors from plastics and other materials. Slight opening of windows and vents will allow air circulation without worry of water entering. Covering wheels to eliminate direct rays of the sun on tires will reduce sidewall cracking.



SECTION VI

LPG SYSTEM

INTRODUCTION

The coach is equipped with a permanently-mounted 45 gallon (150 pounds of fuel) LP gas tank which is the energy source for the refrigerator, range/oven and three gas furnaces. A piping diagram of the LPG system is shown in Section X.

LPG TANK AND CONTROLS

The LPG supply tank is located in the compartment forward of the entry door (which also houses the Racor diesel fuel filter/preheater). Tank controls, figure 6-1, include main gas valve, high pressure regulator, filler connection and the 20% relief valve, which provides 312 PSI protection. The low-pressure regulator and electrical solenoid shut-off valve are located in the refrigerator compartment and connect to the tank via flexible high-pressure hose. The solenoid valve is actuated by either a high-pressure condition (caused by a defective regulator); or by the remote LP leak detector, located beneath the refrigerator. Tank level can be monitored at The Monitor panel on the galley side wall. To read the digital display, press the PROPANE TANK button.

CAUTION

Be sure to shut off all gas appliances before filling the LPG tank. Check gas lines and fittings periodically for tightness and leakage.

FUEL REQUIREMENTS

Liquified petroleum gas is a material composed of various hydrocarbons such as propane, propylene, butane, butylene, or a mixture thereof. In its gaseous form (vaporized) it is colorless and has a garlic-scented additive to ensure detection. In addition to being highly inflammable, it is also dangerous to inhale. For ease of transportation and storage, LPG is compressed into a liquid state and stored, in this form, within the LPG tank. As fuel is used, vapor passes from the top of the tank, via the high-pressure regulator, to the low-pressure regulator, which reduces LPG pressure to 11½-inch water column. Low-pressure vapor is then supplied through LPG piping to the various gas appliances.

Prevent condensation and possible tank or line freeze-ups, when filling the tank, by requesting




Figure 6-1. Location of LPG Tank and Controls



the dealer to add a small amount of Methyl Alcohol to the fill-up. A common mixture is one ounce of Methyl Alcohol to each 20 pounds of LPG. Note that the dealer must use a P.O.L. adapter when filling the tank. A filled tank is indicated when liquid appears at the 20% valve.

LP GAS AND VAPOR DETECTORS

Lifeguard One, on the dinette wall, monitors various locations through the coach and sounds an alarm if the safe amount of LP gas or carbon monoxide in air is exceeded. The LP gas leakage detector beneath the refrigerator monitors only this area, sounding an alarm and actuating the LP gas solenoid shut-off valve if a leak is sensed.

LPG REGULATOR

The low-pressure regulator, located in the refrigerator compartment, regulates the pressure of the LPG supplied to the appliances. The regulator functions automatically and is factory-preset to provide the correct line pressure. **DO NOT** attempt to tamper with or reset the regulator! Even a small variation above the normal gas line pressure can be sufficient to create a dangerous situation and cause possible damage to individual appliance regulators. The high-pressure regulator is located on the LPG tank.

OPERATION

Before the main valve on the LPG tank is opened, check that all inside local shutoff valves are closed. These valves are located at the inlet to each of the gas appliances.

CHECKING FOR LEAKS

Periodically check the LPG system for possible leakage. Do not wait for an alarm condition to occur before correcting a leak! Although the entire system and associated appliances undergo extensive factory testing for leakage, road shocks and heavy vibrations may loosen or damage piping or fittings. Leaks will usually become noticeable by the smell of the characteristic odor-additive of garlic (or onions). If you smell this odor, or if Lifeguard One sounds an alarm, immediately turn

off all flames and begin a systematic search for the leak throughout the entire gas system, or at the monitor point indicated by Lifeguard One. Use a bubble or soap solution and brush on connections and fittings.

CAUTION

**NEVER BRING A LIT MATCH
NEAR A SUSPECTED LEAK!**

Gas leakage will be indicated by the presence of bubbles at junctions or at piping breaks. If it is necessary to tighten a gas connection, turn off the LPG main tank valve, then use two wrenches on the connection, with opposing torques to prevent twisting or distortion of the copper tubing. If the leak cannot be found in this manner, the appliance itself may be at fault. Shut down the suspected appliance to isolate it from the system until repairs can be made by an authorized service station.

LPG CONSUMPTION

Most gas appliances are intermittently operated. However, operation during cold weather conditions does cause a heavy use of the gas furnaces. Extensive oven usage also consumes a great deal of fuel. The amount of LPG consumption depends on the total use and manner of use of these appliances.

Note that each gallon (4-1/4 lbs) of LPG fuel produces approximately 91,500 BTU's of heat energy. The LPG tank used in your coach will furnish about 4 million BTU's.

For your guidance in estimating your anticipated fuel consumption, the following is a listing of typical appliance consumption ratings when the appliance is operated for one hour:

Refrigerator.....	1,500 BTU's
Range Oven.....	10,000 BTU's
Range Top Burners.....	5,200 BTU's
Furnaces:	
Bedroom.....	16,000 BTU's
Living Room (front).....	16,000 BTU's
Living Room (middle).....	12,000 BTU's



SECTION VII

AIR BRAKE SYSTEMS

INTRODUCTION

Your motorhome is equipped with dual service air brake systems, with integral fail/safe operation; and manual/automatic rear spring (parking) brakes. As shown in the air brakes system diagram in Section X, the service brakes are completely independent systems, each including a reservoir and separate distribution lines and valves. A separate reservoir is also supplied for the rear spring brakes, which function independently of the service brakes. All three reservoirs are pressurized from a single compressor. Both service brake systems are brought into operation each time the brake treadle is depressed to slow or stop the coach. Reservoir pressure for each service brake system is monitored by a respective pressure gauge on the front panel; system failure(s) are indicated by low pressure readings, illumination of the LOW AIR failure lamp, located above the odometer, and by sounding of the low air warning buzzer.

OPERATION

When the coach is parked, and the engine off, the rear spring brakes will normally be set by operating the parking brake. The spring brakes cannot be fully released until the air pressure is above 90 psi. These brakes are in the released position when the control is pulled out. In the event that there is a loss of air pressure, the spring brakes will set automatically, at the brake-applied position, and will not release until the air reserve has again built up to the required value. Consequently, there will be a normal delay, after the coach is first started, before the compressor builds up sufficient pressure in the three reservoir tanks, before the brakes can be released and the coach driven. When the brake treadle is depressed, to slow or stop the coach, reservoir air is applied simultaneously to both front and rear service brakes to effect the braking action. The spring brakes are held in a released position by the air pressure supplied from the associated reservoir tank.

CAUTION

Do not attempt to drive the coach until system pressure is 90 to 105 psi.

BRAKE FAILURES

Brake system failures are protected against by a combination of fail/safe features. Each service braking system, front and rear, has a backup capability in the form of the rear spring brakes in the event of partial or total system failures. If the front brakes fail, operating the brake treadle activates both the rear service brakes and the rear spring brakes, providing sufficient braking action to effectively stop the coach. Under these conditions, the spring brakes do not lock in, as in a normal released position, but instead their application is "modulated" in the same manner as the service brakes, thereby providing a normal braking "feel". If a failure occurs in the rear, the front and rear spring brakes provide braking action.

In the unlikely event of a failure where both service braking systems are disabled, the rear spring brakes will apply automatically and bring the vehicle to a stop. As a safety factor, the coach should not be moved until any type of brake failures are corrected.

NOTE

With the front brake system service reservoir fully charged, enough air pressure is available to provide for four full releases of the rear spring brakes. This will allow the coach to be brought to a safe position until repairs can be accomplished.

ADDITIONAL AIR-OPERATED EQUIPMENT

Besides providing the compressed air supply for the coach braking systems, the compressor also provides the air supply for the entry step, side-slide mechanism on driver's and co-pilot's seats, gene-



rator tray, and steering wheel tilt mechanism — all via separately-controlled solenoid switches operated from the dashboard, or at other locations throughout the coach. (This compressed air source is furnished from the front right side reservoir.) For example, the compartment located just inside the entry door contains switches for the generator tray and entry door step (also controlled at the dashboard). Also, a compressed air outlet fitting and air gun is contained in the center storage compartment on the left side of the coach, convenient for blowing out the water system, inflating tires, and so on.

COMPRESSED AIR SYSTEM AIR DRYER

The air dryer unit collects and removes moisture and contaminants from the compressor air output before the air reaches the reservoirs. This unit is different from a reservoir drain or an aftercooler in that it provides dry air for the brake system by eliminating the possible accumulation of condensate in the system reservoirs. This assures a long maintenance-free life for air brake system compo-

nents due to the removal of system contaminants.

The air dryer is located between the compressor discharge (output) line and the compressed air reservoirs. A safety valve mounted in the air dryer housing assembly protects against excessive pressure buildup. The desiccant cartridge and pleated paper oil filters are easily removable and replaceable as a complete serviceable unit. The desiccant "beads" which provide the drying action have a large capacity for absorption due to their combined surface area. In addition, an internal thermostatically-controlled heating element prevents freezeups on the purge drain valve when the unit is used during sub-freezing temperatures.

Purging of the dryer is automatic, exhausting combined oil and water residue to the atmosphere. At the same time that the contaminants are purged the reverse air flow across the desiccant material removes the accumulated moisture and reactivates the desiccant. Cartridge replacement should be accomplished at 12-month periods; sooner, if the cartridge has become contaminated.

TOWING 7500

TONGUE 750



SECTION VIII

OWNER MAINTENANCE DATA

Cat 3208 T 225hp

oil Filter 3743881 Cat 9N6007

Air " 2106722 Forr T-512

Fuel " 2236677 Cat 1P2299

Racor " 2254035 Racor 204050

INTRODUCTION

This section provides general information for use in performing scheduled services as well as preventive and routine maintenance on your motorhome.

SPECIFICATIONS AND DATA

Table 8-1.

Engine Capacities and Specifications

Item	Specifications
Diesel Fuel Tank Capacity	
31' and 33' side bath units	235 gallons
All rear bath units	150 gallons
35' side bath unit	265 gallons
Cooling System Capacity	
w/front heater	46 quarts
w/front and rear heaters	60.2 quarts
Crankcase Capacity	
Dry	12 quarts
Refill	10.5 quarts
Oil Specifications	MS, Series 3
Operating Temperature Range	
30 degrees to 100 degrees F	SAE10W/30,
	SAE10W/40, SAE-30
0 degrees to 30 degrees F	10W-30 or -40
Frequency of Oil Change	Every 3 months,
	or 6,000 miles
Transmission Capacity	19 quarts
Tire Inflation Pressures	
(11 x 22.5, 16 ply tubeless)	
Front	105 lbs
Rear	75 lbs

Table 8-2

Generator Capacities and Specifications

Item	Specifications
Fuel Tank	Separate 30 gallon gas tank, fill through access panel, figure 8-1
Cooling System	Water cooled, 7 quarts

FRONT AXLE GUV - 13,200
 REAR AXLE GUV - 23,000
 GUV 34,200

Crankcase Capacity 5 quarts w/o filter
 5-1/2 quarts w/filter change

Oil Specifications

30 degrees to 100 degrees F SAE38/10W-40
 0 degrees to 30 degrees F SAE10W-30/10W-40
 Below 0 degrees F SAE5W-20

Table 8-3

Motorhome Capacities and Specifications

Item	Specification
Potable Water Tank. <i>Actual 96.8</i>	96 gallons <i>37</i>
Holding Tank, Sewage. <i>Not 4.2</i>	32 gallons <i>38.5</i>
Holding Tank, Waste. <i>Not 60</i>	52 gallons <i>54</i>
LPG Tank	180 lbs (45 gallons) <i>51</i>
Water Pump	2.8 GPM
* Furnaces	16,000 BTU(2); 12,000 BTU(1)
Hot Water Heater	12 gallons
Batteries	4 6-volt batteries, series-parallel connected to supply 12V at 440 AH
Battery Chargers	2, 50 amperes output each
* Air Conditioners	
Rear (31', 33' units)	13,500 BTU(1)
Front (31', 33' units)	13,500 BTU(1)
All (35' unit, option)	13,500 BTU(3)
Automotive	18,000 BTU
Central (35' unit only)	14,000 BTU
** Hot Water Circulating Heaters	
Living Area	50,000 BTU
Driver's Area	90,000 BTU
*NEMA Rating	** SBBMA Rating

Table 8-4

12-Volt Lighting and Equipment, Current Usage

Item	(Qty)/Current (Amps)
Automotive Lighting	
Marker/Identification	(16)/9.6
Stoplights	(4)/7.2
Parking Lights	(4)/2.1
Headlights and Taillights	
Hi-beam operation	(6)/13.4
Lo-beam operation	(4)/9.2
Ignition	(1)/2.5

(continued)



Table 8-4

12-Volt Lighting and Equipment (Continued)

Item	
Instrument Panel.....	(1)/1.0
Stepwell, outside.....	(2)/2.5
Backup Lights.....	(2)/4.2
Interior Lighting	
Reading Spots.....	(7)/1.5 ea
Front Living area.....	(6)/7.8
Bathroom.....	(1)/1.3
Shower.....	(1)/1.0
Dinette.....	(2)/2.6
Kitchen.....	(1)/1.3
Bedroom.....	(4)/5.2
Windshield Wipers.....	(2)/8.0
Water Pump.....	(1)/6.2
Blower Motors	
Front Heater (Hi/Low).....	(1)/9.0/4.5
Defroster (Hi/Low).....	(1)/9.0/4.5
Foot Warmer (Hi/Low).....	(1)/9.0/4.5
Rear Heater (Hi/Low).....	(1)/9.0/4.5
LPG Furnace.....	(1)/7.3
Portable Fan.....	(1)/1.0
Duct Booster.....	(1)/1.0
Stereo System.....	(1)/7.3
Ceiling Vent.....	(1)/4.0




Figure 8-1. Generator Gas Tank Access Panel

CHANGING TIRES

The tires used on your motorhome are heavy-duty truck-type tires. These tires are **HEAVY** and may be difficult to handle. If at all possible, tire changes should be accomplished by a service station equipped to handle truck tires. However, if a situation arises where no service facilities are available, the following procedures may be used.

NOTE

These procedures apply only to front tire changes. A blown-out rear dual tire will not prevent you from driving to a service stop providing that you drive slowly (25 mph, maximum!). This will prevent tire overheat and possible blowout of the other tire in the pair.

WHEN A SPARE TIRE IS AVAILABLE

1. Drive motorhome out of traffic lane, if possible, onto a level surface.
2. Turn on hazard flasher and apply emergency brakes before leaving coach.
3. Turn off ignition and set transmission selector to Neutral (N) position.
4. Remove jackstand, lug wrench and handle from front right side storage compartment, figure 5-3.
5. Place wheel chocks against wheels on opposite side of work from flat tire.
6. Place jack under spring pad and raise jack slightly until securely in place. See figure 8-2 for location of typical jacking points.




Figure 8-2. Locating Tire Jack



MICROWAVE OVEN

The microwave oven provides programmed microwave cooking and conventional "browning".

Cooking with microwaves is considerable different than cooking with a conventional oven. Do not use conventional metal pots or pans (frozen dinners may be cooked directly in the shallow aluminum tins, no more than 7/8-inch high). Use glass, ceramic, china, plastic or paper containers;

these are transparent to microwaves and allow food to heat quickly. Interior spatters, soiling or condensation are easily cleaned with a damp rag.

All operating controls and indicators are provided on a keyboard-type control panel, as shown in figure 1. All control cycles — microwaving, browning, temperature-monitoring, cycle timing — are selected by operating switches on this panel. Use figure 1, on the reverse side of this page, as an operational guide to microwave oven operation.




Figure 1. Microwave Oven Operation Guide



Table 1. Ice-Maker Troubleshooting Guide (continued)

Symptom	Possible Cause	Corrective Action
Ice cube supply cloudy.	This is due to air being trapped in the water due to fast-freezing. This is not harmful.	None required.
Too much water entering.	Water valve switch is not adjusted properly.	Remove front cover and adjust screw.
Ejector blades frozen in cubes.	Too much water entering.	Adjust water valve switch. Remove front cover and adjust screw.
	Machine received a "double shot" of water; or cubes piled too high melted back into freezing tray.	Shut off machine for one hour.
Ice-maker won't eject cubes.	Ejector blades frozen into ice maker mold.	Defrost unit and remove some water from freezing tray.
	Too much water entering.	Adjust water valve switch.
Compressor inoperative.	No supply voltage to unit.	Check for ac supply; reset circuit breaker.
	Unit is switched off.	Set switch behind front grille to ON.
Intermittent operation.	Improper door seal.	Adjust hinges, realign door, or shim door gasket where required.
Noisy compressor.	Machine is not level.	Level unit properly.
Compressor runs continuously.	Control set too cold.	Use a warmer setting.
	Obstructed front grille.	Remove obstruction.
	Dirty condenser.	Clean condenser.



MOTOR GENERATOR

The motor generator is designed for unattended operation and is located in the right front storage compartment. Unlike a dc-to-ac inverter, which electronically changes the dc battery voltage to an ac line voltage, the motor generator includes a dc motor which generates an ac output in the same manner as commercial electricity is produced.

Because of this, the ac output is completely isolated from the dc source. The stabilized ac output is used to operate the optional ice-maker, when this unit is used in the coach. Both the motor generator and the ice-maker are offered as separate options.

User maintenance of this equipment is not recommended.



CAUTION

Truck tires are heavy! Two people will make tire handling an easier chore!

7. Remove spare tire (if available) from tire mounting and place on ground near work area.
8. Loosen lug nuts slightly, then jack up coach until tire is clear of ground.

NOTE

Lug nuts on right side of coach are right-hand threaded (turn counter-clockwise to loosen, clockwise to tighten); lug nuts on driver's side of coach are left-hand threaded (turn clockwise to loosen, counterclockwise to tighten).

9. Remove lug nuts and tire.
10. Install spare tire and replace lug nuts tightly.
11. Lower coach to ground and remove jackstand and handle.
12. Replace lug wrench, jackstand and handle in storage compartment and tie down to prevent road noise. Return damaged tire to holder and have it repaired as soon as possible.
13. Remove and stow wheel chocks.
14. Turn off hazard flasher before returning to traffic.

CAUTION

Check lug nuts for tightness every 1,000 miles. Lug nuts should be torqued to 450 to 475 foot-pounds.

WHEN NO SPARE TIRE IS AVAILABLE

To replace a front tire when no spare is available, remove one of the outer rear dual tires and use this as a spare. To remove the tire, it will be necessary to run the inside dual tire up on a small wooden ramp (contained in the left rear storage compartment, figure 4-8) which is high enough to raise the outer tire above ground level.

CAUTION

For added safety, place the tire jack, extended, beneath the frame member adjacent to the inside dual tire. Remove jack before driving off ramp!

Remove the tire to be used as the spare and back the coach off the ramp. Replace the front tire by following the instructions given previously.

CHANGING A REAR TIRE

Outer tires may be changed, if a spare is available, by driving the inner tire up on the tire ramp, and then removing and replacing the tire as previously described.

BATTERIES

Your motorhome is equipped with four 6-volt batteries, connected in a series-parallel arrangement to provide 12 volts for engine and motorhome use. Batteries are located in the front outside compartment on the driver's side, as shown in figure 4-1. A separate 12-volt battery is contained in the generator compartment and is used only to start the generator; it is also charged by the generator.

The four engine/motorhome batteries are charged by the engine alternator, while the engine is operating. In addition, the batteries are also charged by two 50-ampere battery chargers during the time that generator or shoreline ac power is furnished.

PERIODIC CHECKS

Check the level of the battery electrolyte on a regular basis. The intervals at which fluid is added depend on the battery usage, climate and proper use of the battery charger. Experience with coach operation will soon provide a guide as to how often the batteries should be checked. Add only colorless, odorless drinking water, or distilled water, as necessary, to bring the electrolyte level to the



split ring visible in the filler hole opening. (A small mirror and flashlight will help to check the level.)

CAUTION

Do not expose batteries to an open flame or electric spark — battery action generates hydrogen gas, which is flammable and explosive! Avoid contact with battery acid; this is a sulphuric acid that can cause personal harm. Flush exposed area immediately with water to neutralize and remove acid. Do not allow acid to come in contact with clothes, painted surfaces, etc., or these will be damaged. Also, do not wear metal rings, watches or jewelry when working on or near the battery, cables, solenoids, or chassis wiring. These can short out electrical wiring and cause injury.

To make sure that the batteries are always ready for use, periodically check and charge as necessary. Check batteries at least every two weeks in freezing weather; at least every four weeks in warmer weather. A fully-charged battery will not freeze under normal circumstances, so it is imperative that the batteries remain charged during winter. A safe level of charge is a specific gravity reading of 1.225 to 1.280. Always use a battery hydrometer which has a temperature correction scale.

BATTERY MAINTENANCE

A dirty battery will eventually dissipate its charge through conductive surface contamination. Clean battery top surface with a damp cloth and dry thoroughly. Check that terminals are tight and free of corrosion. To clean terminals, neutralize corrosive deposits with a solution of baking soda, rinse with clear water, and dry. Note that commercial type spray-on battery cleaners are available at automotive supply stores. Use as directed to keep the batteries clean. Spray-on cable and terminal protective coatings are also available, easy to use, and effective.

EXTERIOR CARE

Exterior paint finish life can be extended by

periodic cleaning and waxing. This will preserve the paint and allow easier removal of dirt and road tars. Use touch-up paint for small areas to keep the coach finish in like-new condition.

Frequent washing of the coach is necessary to prevent corrosion when parking where heavy salt sprays are evident. A clear acrylic spray may be used, with care, to control corrosive effects of salt spray on metal surfaces.

INTERIOR CARE

The interior can be kept in good condition with the use of approved cleaning agents for vinyl walls and ceilings, plastic fixtures, stainless steel, formica and so on. Never use abrasive cleaning agents on interior of refrigerators, or on sinks, as they can cause permanent scratches. Be sure that the cleaning agent will not damage the material. Note that some plastics are incompatible with certain cleaners. Read the directions on the container before using. For the most part, the cleaners and polishes that would normally be used in your home are equally well-suited for use in your motorhome.

FLUID LEVEL CHECKS

CRANKCASE OIL LEVEL

Oil level checks can be accomplished from inside the coach by unlatching and lifting away the hood ledge cover, shown removed in figure 8-3.




Figure 8-3. Oil Dipstick Location, Engine Hood Removed



The crankcase engine oil supply should be maintained at the proper level. If checking oil level immediately after engine has been operating, allow a few minutes for the oil to drain back into the crankcase before checking the dipstick reading.

The oil level may be checked, and oil added, from inside the coach. The best time to check the oil is before getting underway because the engine is cool and the dipstick reading will be most accurate. To check oil level, remove dipstick, wipe clean, and reinsert for an accurate reading. If oil reads at or below the "Add Oil" mark, add oil as necessary. Maintain oil level in the safety margin, staying between the "Full" and "Add Oil" markings.

POWER STEERING FLUID LEVEL

Regularly check hydraulic fluid level in the power steering pump reservoir, figure 8-4, at each fuel stop. Add power steering fluid (or automatic transmission fluid) as necessary to maintain the correct dipstick reading, depending on fluid/engine temperature. (Note that dipstick is attached to the bolt on top of the reservoir.) If the fluid is at normal operating temperature — about 150 degrees, and hot to the touch — the dipstick should indicate $\frac{1}{2}$ to $\frac{3}{4}$ full. If engine is cool, fluid level should read about $\frac{1}{2}$ full. Power steering fluid does not require periodic changing, as does automatic transmission fluid.

TRANSMISSION FLUID LEVEL

Check transmission fluid level, figure 8-5, with engine idling. Cold checks, or checks made with the engine off, will be misleading. Dipstick should read "Full".

WATER PUMP MAINTENANCE

Under normal usage, the water pump should




Figure 8-4. Power Steering Reservoir




Figure 8-5. Transmission Dipstick Location

require no periodic maintenance other than ensuring that the input water supply is properly filtered of particles that could damage the pump mechanism. Pump failures can generally be tied in to the plumbing system, or to electrical supply lines, or to the pump electrical wiring. If the pump fails to operate properly, refer to the general troubleshooting guide given in table 8-5. Note that detail pump repairs and overhaul (noted by *) should be performed by a qualified repair facility.



Table 8-5. Water Pump Troubleshooting Guide

Symptom	Possible Cause	Corrective Action
Pump operates but no water flows through faucet.	Low water level in tank.	Add water to tank.
	Water lines are clogged.	Blow out water lines with compressed air.
	Kink in water hose.	Check water hose connections to tank and straighten or replace, as necessary.
	Air leak in suction line.	Replace suction line.
	Dirty or hard-to-open in-line check valve.	Replace check valve.
	Defective pump valve.	* Replace pump valve.
Pump cycles on and off when faucets are closed.	Water leak in plumbing.	Check for signs of leakage and tighten or replace fittings, pipe, etc.
	Defective toilet flush valve.	Repair flush valve.
	Internal leak in valve. Pump check valve not sealing.	Replace check valve.
Pump operates roughly and has excessive noise and vibration.	Intake line is restricted, kink in suction hose or fittings too small.	Check input hoses and straighten or replace, as necessary.
	Deformed or ruptured pulsation dampener in pump.	* Replace dampener.
	Loosened screws at pulleys and connecting rod.	Tighten screws.
	Worn connecting rod bearing.	*Overhaul required.
Pump fails to start when faucet is opened.	Clogged piping.	Blow out water lines with compressed air.
	No voltage to pump.	Check input wiring, circuit breaker and switches.
	Defective pressure switch.	*Replace pressure switch.
Pump fails to stop when faucets are closed.	Empty water tank.	Add water.
	Insufficient voltage to pump motor.	Check battery voltage. If voltage is OK, pump is defective.
	Defective pressure switch.	*Replace pressure switch.



WINDSHIELD WASHERS

Check reservoir fluid level periodically and use a prepared washer solution, if possible. During freezing weather, use a solution additive, or a solution specifically designed for cold weather usage. The washer reservoir is accessible through the front right storage compartment.

GENERATOR

Keep the generator operating at peak efficiency by following a regular schedule for inspections and servicing, based on operating hours. Keep an accurate logbook record of maintenance, service and hours of operation, following regular schedules for normal operating conditions; and a more frequent service schedule for operation under dusty or dirty conditions. Check condition of crankcase oil and change air filter frequently until the proper service/time periods can be determined based on your usage.

MAINTENANCE SCHEDULES

Use the generator maintenance schedule as a guide for routine and periodic maintenance. Neglecting generator maintenance can result in failures

or permanent generator damage. Refer to figure 8-6 for component location; refer to the generator service manual for detailed repair and maintenance.

Generator Maintenance Schedule

Frequency	Service
Daily, or before each startup	Check oil level Check fuel supply Clean radiator intake screen
Every 50 hours, or 6 months, whichever occurs first	Change lubrication oil Service air cleaner Check radiator coolant level Check fan belt tension Clean oil filter breather cap
Every 100 hours, or 8 months, whichever occurs first	Service spark plugs Check battery electrolyte level
Every 200 hours, or every year	Check and tighten electrical connections Clean crankcase breather cap Check and tighten mounting bolts Check generator brushes,




Figure 8-6. Generator Component Locations



commutator and slip rings
Check ignition timing
Replace air cleaner element
Tune-up engine
Every 500 hours, or every 2 years
Contact authorized service center for overall tuneup and preventive maintenance checkout

Periodically, perform a complete visual inspection of the generator when operating at full load.

CAUTION

Use extreme caution when observing an operating generator with tray extended.

1. Check for possible leakage from oil and fuel lines.
2. Inspect exhaust line, muffler, and connections for possible cracks or leakage.
3. Periodically check air shrouds for leakage and security. Check that cooling fins are clean.
4. Inspect electrical wiring for frayed wires, corroded connections and general wire damage.

BATTERY

Check the condition of the generator battery at least every two weeks. See that battery connections are clean and secure. A light coating of non-conductive grease will prevent corrosion at terminals. Keep the battery electrolyte at the proper level above the plates by adding water, as needed. Check specific gravity and recharge if hydrometer reads below 1.250. Refer to Battery Maintenance procedures provided earlier in this section.

AIR CLEANER MAINTENANCE

Proper maintenance of the air cleaner, figure 8-7, is extremely important. Allowing this vital element to become clogged with dirt restricts the flow of intake air into the engine. Inspect the element for tiny holes or tears which would allow particles of dust or dirt to enter the carburetor. These particles can also cause excessive wear of piston rings.

Operating with an over-rich fuel mixture caused

by a poorly serviced or clogged air cleaner leads to formation of harmful sludge deposits. It is a good practice to replace the element after 100-200 hours of usage, under normal conditions; and more often under dusty or dirty conditions.

Every 50 hours, or six months, remove the element and lightly tap rubber rim against a flat surface to dislodge any loose dust or dirt from the surface. Replace element if there are too many dark spots or extensive dark areas as these indicate dirt trapped within the filter material. It is not advisable to wash dry the element in any liquid or to attempt to clean it with an air hose as this will ruin or damage the paper fiber filter. When handling the element, use care to avoid crushing or bending as this will permit unfiltered air to enter the engine.




Figure 8-7. Air Cleaner

CRANKCASE BREATHER CAP

At every fourth oil change, or every 200 hours, remove the crankcase breather cap and service by soaking and swishing in a solvent, such as kerosene. After cleaning, allow five minutes for it to dry, then lightly re-oil with engine oil before reinstalling on breather tube.

LUBRICATION

The generator engine has a positive pressure lubrication system and low-oil pressure shut-down.



NOTE

The low-oil pressure shut-down feature protects the engine from internal damage due to oil pump failures or other malfunctions causing low oil pressure. It does not protect against damage due to operating with oil level below the safe range since it is not a low-oil level shut-down. The only protection against running out of oil is periodic checks and addition of oil to keep level constant.

OIL CHECK — To be on the safe side, check oil in engine crankcase daily, or before each start, to ensure that the level is in the safe range between the “L” and “F” marks on the dipstick, figure 8-8. Do not operate generator if level exceeds “F” mark, or is below “L” mark.

CAUTION

Do not check oil level while engine is operating. Engine must be stopped to obtain a true reading, as well as for safety reasons!

OIL CHANGE — On a new engine, change the oil after the first five hours of operation and, thereafter, at 50 hour intervals or every five months, whichever occurs first. Whenever possible, drain the oil while the engine is still warm. To drain, place a container below the unit, open the oil drain and allow sufficient time for the old oil to




Figure 8-8. Oil Dipstick

drain completely. After draining, close drain plug and tighten securely. Note that the oil refill is 5 U.S. quarts.

OIL TYPE — The lubricating oil used must meet the requirements of the American Petroleum Institute (API) Service Classification SC, SD, SE, or CC (MS). Oil weight (SAE viscosity) is selected according to anticipated ambient temperatures. Use a straight-weight SAE30 oil when temperatures are above 30 degrees F (–1 degree C); use SAE-10W30 when temperatures are in the range of 30 degrees F (–1 degree C) to 0 degrees F (–18 degrees C); and use SAE5W-20 when temperatures fall below 0 degrees F (–18 degrees C). The API Service Classification and SAE viscosity numbers are stamped or printed on the oil can.

COOLING SYSTEM

To avoid having the inconvenience of the generator shutting down due to overheating, or becoming damaged as a result of an overheat condition, be sure to keep the cooling air inlets to the




Figure 8-9. Generator Cooling System



compartment clean and unobstructed at all times.

Cooling system capacity is about 7 quarts of liquid. When operating in climates subject to freezing temperatures, make sure that enough anti-freeze solution is added to the coolant to prevent system freeze-up. As shown in figure 8-9, a drain petcock is provided on the underside of the radiator to drain the system. When draining the coolant, remove the radiator cap and open the block drain valve near the oil filler cap to prevent air pockets from forming and blocking water in passages in the block.

Check coolant level frequently and add water or anti-freeze as needed to maintain correct level.

Before adding anti-freeze, drain the coolant system completely to assure correct proportions of anti-freeze to water. For example, to protect a 7-quart capacity radiator system to -11 degrees with ethylene glycol, use a 40% solution, as shown in the chart given below. [This is figured as $.40 \times 7$ quarts = 2.80 or, rounded off, 3 quarts of anti-freeze to 4 quarts of water = 7 quarts total.]

For maximum protection always use a solution which will remain liquid below the lowest anticipated temperature.

Anti-Freeze Protection Chart

AntiFreeze Protects to:	Mixture Proportions (ethylene glycol)				
	10%	20%	30%	40%	50%
+16 degrees F (-9 degrees C)		x			
+3 degrees F (-16 degrees C)			x		
-11 degrees F (-24 degrees C)				x	
-31 degrees F (-35 degrees C)					x

GENERATOR TROUBLESHOOTING

Under normal conditions, generator service will

not be required on a regular basis. If operating under extremely dusty and dirty conditions, use dry compressed air to blow dust out of generator at frequent intervals. Do this with the generator set operating and direct the stream of compressed air in through the cooling slots at the end of the generator.

Refer to the generator service manual for repair and maintenance data. Generator repairs should be accomplished by a qualified repair agency.

GENERATOR OVERLOADS — If the rated capacity of the generator is exceeded, the safeguard circuit breakers, located on top of the generator end cover (figure 8-6), will trip to protect the generator against damage. This condition could be caused by a short in the coach ac supply circuits, or by operating too many appliances simultaneously, resulting in an overload condition. If the safeguard circuit breaker trips, the generator will continue running but no ac output will be supplied. Before resetting the circuit breakers, turn off some of the coach appliances and lighting to reduce the load to within the operating limits of the generator. If this is done, and the generator breakers still trip, a short circuit is indicated. Turn off the generator, locate and correct the cause of the short circuit.

STORAGE PROCEDURES

If the generator is to be out of service for a long period of time, perform the following procedures before placing the unit in storage:

1. Drain oil from crankcase (while hot) then flush with clean light-weight oil. Refill crankcase with regular-weight oil after flushing.
2. Drain fuel from carburetor bowl. This is necessary to prevent the gasoline from becoming "stale", which results in the formation of gum deposits.
3. Remove the spark plugs, pour about 1 tablespoon of oil into each hole, crank engine several times, then replace spark plugs.
4. Clean exterior surfaces of generator set then spread a light film of oil over any unpainted metallic surfaces which could corrode.



REFRIGERATOR

ROUTINE MAINTENANCE

To ensure that your refrigerator will provide trouble-free operation, the following routine maintenance procedures should be performed at least once each year.

1. Inspect electrical connections, 12-volt dc and 120-volt ac, for tightness and proper grounding. Intermittent refrigerator operation on electric power may indicate poor connections.

2. Inspect all gas connections for leakage, using a solution of soapy water. Tighten, as necessary.

3. Remove and clean the gas burner orifice, figure 8-10, as follows:

- a. Turn off refrigerator gas supply.
- b. Remove burner shield to gain access to burner gas supply tube.
- c. Loosen burner tube connection fitting and CAREFULLY remove burner gas tube from burner.
- d. Remove orifice and clean, using air pressure. Inspect orifice against light to see that opening is clean. **DO NOT CLEAN ORIFICE WITH A PIN OR SHARP OBJECT.** This will affect the size of the opening.
- e. When clean, replace orifice and burner gas supply tube, then reassemble. Check for leaks with soapy solution before replacing burner cover. (Turn on gas supply and press safety valve button in to check.)
- f. Start refrigerator and allow to operate for a while before checking appearance of flame. Flame should be "sharp" blue with no yellow coloring.

REFRIGERATION FAILURES

Not all refrigeration failures are caused by a defective cooling system. Before having the unit serviced, check the following:

1. If the unit has been operating on LP and a loss of cooling occurs, switch operation from gas to electric and see if cooling occurs. This will show if the problem is in the LP supply. Similarly, if cooling is inadequate on electric, try using LP.

2. When changing from gas to electric operation, or vice-versa, allow time for the refrigerator to cycle properly. Cooling should occur normally providing that the following have been checked:

- a. Evaporator plate level in each direction.
- b. Controls have been set to correspond to the power source used.
- c. The LP supply is at the correct pressure and the electric supplies are within tolerance.
- d. Upper and lower vents are not being obstructed, restricting ventilation.

3. If no cooling is apparent after a reasonable period of operation, the cause of failure may be due to a system blockage. This problem is caused by operating the unit for extended periods in an off-level condition. This does not mean that the unit has been damaged, but correction requires that the refrigerator be removed from the coach and placed on its left side for a minimum of one hour. This will allow the ammonia and water to mix with each other, which is necessary for operation of an absorption cooling system. Once the system blockage has been relieved, operate the unit on ac for a while to be sure that the problem has been corrected. Otherwise, cooling system service should be performed by an authorized refrigerator service center.




Figure 8-10. Cleaning Gas Burner Orifice



AIR CONDITIONING SYSTEMS

MAINTENANCE

Both roof air and central air conditioning units require periodic cleaning of the air filters. This is the only user maintenance recommended for these units. Under normal operating conditions, filters should be cleaned at least once each month. More frequent cleaning may be necessary in dusty areas. Adapt the following procedure to the type of filter used in your air conditioning unit:

1. Turn unit off.
2. Remove return air grilles and filters. Insert a smooth flat object, such as a table knife, between the center of the switch (or label) end of the grille and, with a twisting action, gently pry grille out until mounting holes are free of the corresponding holes in the plenum assembly. (The filter used in central air conditioning units is located behind the return air grille.)
3. Wash filters and grilles in warm soapy water. **DO NOT USE SOLVENTS!**
4. Rinse filters and grilles with fresh water and dry.
5. Replace filters and grilles in unit.

NOTE

When replacing the grilles be sure to install with notched (cutout) sides up toward the switch and label plates. If grilles are mounted incorrectly, mounting pins will not fit holes and pins may be broken.

CAUTION

Do not cycle compressor on and off rapidly or compressor damage may result. Once the compressor has been turned off, wait several minutes for system pressure to equalize before restarting unit.

To avoid damaging the air conditioning unit:

1. DO NOT turn the air control knob from a cool position to OFF and then immediately back to a cool position.
2. DO NOT turn air control knob from any

COOL position to a FAN ONLY position and then back to COOL.

3. DO NOT turn the temperature control from a colder setting to a warmer setting and then back again rapidly.

Periodically check for proper drainage in the condensing unit (central air conditioning system) drip tray by rapidly pouring two quarts of water directly into the tray. The water should drain completely within 30 seconds. If not, clean tray and check drain holes for obstructions.

TUB/SHOWER MIXING VALVE

The water mixing valve used in the tub/shower contains a spool valve, figure 8-11, which requires periodic cleaning. Water mineral deposits which can accumulate in the valve body and spool valve can affect the normal operation of the mixing unit. To gain access to the valve body, remove the four screws which hold the faceplate to the shower wall. (Water supply must be turned off.) Remove the control knob, then lift off the faceplate.

To remove the spool, unscrew the large center screw and carefully withdraw the spool from the valve body. Inspect O-rings for damage and replace, if necessary. Flush out spool of any foreign material, then replace in valve. Replace faceplate and secure with four screws. Replace knob.




Figure 8-11. Tub/Shower Mixing Valve



AQUA MAGIC TOILET MAINTENANCE

No routine maintenance is required. If the bowl sealing blade fails to operate freely after extended usage, restore the original smooth operation by applying a light film of silicon spray to the blade.

To clean the toilet, use Thetford Aqua Bowl or any other high-grade, non-abrasive cleaner. Do not use highly concentrated or high-acid household cleaners. They may damage the rubber seals.

normally require routine maintenance or cleaning. However, if, for any reason, the main burner has been allowed to operate with a high yellow flame, a soot formation is sometimes deposited inside the combustion chamber. This carbon deposit may be of such quantity that cleaning will be required. To clean the combustion chamber, there is an access hole on the front of each radiation chamber. A vacuum cleaner is ideal for cleaning out carbon deposits. The blower motor is the sealed, permanently-oiled type and requires no oiling.

SUBURBAN DYNA-TRAIL FURNACE MAINTENANCE

The Suburban Dyna-Trail furnace units do not

Before assuming that the furnace is defective, check the following possible causes and corrective actions. If these fail to correct the trouble, refer to the furnace service manual for detailed repair and maintenance data.

Possible Cause	Corrective Action
Thermostat off.	Check to be sure that thermostat is calling for heat. Check for defective thermostat wiring.
Gas supply shut off.	Check that manual gas valve is in open position, with lever parallel to gas line.
Poor electrical connections or low battery voltage.	Check battery supply voltage. If battery is low, there will be sufficient power to run the blower, but not at full speed. This will prevent the air-operated microswitch from being actuated, gas will not flow to the main burner, and the spark will be missing. Be sure that the terminal wiring and connections are not loose or broken.



SECTION XI
EQUIPMENT OPTIONS



AWNINGS

The awning attached to your coach is designed for simplicity of operation and long-term use. To open the awning, refer to the installation sequence, shown in figure 1, and proceed as follows:

OPEN AWNING

1. Loosen clamp wheels and tilt inward, as shown in A.

2. Completely unroll awning by pulling the tab toward you with the hook. Fold and tuck the tab into the loop nearest the roller on the underside of the awning as shown in B. Now move be-

neath the awning and proceed with step 3.

3. Release snap stud on main arm and extend the awning until the second hole is engaged, as shown in C.

4. Referring to D, raise awning to desired height by extending main arm. Release snap stud and push outward on underside of roller-release snap stud so it will engage at desired height. Lean, so that body weight — rather than arm strength — carries out this step.

5. For a "short" awning, refer to E and unroll awning two-thirds of its length. Place spring arm claw on roller shaft; do not release snap stud. Do not release the tab until spring arm is secured. Fold tab and tuck into middle loop.




Figure 1. Awning Installation Sequence



CLOSE AWNING

1. Release snap stud on spring arm. Remove spring arm claws from roller shaft and place them on claw pins (on inside of main arms). This "scissors-action" guides the main arms evenly and upward.
2. Release snap stud on main arms and lower awning.
3. While facing the awning, and holding the tab loosely in one hand, give the roller an upward push until the spring takes over. Control the roll-up speed by holding the tab until all but 6" of fabric has rolled up. Release tab and allow awning to roll free for these last few inches and snap closed.

NOTE

The tab must be spiraled around the roller to prevent a loose roll and the bunching-up of fabric.

4. Tighten clamp wheels before moving vehicle.
5. Observe if the roll-up is even and in-line with clamps. If not, then unroll and give roller a slight push toward the direction required to line up the roller. If you wish to have the awning roll up more in either direction spiral the pull tab in that direction.

FABRIC CARE

The awning fabric is Acrilan, which cannot rot or mildew. Since it is woven, you will be cooler in its shade because of air circulation through the weave. A regular cleaning with a dry, medium-bristle brush, or a hose rinse, is usually sufficient to remove most dust and dirt. For more stubborn stains, use a mild solution of pure soap (Ivory or Lux, for example) and Borateem, applied with a sponge or a soft brush. Rinse well after and repeat if necessary. NEVER use a strong detergent (such as 409 or Fantastic) as these can remove the chemical impregnation that keeps the fabric water-resistant.

Acrilan can be rolled up wet, if necessary, but unroll to dry as soon as possible. Acrilan is a completely synthetic material. As such, it cannot support mildew or other plant growth. However, mildew can form on the organic material that lands

on the awning over a period of time, such as pollen and plant spores, grain dust and other airborne plant material. Although this mildew will not damage fabric structurally, the resulting stain is unattractive and extremely difficult to remove. To reduce the chances of this type of stain formation, keep your awning as clean and dry as possible, hosing it down frequently between seasonal washing.

WATER LEAKS

The awning seams are stitched and the Acrilan weave will normally re-form around the needle holes to seal them. Depending on how much you use the awning, this process may take a bit longer in some cases. If so, apply a commercial seam sealer (available from canvas or trailer suppliers) or plain paraffin wax to the top of the seams.

If the body of the fabric seems to lose its water repellency after a time (this can be caused by harsh industrial atmosphere or strong cleaning agents) you can restore it with a commercial water-repellent such as Gard, Scotch Guard or Rain Check, which are locally available. However, soap or chemical residues can "wet" the fabric so that it only appears unable to repel water in some spots. So, before you renew the fabric, rinse it thoroughly and test the water-repellency again after it is dry.

Although your Zip-Dee awning requires less maintenance than an ordinary awning, a little care will keep it in top shape. At the end of each season, check and tighten any loose bolts or screws. Replace missing parts with factory-replacements only.

Ensure continued ease of operation and prevent corrosion by cleaning all accessible hardware with alcohol and protect with a coating of auto wax. Use a spray silicone lubricant for inaccessible places. Extend the main and spring arms as far as possible to wipe off sand and dirt that can clog and score the aluminum.

Avoid leaving the awning open during storms or sudden gusts of wind to prevent damaging the arms.



INSTANT HOT WATER HEATER

The instant hot water heater is installed on the left side of the galley sink, as shown in figure 1. The unit includes a 120-volt ac 2-quart electric under-cabinet water heater and push-lever operated faucet. Power to the heater is supplied via the circuit-breaker panel in the rear closet.

User-maintenance is not recommended; refer repairs to an authorized service center.




Figure 1. Instant Hot Water Heater



ICE-MAKER

The ice-maker, figure 1, is designed to provide a continuous automatic supply of ice cubes. It will operate unattended providing that the water supply line is open and the ac power is applied to the unit.

OPERATION

The power on-off switch is located on the front grillework. When the ice cube supply is full, the ice-making mechanism shuts off automatically. However, the refrigeration system continues to operate to prevent the prepared ice cubes from melting. When removing cubes, do not use a sharp instrument to separate the cubes that are frozen together or the interior may be damaged.

Note that the ice-maker may supply small cubes the first time that it is used. This is due to accumulated air in the water line and subsequent batches will be normal-sized;

If the machine is used only intermittently, empty the ice periodically (every week to 10 days) to ensure a fresh supply of cubes.

Do not clean the cabinet interior with solvent-type cleaners, abrasives, or other cleaners that might cause ice cubes to acquire a bad taste. The exterior should be cleaned with a furniture-type cleaner/polish. Clean condenser (behind grille) with a blower/vacuum at least 3 to 4 times each year, depending on usage.

SHUTDOWN — To shutdown the ice-maker, set power switch to off, shut off the water supply to




Figure 1. Ice-Maker

the unit and remove all cubes. Leave the door slightly ajar for ventilation to avoid mold or odors.

MAINTENANCE

Other than periodic cleaning of grillework, condenser and interior, no other maintenance procedures are required. Refer to table 1 for a general guide to ice-make troubleshooting; equipment repairs should be accomplished by a qualified repair facility.

Table 1. Ice-Maker Troubleshooting Guide

Symptom	Possible Cause	Corrective Action
Water in bucket.	Machine is not level, water runs out of freezing mold into storage compartment or bucket.	Level ice-maker.
	Poor gasket seal, or door is slightly ajar because bucket is not pushed in far enough.	Correct gasket seal; remove obstruction.



Table 1. Ice-Maker Troubleshooting Guide (continued)

Symptom	Possible Cause	Corrective Action
Ice sticks together.	Unit is not leveled.	Level unit properly.
	Faulty door seal.	Correct/replace door seal.
Defrosting occurs too often; or cubes frosty on surface.	Faulty door seal.	Correct/replace door seal.
	Chemical content of water differs in each locality, therefore, freezing point of ice differs.	Lower freezing temperature by turning temperature control(in rear of cabinet) one-quarter to one-half turn clockwise. Reverse procedure for a warmer setting.
Ice-maker freezes up.	Faulty door seal.	Correct/replace door seal.
	Water splashing out of ice-maker mold into storage compartment or bucket.	Remove excess water.
	Ejector blades are frozen-in and cannot eject cubes.	Defrost unit thoroughly.
	Switch in unit compartment may be set "off". Also, Check power supply wiring.	Check switch; check electrical connections.
Ice-maker does not produce ice cubes.	Water supply is turned off.	Restore water supply.
	Unit is not installed level, but is tilted backwards, creating a frost buildup on the suction line.	Level unit properly.
Ice is too soft and wet.	Control setting too warm.	Adjust control to colder setting.
	Door not closing fully.	Correct/replace door gasket.
	Bucket is out too far.	Reposition bucket.
	Air blocked from grille.	Remove obstruction.
Ice-maker produces cubes continuously.	Shut-off arm switch is frozen in ice.	Remove cubes and defrost unit until arm moves freely.
Insufficient cube supply.	Control setting too cold.	Adjust control to warmer setting.
	Ice-maker not level.	Level unit properly.
	Dirty condenser coil.	Clean coil.



Table 1. Ice-Maker Troubleshooting Guide (continued)

Symptom	Possible Cause	Corrective Action
Ice cube supply cloudy.	This is due to air being trapped in the water due to fast-freezing. This is not harmful.	None required.
Too much water entering.	Water valve switch is not adjusted properly.	Remove front cover and adjust screw.
Ejector blades frozen in cubes.	Too much water entering.	Adjust water valve switch. Remove front cover and adjust screw.
	Machine received a "double shot" of water; or cubes piled too high melted back into freezing tray.	Shut off machine for one hour.
Ice-maker won't eject cubes.	Ejector blades frozen into ice maker mold.	Defrost unit and remove some water from freezing tray.
	Too much water entering.	Adjust water valve switch.
Compressor inoperative.	No supply voltage to unit.	Check for ac supply; reset circuit breaker.
	Unit is switched off.	Set switch behind front grille to ON.
Intermittent operation.	Improper door seal.	Adjust hinges, realign door, or shim door gasket where required.
Noisy compressor.	Machine is not level.	Level unit properly.
Compressor runs continuously.	Control set too cold.	Use a warmer setting.
	Obstructed front grille.	Remove obstruction.
	Dirty condenser.	Clean condenser.



INTERCOM SYSTEM

A three-station master-to-master intercommunication system links the driver, dinette and bedroom areas.

As shown in figure 1, each telephone-type handset includes two pushbutton station selectors, which may be depressed to contact one of the other stations with a beep-alert.




Figure 1. Typical Intercom Unit



MOTOR GENERATOR

The motor generator is designed for unattended operation and is located in the right front storage compartment. Unlike a dc-to-ac inverter, which electronically changes the dc battery voltage to an ac line voltage, the motor generator includes a dc motor which generates an ac output in the same manner as commercial electricity is produced.

Because of this, the ac output is completely isolated from the dc source. The stabilized ac output is used to operate the optional ice-maker, when this unit is used in the coach. Both the motor generator and the ice-maker are offered as separate options.

User maintenance of this equipment is not recommended.



SCREEN PORCH

The screen porch is designed to be attached to the Zip-Dee awning. Refer to the installation sequence illustration, figure 1, and proceed as follows:

1. Attach coach skirt to coach, figure A.
2. Fill "aqua-bag" of coach skirt with a garden hose, figure B.
3. Assemble 3-piece spring pole, figure C.
4. Insert spring pole into side panel pocket, figure D.
5. Wedge spring pole inside and under front

section of open awning to set panel in place, as shown in figure E.

6. Snap side panel to coach, figure F.
7. Fill side panel "aqua-bag" with water, figure G.
8. Check that side panels are properly positioned, figure H.
9. Insert front panel cable and eye hook through spring pole and elastic. Tighten front and rear knobs for proper tension, figure I.
10. Lock zippers of front and side panels, figure J.
11. Fill front "aqua-bag" to complete installation, figure K.




Figure 1. Screen Porch Installation Sequence



MICROWAVE OVEN

The microwave oven provides programmed microwave cooking and conventional "browning".

Cooking with microwaves is considerable different than cooking with a conventional oven. Do not use conventional metal pots or pans (frozen dinners may be cooked directly in the shallow aluminum tins, no more than 7/8-inch high). Use glass, ceramic, china, plastic or paper containers;

these are transparent to microwaves and allow food to heat quickly. Interior spatters, soiling or condensation are easily cleaned with a damp rag.

All operating controls and indicators are provided on a keyboard-type control panel, as shown in figure 1. All control cycles — microwaving, browning, temperature-monitoring, cycle timing — are selected by operating switches on this panel. Use figure 1, on the reverse side of this page, as an operational guide to microwave oven operation.




Figure 1. Microwave Oven Operation Guide