



# Table of Contents

## Section I — Introduction

Contents	1-1
Checklists	1-2
Citizen's Band Transceiver	1-3
Hot Weather Operation	1-3
Cold Weather Operation	1-3
Campground Courtesy	1-4
Insurance	1-4
Safety Considerations	1-4
Vehicle Loading	1-6
Economical Driving	1-7
Engine Operating Hints	1-7
Lubrication and Maintenance	1-7
Traveling in Your Motorhome	1-7

## Section II — Operation

Instrumentation	2-1
Lower Dash	2-3
Pilot's Area Overhead Dash and Radio Panel	2-7
Pilot's Left Overhead Control Panel	2-9
Co-Pilot's Area Overhead Dash	2-9
Leveling Jacks Controls	2-10
Steering Column Area	2-12
Floor Controls	2-12
Transmission Gear Selector Console	2-13
Air Suspension System	2-13
Radar Detector	2-14
Seat Controls	2-15
AM/FM Stereo Tuner/Cassette Player	2-16
Closed-Circuit TV/Receiver System	2-20
TV Antenna and Rotator System	2-21
CB Transceiver Unit	2-22
Digitell Monitor	2-24
Diesel Engine/Transmission Operation	2-24
To Start Engine	2-24
To Stop Engine	2-24
Using the Jacobs Drive-Line Retarder	2-25
Trailer Hitch Capacity	2-25
Towing	2-25
Transmission Operation	2-25
Driving Tips	2-25
Accelerator Control	2-25
Downshift Control	2-25
Transmission Oil Temperature	2-25
General Information — Caterpillar 3208 Engines	2-26
Racor Fuel Filter	2-26

## Section III — Living Area Facilities

Sofa	3-1
Vacuum Cleaner	3-1
Dinette Area	3-1
Galley Facilities	3-1
Refrigerator	3-2
Gas Range and Oven	3-4
Galley Sink	3-4
Food Center	3-5
Toaster	3-5
Bathroom	3-5
Roof Vents and Exhaust Fans	3-6
Heating Systems	3-7
Central Air Conditioning Systems	3-9
Systems Monitoring and Control Panel	3-10
LP Gas Leakage Detector	3-14
Electronic Door Chime	3-14
Portable Fan	3-14
Security Timer	3-15
Burglar Alarm/Anti-Theft Features	3-15
Fire Extinguisher	3-15
Intercom System	3-15
Stepwell Area	3-16
Smoke Detector	3-16

## Section IV — Electrical Systems

12-Volt DC Supply System	4-1
Battery Heaters	4-1
Battery Chargers	4-1
DC Supply Monitors	4-2
AC Supply System	4-2
Power Line Monitor	4-2
AC Circuit Breaker Panels	4-2
Generator Operation	4-3
Shoreline Operation (Commercial Power)	4-4
Shoreline Operation—Troubleshooting	4-5
Safeline Alarm	4-5
Electronic Filter	4-5
Electronic Master Switch	4-5
Battery Jumper Terminals	4-5

## Section V — Water Distribution and Drainage Systems

Water Supply and Distribution System	5-1
Commercial Water Hookup	5-1
Filling and Sanitizing	5-1
Potable Water Distribution System	5-2
Water Pump	5-2
Water Purifier	5-3
Water Heater	5-3



Drainage System	5-3
Draining the Holding Tanks	5-3
Tank Level Detectors	5-4
Winterizing	5-4
Draining and Winterizing the Fresh Water Supply System	5-4
Draining the Ice-Maker	5-5
Battery Storage in Freezing Weather	5-5
General Storage Notes	5-5

## Section VI — LPG System

LPG Tank and Controls	6-1
Fuel Requirements	6-1
Filling the LP Gas Tank	6-2
LP Gas and Vapor Detectors	6-2
Regulator Pressure	6-2
Operation	6-2
Checking for Leaks	6-2
LPG Consumption	6-3
LPG System Warnings	6-3

## Section VII — Air Brake Systems

Operation	7-1
Brake Failures	7-1
Additional Air Operated Equipment	7-1
Compressed Air System Air Dryer	7-2

## Section VIII — Owner Maintenance Data

Specifications and Data	8-1
Changing Wheels/Tires	8-4
Using the Optional Mountz Power Wrench	8-5
Battery Maintenance	8-6
Periodic Battery Checks and Maintenance	8-6
Exterior Care	8-6
Interior Care	8-6
Fluid Level Checks	8-6
Crankcase Oil Level	8-6
Power Steering Reservoir Fluid Level	8-7
Transmission Fluid Level	8-7
Importance of Proper Oil Level	8-7
Oil Check Procedure	8-7
Hot Check	8-7
Cold Check	8-7
Racor Filter and Water Separator System	8-7
Filter/Separator Operation	8-7
In-Filter Fuel Heater	8-8
Water-In-Filter Alarm	8-8
Maintenance	8-8

Leveling Jacks Reservoir	8-9
Engine Cooling System Refill	8-9
Cooling System Additives	8-10
Windshield Washers	8-10
Battery Jumper Terminals and Jump-Starting	8-10
Generator	8-10
Maintenance Schedules	8-10
Generator Troubleshooting	8-13
Generator Overloads	8-13
Generator Battery Charging	8-13
Storage Procedures	8-13
Refrigerator	8-13
The Electrode-General	8-14
Air Conditioning Systems	8-15
Toilet	8-15
Water Pump	8-15
Clock/Thermometer Calibration Procedures	8-16
Thermometer Calibration Procedures	8-16
Motor Generator (Redi-Line)	8-16
Tub/Shower Mixing Valve	8-17

## Section IX — General Information Equipment Manufacturers

## Section X — Diagrams

## Section XI — Equipment Options

Awnings	11-1
Open Awning	11-1
Close Awning	11-2
Fabric Care	11-2
Washing	11-2
Water Leaks	11-2
Storm Precautions	11-3
Hardware and Mechanism Maintenance	11-3
At the End of Each Season	11-3
Ice-Maker	11-3
Ice-Maker Operation	11-3
Ice-Maker Maintenance	11-4
Winterizing	11-4
Microwave/Convection Oven	11-4
Caution Notes	11-4
To Set the Clock	11-6
Microwave Cooking	11-6
Microwave Utensils	11-6
Convection Cooking	11-6
Convection Utensils	11-7
Mountz Power Wrench	11-7
Konstant Hot Water Dispenser	11-7



Kool-O-Matic Ventilation Fan .....	11-7
Operation .....	11-7
Redi-Line Motor Generator .....	11-7





# List of Illustrations

Fig. No.	Title	
1-1	Federal Certification Label	1-6
1-2	Typical Identification Plate	1-6
2-1	Pilot/Co-Pilot Compartment	2-1
2-2	Lower Dash	2-2
2-3	"The Horn"	2-5
2-4	Pilot's Area Overhead Dash and Radio Panel	2-7
2-5	Digital Clock/Elapsed Time Display	2-8
2-6	Pilot's Left Overhead Control Panel	2-9
2-7	Co-Pilot's Area Overhead Dash	2-10
2-8	Leveling Jack Controls	2-11
2-9	Steering Column Area Controls	2-12
2-10	Transmission Gear Selector Console	2-13
2-11	Radar Detector	2-14
2-12	Seat Controls	2-15
2-13	AM/FM Stereo Tuner/Cassette Player	2-16
2-14	CCTV Camera Port	2-20
2-15	TV Controls	2-21
2-16	Picture Control Panel	2-21
2-17	Extendable TV Antenna Radome	2-21
2-18	Antenna Control Panel	2-21
2-19	CB Transceiver Unit	2-22
3-1	Vacuum Cleaner System	3-1
3-2	Dinette Area	3-1
3-3	Galley Facilities	3-2
3-4	Refrigerator Operating Controls	3-2
3-5	Gas Range and Oven	3-4
3-6	Food Center	3-5
3-7	Shower Stall	3-5
3-8	Toilet	3-6
3-9	Hallway Lighted Vent/Exhaust Fan	3-6
3-10	Exhaust Fan Control Panel	3-6
3-11	Bathroom Vent/Exhaust Fan	3-6
3-12	Heater Thermostat	3-7
3-13	Air Conditioner Controls	3-10
3-14	Systems Monitoring and Control Panel	3-10
3-15	The Thermometer and The Clock	3-10
3-16	Tank Monitor Panel	3-11
3-17	Gas/Smoke Alarm	3-11
3-18	AC Voltage Monitor	3-12
3-19	Waste Odor Control Panel	3-12
3-20	Digitell Control Center	3-12
3-21	Generator Switch	3-13
3-22	Switch and Monitor Panel	3-13
3-23	LP Gas Leakage Detector	3-14
3-24	Electronic Door Chime	3-14
3-25	Portable Oscillating Fan	3-15
3-26	Security Timer	3-15
3-27	Intercom System	3-16
4-1	Typical Load Center	4-1
4-2	Battery Compartment	4-1
4-3	Stepwell Compartment	4-2
4-4	Load Center Circuit Breakers	4-3
4-5	30A. Shoreline Circuit Breakers	4-3
4-6	Generator Tray	4-3
5-1	Location of Commercial Water Hookup	5-1
5-2	Water Purge Air Pressure, Water Heater Drain and Water Tank Drain Controls	5-2
5-3	Water Pump Location	5-3
5-4	Location of Holding Tanks Drain Valve	5-4
5-5	Lavatory Plumbing	5-4
6-1	LPG Tank Compartment	6-1
6-2	LPG Low Pressure Distribution	6-2
8-1	Locating Jack	8-4
8-2	Lug Nut Tightening Pattern	8-5
8-3	Mountz Power Wrench	8-5
8-4	Racor Filter/Separator	8-8
8-5	Generator Unit, Tray Extended	8-11
8-6	Generator Air Cleaner	8-12
8-7	Refrigerator Gas Burner	8-14
8-8	Tub/Shower Mixing Valve	8-17
10-1	Chassis and Water Heater Circuits	
10-2	12-Volt Diagram, Lower Front Load Center	
10-3	12-Volt Diagram, Overhead Front Load Center	
10-4	12-Volt Diagram, Left Front Load Center	
10-5	12-Volt Diagram, Right Front Load Center	
10-6	12-Volt Diagram, Left Rear Load Center	
10-7	12-Volt Diagram, Right Rear Load Center	
10-8	12-Volt Diagram, Batteries and Charging Circuits	
10-9	Potable Water System	
10-10	Drainage System	
10-11	Liquid Petroleum Gas System	
10-12	Air System (sheet one)	
10-12	Air System (sheet two)	
10-13	Chassis Lubrication Guide	
11-1	Awning Opening Procedure	11-1
11-2	Awning Opening Procedure	11-1



11-3	Awning Opening Procedure	11-1
11-4	Awning Opening Procedure	11-2
11-5	Ice-Maker Details	11-4
11-6	Microwave/Convection Oven Control Panel	11-5



## List of Tables

<b>Table No.</b>	<b>Title</b>	
4-1	Electrical Ratings for Motorhome Appliances .....	4-4
8-1	Engine and Chassis Specifications ...	8-1
8-2	Engine/Chassis Capacities .....	8-1
8-3	Generator Capacities and Specifications .....	8-1
8-4	Motorhome Capacities and Specifications .....	8-2
8-5	Maintenance Schedule Summary .....	8-2
8-6	12-Volt Light Equipment, and Fuses, Current Usage .....	8-3
8-7	Generator Maintenance Schedule ...	8-10
8-8	Anti-Freeze Protection Chart .....	8-13
8-9	Water Pump Troubleshooting Guide .	8-15







# Section I

## Introduction

This section of your Owner's Manual contains general hints and recommendations for using your motorhome. Checklists and suggestions are offered which cover just about every phase of motorhome travel.

The remaining sections of this manual, Sections II through XI, describe in detail the operation and use of the individual items and systems which comprise your motorhome. The following paragraphs summarize the contents of these sections:

**Section II Operation** — Covers driver's instrumentation, operating controls, gauges and indicators.

General data on operation of coach vehicular systems are also covered in this section.

**Section III Living Area Facilities** — Covers operation of heating and air conditioning systems, use of accessories and appliances and related general coach facilities data.

**Section IV Electrical Systems** — This section describes operation of coach electrical systems; ac/dc operation and generator switching are also covered.

**Section V Water Distribution and Drainage Systems** — Covers internal supply and distribution, plumbing, city water hookups, tank fill and sanitizing, holding tank dumping and operation of hot water supply system.

**Section VI LPG System** — This section describes LPG internal supply and distribution, tank filling procedures, system component locations, and precautions to observe regarding LPG handling.

**Section VII Air Brake Systems** — This section covers operation of the service brakes and spring brake systems, fail/safe features and general brakes system operation.

**Section VIII Owner Maintenance Data** —

Includes information on maintenance procedures which may be within the scope of the owner. Coverage is provided for preventive maintenance schedules, specifications and system capacities, cold weather operation, storage and winterizing.

Interior/exterior appearance care and emergency maintenance procedures are also described.

**Section IX General Information** — A list of major components, including model numbers, name and address of manufacturer.

**Section X Diagrams** — Contains wiring, schematic, piping and general-purpose diagrams to assist in troubleshooting and understanding how these systems function.

**Section XI Optional Equipment** — This section provides you with information on optional equipment and features used in your motorhome.

We hope that this manual will help answer any questions that may arise about the use, operation and maintenance of your motorhome. Any suggestions or recommendations that you might have for including or expanding on material of interest will be carefully considered for incorporation in periodic supplements. We are always interested in providing our coach owners with the most current and comprehensive information about our product.

Your satisfaction is our assurance that we are fulfilling our responsibilities to our owners.



## Checklists

A little preliminary planning will go a long way to help make your trips successful and enjoyable. As an aid to planning your travels, review the following checklists. If there are any additional items that you should be reminded of, add them where you see fit. These lists are only recommendations based on the experience and suggestions of sources well-versed in motor-coach expertise. You will eventually find that a short "walk-around" the coach, outside and inside, will be adequate and comprehensive enough to ensure that you're ready for travel.

### Before You Leave:

- Store valuables and important papers in a safe place.
- Arrange care for your pets.
- Cover all food to keep out mice and insects.
- Store oil, gasoline, matches and other inflammables properly; get rid of newspapers, magazines and oily rags.
- Connect timers to several inside lamps and outside lights; keep some shades open for a lived-in look.
- Discontinue newspaper, milk and other deliveries; store trash cans and outside equipment.
- If weather permits, shut down hot water and heating systems; close main water supply.
- Ask the Post Office to hold your mail.
- Have your lawn, garden and house plants cared for.
- Arrange with the Telephone Company for discontinued or "Vacation Service".
- Lock all windows and doors securely.
- Leave your key with your neighbor; let him know your basic itinerary.
- Notify police.

### Checkout Your Coach — Outside:

- Disconnect and stow:
  1. Electrical cord.
  2. Sewer hose (flush out)
  3. Water hose.
- Check all exterior lights for damage.
- Check wheel lug nuts for tightness. (450-500 ft.-lb.)
- Check tires for correct pressure. (See Table 8-1).
- Check that all external compartments and filler openings are properly closed and/or locked.

- Check that items stored on exterior of coach are secured. (Be sure that these items present no clearance problems.)

## Note

**If the trip you are planning will take the coach well past suggested maintenance intervals listed in Section VIII, it may be advisable to perform these procedures before leaving. This may avoid unscheduled stops or interruptions during your trip.**

- Check that there are no obstacles to avoid above or under the coach. Be sure that there is sufficient clearance front and rear.

### Checkout Your Coach — Inside:

- Turn off water pump switches.
- Close windows and vents.
- Check that cabinet doors and drawers are secured.
- Check that refrigerator door latch is in locked position.
- Check that no heavy item is stored in an overhead cabinet.
- Store large items in base cabinets.
- Check that counter tops, range top, table tops and shelves are clear of unsecured items.
- Turn off interior lights; check that entrance step is retracted.
- Secure and lock the entrance door.
- Adjust exterior and interior mirrors.

### Check Your Automotive Systems:

- Check that fluid levels are normal (oil, power steering, engine coolant, battery electrolyte, windshield washers, transmission, etc.).
- Check generator oil level, coolant level, battery condition.
- Check operation of turn signals, emergency flasher, stoplights and backup lights.
- Check that headlight high- and low-beams operate.
- Check horn operation.
- Check fuel gauge, and top up fuel tank.
- Start engine and check gauges for signs of trouble.
- Check operation of foot brakes, emergency brake. (See that brake pressure builds up and steadies at about 100 to 120 psi.)



### **And, Before Driving Away:**

- Check operation of appliances and special equipment.
- Check that fire extinguishers are fully charged.
- Check operation of interior and exterior lighting.
- Start generator and check 120v ac system and wall outlets.
- Adjust driver's seat so that all controls are within easy reach.
- Make sure that seat is locked in position. Do not adjust driver's seat swivel or foreaft mechanism while vehicle is moving or seat could move unexpectedly, causing a loss of control.
- Check that front passenger's seat is locked in position.
- Fasten seat belts. Belts should be placed as low as possible around the hips. This places the load of the body on the strong hip bone structure instead of around the soft abdominal area and prevents sliding out in case of an accident.
- Check that warning lights are lit when the ignition key is turned to **on** or **start** position.

### **Some Items You Might Want to Take Along On Your Trip**

#### **Note**

**You may find that many items taken were not needed and that some items that were needed were overlooked during planning of your last trip. Make notes of these items to prevent duplicating the same errors.**

- Adequate supply of prescription medicines.
- Prescription sunglasses or reading glasses.
- Camera equipment and film supply.
- Heating pads, ice bags, etc.
- Stationery, envelopes, stamps.
- Telephone number list.
- Reading material.
- Special pet supplies.
- Extra toilet chemical and toilet articles.
- Spare belts for engine-operated equipment.
- Spare parts for generator: suggested spares include oil filter, fuel pump, air filter, solenoid. Five quarts of approved motor oil.
- A professional-type double-action tire pressure gauge.
- Under the heading of **Emergency Equipment**, it is advisable to consider outfitting your coach with these items:

1. First aid-kit
2. Emergency highway flares
3. Flashlight or lantern (with extra batteries)
4. Tool kit
5. Replacement lamp assortment
6. Replacement fuse assortment
7. A trouble light with a long cord

### **And Some Other Thoughts To Consider**

- Automobile insurance to cover you and your family.
- Avoid cash. Use traveler's checks and credit cards wherever possible.
- Confirm reservations well in advance of arrival.
- Make a clothing check list for everyone.

### **Citizen's Band Transceiver**

You might also bear in mind that your coach is equipped with a CB unit (Citizen's Band receiver-transmitter). In the event of an emergency situation which requires outside assistance, remember to call for help on Channel 9. This channel is restricted to emergency use only and it is monitored 24 hours per day! Don't hesitate to use your CB if you see someone else in need of assistance. Remember that you will need a Canadian license to operate your CB radio during your travels in Canada.

### **Hot Weather Operation**

Wherever possible, choose a shaded parking site so that the coach will be cooler during the hottest part of the day. The full-length side awning will be especially useful in lowering inside temperature. Air conditioning units are indispensable in hot climates. Keep in mind that their proper operation depends on adequate line voltage. Low voltage causes motors to run hotter and reduces compressor motor life. Supply voltage in some campgrounds may not be as high as necessary, especially when there are heavy loads on the lines from other air conditioners. Check the wall-mounted monitors when in doubt.

### **Cold Weather Operation**

LPG appliances, furnace, and gas refrigerator are designed with sealed combustion areas. This is for your protection to prevent danger from carbon monoxide or depletion of oxygen. Your motorhome is equipped with a highly accurate and sensitive gas/smoke alarm. Heed alarm indications!



If frost or condensation accumulates in closets or cabinets during long periods of cold weather operation, leave the doors to these areas slightly ajar to provide air circulation. Be sure that roof vents are open when using oven or burners.

### **Campground Courtesy**

Don't forget the "Golden Rule". Being considerate of your neighbors will help make friends. A few of the "Do's" and "Don'ts" are:

- Good housekeeping — put all litter in the proper receptacles and leave your site neat and clean.
- Don't allow your water or sewer hook-ups to leak.
- Respect your neighbor's desire to retire at an early hour. Avoid loud noises and bright lights after dark.
- Drive slowly through camp areas at any hour for the safety of pedestrians.

### **Insurance**

As with your automobile, it is important that you have adequate protection with insurance coverages for personal liability, theft, collision, overturn, property damage, etc.

### **Canadian and Mexican Insurance**

Insurance for travel in Canada can usually be covered by your present U.S. policy for the recreational vehicle, often at no extra cost. Consult your individual company for procedures and be sure of your coverage before entry.

For travel in Mexico (at the present time) there are no U.S. insurance companies that can provide recognized Mexican coverage, with the exception of that required for travel through a narrow strip of Mexican territory in and around ports of entry and the U.S./Mexican border.

Mexican insurance is controlled, and rates are set, by the Mexican government. There are several reliable companies handling Mexican insurance, with similar rates for the necessary coverages. The principal differences between them are the "fringe benefits", received in the form of informational travelogs and other helpful information, such as dining places considered acceptable for sanitary conditions, fuel stations, and so on.

Some insurance services include detailed route maps with "where to stay" recommendations and "things to see" mile-by-mile (or kilometer-by-

kilometer post). While the rates set by Mexico may seem quite expensive at first glance, you usually end up not spending quite as much as expected because you can usually arrange to hold your state-side policy in abeyance during the same period you are in Mexico, thus not having to pay unnecessarily for double coverage. In addition, you may be able to obtain substantial refunds on the Mexican collision insurance after your return to the U.S. Be sure to obtain a certification from the park operator at each location in Mexico to certify the dates that your coach was parked there. If your coach is parked for most of the time, instead of constantly traveling, your refund may be a major portion of the original cost. This feature is referred to as the "in-storage" credit. (It is a good idea to always check with your insurance company before taking a trip to find out whether applicable insurance rules and regulations have changed. Keep up to date on your coverage.)

Carry insurance papers at all times!

### **Safety Considerations**

#### **Using LP Gas**

Check for leaks at the connections on the LP gas system soon after purchase and initial filling of LP tank; continued periodic checks of the system are recommended. Even though the manufacturer and dealer have already made tests for leakage, this check is advisable because of the vibrations encountered during travel. Apply a soapy water solution to the outside of gas piping connections to find gas leakage (bubbles). Usually, tightening of connections will close leaks. (Be sure to first shut off the gas supply!) If not, ask your authorized dealer service to make the needed repairs.

Liquified Petroleum Gas (LPG) is heavier than air. Leaking gas tends to flow to low places, such as does water. It will sometimes pocket in a low area. LP gas can usually be detected by an identifiable odor characteristic to onions or garlic.

### **Caution**

**Never light a match or allow any open flame in the presence of leaking gas!**

Be sure that the main LP gas supply valve is closed during refueling to prevent accidental ignition of gas fumes by appliance pilot lights.

Your Wanderlodge® has been provided with an



automatic 80% fill valve to protect you from the dangers of an overfilled LPG tank.

### Electrical Systems

Your coach has been engineered and checked for your complete electrical system safety. Circuit breakers and fuses are installed to protect electrical circuits from overloading. Before making modifications or additions to the electrical system, consult your dealer for assistance in obtaining a safe and secure installation.

Do not "jump" circuit protectors!

### Built-In Power Cord Adapter

Approved power supply cords supplied with the coach for hookup to external power sources are listed below:

- 50A female to 50A male (1)
- 50A female to 30A male (1)
- 30A female to 30A male (2)
- 30A female to 30A male extension(2)
- 30A female to 20A male adapter (2)

Note that each cord has a ground pin which provides proper electrical system grounding. The ground pin is your personal protection from electrical shock hazards. Do not use any adapter, cheater, or extension cord that will break the continuity of the grounding circuit. **Never** remove the grounding pin for convenience of being able to make a connection to a non-grounded receptacle!

The power cord adapter allows connection of two 30-ampere 120-volt lines (from separate external circuits) to the shoreline plug in the rear of your coach. This will permit use of all motorhome appliances without overloading the supply lines.

**Never** operate your coach with a "hot skin"! If you can feel even a slight "tingling" shock from touching the coach body while standing outside on the ground, immediately disconnect the electrical hookup until the trouble is located. This fault is usually caused by a break in the grounding circuit, which should be continuous from the coach skin or frame to the distribution panel board to the third (ground) pin on the power supply cord, and from there to the park receptacle and earth ground. Your motorhome is equipped with dual polarity-protector monitor panels, located on the dinette wall. These panels are for your protection in ensuring against improper grounding or reversed hookups.

### Emergency Stops

Always carry road flares and/or reflective triangular highway warning markers for emergency warning display. Pull off the roadway as far as possible when changing flats or for other emergency situations. Turn on your hazard warning flashers when parked alongside a roadway, even if only for a short while. Have your coach occupants leave the vehicle and stand clear of the area when parked on the edge of a highway.

### Engine Exhaust Gas

Avoid inhaling exhaust gases because they contain carbon monoxide, which by itself is colorless and odorless. Carbon monoxide is a dangerous gas that can cause unconsciousness and is potentially lethal. If at any time you suspect that any exhaust fumes are entering the passenger compartment, have the cause determined and corrected as soon as possible.

The best protection against carbon monoxide entry into the vehicle body is a properly maintained engine exhaust system, body and ventilation system. It is a good practice to have the exhaust system and body inspected by a competent mechanic each time the vehicle is raised for lubrication or oil change. It should also be inspected whenever a change is noticed in the sound of the exhaust system and if the exhaust system, underbody or rear of the vehicle has been damaged.

To allow proper operation of the vehicle's ventilation system, keep ventilation inlets clear of snow, leaves, or other obstructions.

Sitting in a parked vehicle with the engine on for extended periods, without proper ventilation, is not recommended!

### More Safety Considerations

- Sanitize fresh water supply system periodically. See Section V.
- Prevent water connection fittings from contacting the ground or drain hose to reduce chances of contamination.
- Consider using a qualified technician for repairing gas or electrical appliances.
- Check fire extinguishers periodically for proper charge.
- Avoid overloading your vehicle.
- Be careful not to cause an improper load distri-



tribution which can adversely affect roadability.

- Insure that tires are in good condition and properly inflated at all times. Under-inflated tires overheat and are blowout-prone!
- Check and tighten wheel lug nuts every 1,000 miles (torque to 450-475 ft-lbs.)
- Check brake operation in a safe area — not while traveling on a busy highway!
- Use seat belts!

### Emergency Exits

Sliding windows, which can be easily opened, may be used as an emergency exit. Squeeze the screen latch and slide it to the rear enough for access to the window latch. Squeeze the window latch and slide window open. Emergency exit windows are identified by an EXIT decal on the glass.

### Vehicle Loading

#### Weight Distribution and Load Rating

The Federal Certification Label, located inside and above the drivers windshield between the sunvisor mounting brackets describes the maximum weight-carrying capacities of your motorhome and for each axle, respectively abbreviated by "GVWR" and "GAWR". A typical identification plate is shown in figure 1-1.

Generally, a 31-foot unit will weigh about 25,500 pounds; a 33-foot unit will weigh about 26,500 pounds; and a 35-foot unit will weigh about 28,000 pounds. If optional equipment is installed, add the weight of these items to determine the total weight.

The load capacity is the difference between the GVWR and the actual weight. This means the total weight of all food, clothing, other supplies and passengers, must not exceed the load capacity.

To find the actual weight, with the motorhome fully loaded, drive to a scale and read the weight on the front and on the rear wheels, separately, to determine axle loading. The load on each axle should not exceed its GAWR. If weight ratings are exceeded, move or remove items to bring all weights below the ratings.

Additional data plates located on the back of the stepwell compartment door provide information useful for identifying your coach if you are planning on ordering parts. Identification plates, figure 1-2, provide information such as:

1. Body Serial Number
2. Chassis Serial Number
3. Model Year
4. Model Number of Axle (if axle parts are to be ordered)




Figure 1-1. Federal Certification Label

The Gross Vehicle Weight Rating (GVWR) is the maximum motorhome weight allowable with all systems filled and with passengers and supplies aboard.

Each axle also has a maximum load-bearing capacity referred to as the Gross Axle Weight Rating (GAWR).

A typical motorhome rating might be as follows:

GVWR .....	34,000 lbs
GAWR (front) .....	13,200 lbs
GAWR (rear) .....	23,000 lbs




Figure 1-2. Identification Plates

When loading your motorhome, store heavy gear first, keeping it on or as close to the floor as possible. Heavy items should be stored centrally so as to distribute the weight more or less evenly between the front and the rear axles. Store only light objects on high shelves. Distribute weight to obtain even side-to-side balance of the loaded unit. Secure loose items to prevent weight shifts that could adversely affect the balance and roadability of the vehicle.



## **Economical Driving**

How you drive, where you drive and when you drive — these factors all have an effect on determining how many miles you can get from a gallon of fuel. The careful attention you give your vehicle, as far as maintenance and repairs are concerned, will also contribute to fuel economy.

## **Engine Operating Hints**

It is recommended that you use Number 2 diesel fuel for your engine. To locate the closest Caterpillar dealer or other authorized repair shop, call toll free (800) 447-4986 except in Illinois call (309) 673-3252.

## **Stop-And-Start Driving**

Frequent stops and starts during a trip diminish miles per gallon. Plan even short shopping trips so you can take advantage of through-streets to avoid the traffic lights. Pace your driving like the professional drivers to avoid unnecessary stops.

## **Excessive Idling**

An idling engine also consumes fuel. If you are faced with more than a few minutes wait, and you are not in traffic, it may be advisable to shut off the engine and re-start later on.

## **Lubrication and Maintenance**

A properly lubricated vehicle means less friction between moving parts. Consult the maintenance schedules in Section VIII for proper lubricants, lubrication intervals and general coach maintenance scheduling.

## **Air Cleaner**

The mixture of fuel and air which powers the engine is taken into the system through the air cleaner. Replace the air cleaner at required intervals to maintain peak engine efficiency.

## **Excess Weight**

Fuel economy is also related directly to the amount of work accomplished by the engine. Heavier loads require more power. Keep excess weight to a minimum.

## **Tire Inflation**

Under-inflation causes needless tire wear and promotes excess fuel consumption. Check tire pressures on a regular basis. (Michelin recommends that front tires be inflated to 115 pounds and rear tires to 110 pounds. These inflation pressures are for "cold" tires.)

## **Traveling in Your Motorhome**

### **Overnight Stops**

There are many modern recreational vehicle parks with good facilities, including State, County and Federal Parks, where electrical, water and sewer connections are readily available. Directories are published which describe these parks in detail and list available services and hookups.

On overnight or short weekend trips, your motorhome has more than adequate holding tanks and water supply capacity in the event that campgrounds or parking sites are not equipped with these facilities.

On longer trips, where sewer connections and utility hookups are unavailable, it will be necessary to stop from time to time to dispose of holding tank wastes and replenish the water supply. Many gas stations (chain and individually-owned) have installed sanitary dumping stations for just this purpose.

When stopping for the night, park the coach in a location that is relatively level and where the ground is firm. This will ensure your comfort as well as the leveling of your refrigerator (for most efficient operation).

### **Extended Stays**

Making a long trip is not very different from making a weekend excursion since everything you need is right at hand and you are home wherever you travel. When packing for an extended trip, try to avoid taking non-essential items.

When planning to stay in the same location for several days, weeks, or even months, be sure to maintain the motorhome level. Use leveling jacks system controls for this purpose.

Hook up to the water supply by attaching the water hose to the commercial water supply inlet.

Plug the electrical cable into the shoreline re-



ceptacle. Be sure to observe all grounding and connection precautions!

Connect sewage hookup into the disposal facility.

### Winter Traveling

Certain precautions should be taken when traveling in your motorhome during the cold winter months. Keep these suggestions in mind:

- Provide heat in the coach at all times.
- Have a plentiful supply of LPG.
- If your stay is longer than overnight, and you do not use the generator, try to have a shoreline hooked up to outside ac power.
- Minimize your use of electricity if 120v ac is unavailable.
- Leave cabinet doors and wardrobe doors slightly open at night to allow for proper air circulation.
- Freeze protection heaters and heat tapes greatly decrease the chances of frozen water lines **provided the coach is plugged into outside power (one 50A. or two 30A. power cords) or the generator is run continuously during cold weather periods.**

Remember that low temperatures in combination with high winds will cause an equivalent chill temperature much below that indicated by your thermometer. For instance, with an outside temperature of zero degrees, and a wind velocity of 10 miles per hour, the equivalent chill temperature would be -20 degrees F!

There is no substitute for common sense when traveling in cold weather.





## Section II Operation

This section provides information on the operation and function of the controls, indicators and gauges located in the pilot/co-pilot compartment that are used in connection with the coach automotive systems. Figure 2-1 illustrates the pilot/co-pilot compartment, high-lighting the instrumentation and panels covered in this section.

### Instrumentation

All essential operating controls and gauges used to monitor and control associated engine, generator and coach systems are located conveniently on and adjacent to the electroluminescent dash panel, figure 2-2.

Associated instrumentation, accessible on the bulkhead above the pilot, includes stereo AM/FM radio/cassette player, TV, generator ON-OFF switch, altimeter and diesel fuel filter monitors. Controls for TV operation are located on the left side bulkhead above the pilot. Refer to figures 2-2 through 2-20 and the following paragraphs for locations and functions of associated operating controls and indicators.



Figure 2-1. Pilot/Co-Pilot Compartment




Figure 2-2. Lower Dash



## Lower Dash

On the previous page, in figure 2-2, the Lower Dash is shown. Each item on the lower dash is identified by an index number which corresponds to the following description. Some items operate at all times, some require the 12 volt master to be on, while others need the 12 volt master and the ignition on.

\*These gauges, require the engine to be at normal operating temperature for correct readings.

① **AUXILIARY STEP** Switch — An **On-Off** switch that, when set to the **EXTENDED** position, activates a relay automatically locking the outside entry step in the out position. The indicator light comes on when the ignition switch is turned on to remind you that you need to retract the step before proceeding.

② **SPEEDOMETER** — Indicates speed and accumulated mileage (odometer). This is a solid-state electronic monitor, with an RPM sensor located at the right drive axle brake drum.

③ **ACCESSORY** Position — These blank positions may be used for the installation of additional switches and indicator lights for customer add on equipment. Also includes items (33), (52), (55), and (60).

## Caution

**Use existing panel holes for installation of additional controls or indicators. Drilling new holes will destroy the electroluminescent features.**

④ **AIR PRESSURE REAR** Gauge &

⑦ **AIR PRESSURE FRONT** Gauge — The Dual Air Service Brake Pressure systems are engine operated and supply independent brake system air pressure for front and rear service brakes and the parking brake. During normal operation, each air pressure gauge reading will build up to 100 psi to 120 psi shortly after the engine is started. Note that, as a safety feature, the parking brake cannot be released until air pressure readings are at least 65 psi.

⑤ \* **TURBO BOOST** Gauge — Registers the psi of the Turbo Compressor outlet. The gauge should read a maximum of 21.5 psi at maximum power.

⑥ **ENTRY DOOR** Switches — Dual momentary switches to lock and unlock the entry door. An indicator next to these switches lights when the entry door is unlocked, if the ignition switch is on.

⑦ \* **ENG. OIL TEMPERATURE** Gauge — Gives a constant reading of the engine oil in the supply line from the pump. The normal operating temperature is from 200 °F to 250°F. If the temperature goes over 250° the engine may be low on oil or there is overheating of the cooling system.

⑧ \* **ENG. OIL PRESSURE** Gauge — Indicates the pressure of the oil, not the amount of oil in the engine reservoir. This gauge will normally read between 40 and 65 psi during cruising speeds; and drop to a minimum of 14 psi when the engine is idling.

## Caution

**No oil pressure, or low oil pressure readings (below 25 psi) when engine is operating at cruising speeds are trouble indications! Do Not Operate the Engine Under These Conditions!**

⑨ **LOW AIR** Warning Indicator — This light is associated with a buzzer. These warn the driver that there is an insufficient supply of air (65 psi or less) to properly operate the coach. If the air pressure is low, when the ignition key is turned on, the light and buzzer will come on immediately. Both warnings will continue until the air pressure is built back up, or the ignition key is turned off.

⑩ **HIGH BEAM** Indicator — Lights when the headlight dimmer floor switch is pressed for High Beam operation and the Headlight switch (43) is on.

⑪ **A/T** Switch — (Anti-Theft) deactivates the starting system for protection against unauthorized cranking and theft.

⑫ **ENGINE ALARM** Indicator — This indicator, along with a Buzzer Alarm, monitors engine operation. If the oil pressure or the coolant level drops too low or if the coolant temperature gets too high, the engine alarm light and buzzer will be activated.

⑬ \* **ENG. WATER TEMPERATURE** Gauge — Normal water temperature should be between 180° and 200°F for safe operation.



## Caution

If the Engine Temperature gauge indicates excessively high temperatures, the engine may be over-heating and should be stopped to prevent damage. Allow the engine to cool before checking the radiator coolant level.

⑭ \* **TRANS. OIL TEMPERATURE** Gauge — Monitors and gives constant temperature readings of the transmission oil. If the gauge registers a temperature over the 300°F maximum safety range, check for low fluid in the transmission.

⑮ **L.H. WIPER** Dual Switches &

⑯ **R.H. WIPER** Dual Switches — The Dual Wiper switches turn the windshield wipers on or off and also control high or low operation. The wipers can be turned on and used individually or both at one time.

⑰ \* **TURBO PYROMETER** — Registers the temperature of the exhaust gas output of the Turbo. The correct temperature of the exhaust should be around 740°F at maximum power.

⑱ **AIR PRESSURE FRONT** Gauge — See item (4).

⑲ **R.H. WIPER** — See item (15).

⑲ **TACHOMETER** — Indicates actual engine RPM (Revolutions Per Minute) when scale (0-40) reading is multiplied by 100. Idle RPM should be 700 and full load (uphill) 2600 RPM.

⑳ **LIGHTER** — Depress to heat the element; pops out when hot.

㉑ **WIPER HEATER** Switch — Activates a heating element built into each wiper blade assembly. These heaters are controlled thermostatically to come on whenever the outside temperature drops below 39°F to help prevent ice build-up. An indicator lamp next to the switch lights whenever power is supplied to the wiper heater thermostat.

㉒ **RIGHT TURN** Indicator — When the turn signal lever, (steering column control section), is pushed up into the right turn position this indicator flashes in conjunction with the outside directional lights. The right cornering light will come on continuously if the headlight switch control has been pulled out to either position while the turn signal lever calls for a right turn.

The indicator, along with the left turn indicator and all outside directional lights, flash in unison when the emergency flasher switch on the steering column is pressed in to the on position.

㉓ **WINDSHIELD WASHER** Switch — When this switch is held on it provides power to the windshield washer pump to spray a steady stream of water in a vertical pattern from a nozzle mounted on each windshield wiper blade arm. Next to this switch is an indicator that lights when windshield washer fluid is low.

㉔ **MIST CONTROL** Switch — When pressed to the **ON** position, will activate the windshield wipers on a delayed time cycle. With both wiper switches **OFF**, press the Mist Control switch to **ON** once and let it return to the center position. This starts the wipers on a 16 second Off-On cycle, meaning that every 16 seconds the windshield wipers will make one sweep across the windshields. To decrease the delay time between cycles press the Mist Control switch to **ON** again, and let it go. This will decrease the delay from 16 seconds to 14 seconds. Each additional time the switch is pressed **ON** will decrease the delay another 2 seconds until the 4 second minimum delay is reached. When the 4 second cycle is reached the next time the Mist Control switch is pressed **ON** it will return the delay cycle to 16 seconds. Anytime during the cycle, when you want to stop the wipers completely, momentarily press the switch to the far right.

㉕ **HEAT** Switch — To turn on the Heater Blower for the co-pilots area press this switch to either the **HI**— or **LOW** position.

㉖ **FRONT HEAT** Switch — Activates a solenoid valve to provide engine coolant flow to the front heater core.

㉗ **HORN SELECTOR** Switch — Allows selection of the air or electric horns when the steering wheel horn button is depressed.

㉘ **HEAT** Switch — To turn on the heater blower for the pilot's area press this switch to either the **HI**— or **LOW** position. Note that when the front heat switch (26) is **OFF**, the heat switches (25) and (28) can be used to provide cool air circulation by turning on the blowers.



②⑨ **AUX. BATTERY** Switch — When this switch is pressed, a jumper solenoid connects the generator and coach batteries together (in parallel) to provide extra power for cranking the generator or coach. Releasing the switch immediately isolates the two battery systems.

③⑩ **THE HORN**, Figure 2-3 — This corner of the dash has 3 different switches for use with the musical horn.

The **SELECTOR** switch incorporates 2 thumbwheels for selecting the tune to be played. Use **The Horn** manual to select a tune. Then set the thumbwheels to the corresponding numbers or number and letter. Note, that if a tune is playing, making a new selection on the the selector switch will not affect the tune playing.

The **POWER** switch provides power to the musical horn. When this switch is turned **ON** the horn will immediately start playing the tune that corresponds to the digits on the selector switch.

The **PLAY** switch (momentary) resets the horn to the beginning of tune chosen by the Selector switch. If the **PLAY** switch is pressed while a tune is playing, that tune will stop instantly and the horn will reset to the beginning of the tune that corresponds to the digits on the **SELECTOR**.




Figure 2-3. "The Horn".

③① **BULK OIL** Switch — When switch is pushed **ON**, 12 volt power is supplied to switch in engine compartment for activation of bulk oil fill system. An indicator lamp next to the switch lights whenever switch is on.

③② **DEFROST** Switch — Turns on the blower for defrosting or defogging the front windshield. Set to **HI**— or **LOW** speed as desired.

③③ **ACCESSORY** Position — See item (3).

③④ **ENG. VOLT METER** — Registers the actual voltage at the coach batteries. With the engine running, gauge should read 14 volts (+ or - 0.5).

③⑤ **MIRROR HEAT** Switch — This switch turns on a thermostatically controlled heater in the right and left outside mirrors (convex mirrors excluded). With the switch **ON** the Mirror Heaters will automatically come on when the mirror temperature drops below 60°.

③⑥ **LEVEL MASTER** Switch — With this switch **ON** power is supplied to the level system (39) and the Level Warning system (41). Leveling jacks can be extended only when the Level Master switch is **ON**.

## Caution

**Even with all power OFF the leveling jacks can still be retracted. Make sure everyone is clear of the outside of the coach before retracting the jacks.**

③⑦ **ENG. AMP. METER** — Shows total charging current in amperes. With the engine running, total alternator output is shown. When parked, with a source of 120 volt ac, (outside power or generator), the gauge will show total output of the battery chargers.

③⑧ **ACCESSORY WARNING** Lights — These three (3) red warning indicators light to alert you of the following conditions:

**SUSP. DUMP** — Lights to tell you that the suspension system has little or no air, and that the suspension needs to be pressurized before the coach is driven.

**GEN. DOOR LOCK** — Comes on when the generator compartment is not locked and stays on until the lever is moved to locked position.

**HEADLIGHT ALERT** — When the ignition switch is turned off and the headlight switch is on, this red warning light, along with a buzzer, will come on. These will remain on until the headlight switch is turned off or the ignition switch is turned back on.

③⑨ **LEVEL SYSTEM** — These blue indicator lights are marked as follows: **LEFT FRONT**, **LEFT REAR**, **RIGHT FRONT**, and **RIGHT REAR**. When the ignition is on the lights come on if the corresponding corner of the coach is not level.



④⑩ **FUEL MONITOR** — Three orange indicators come on when the following conditions are present, and the ignition switch is on:

**LOW FUEL** — This light comes on when the fuel in the tank is below the 1/4 full mark.

**WATER IN FUEL** — This light comes on when there is an excess of water in the bottom of the fuel tank.

**MAX. FUEL FLOW** — Indicates throttle is open as far as needed for maximum power.

④⑪ **LEVEL WARNING SYSTEM** — This system consists of four red indicator lights. These lights come on when the respective leveling jack is not fully retracted. All four lights should be off when the jacks are retracted.

④⑫ **REAR LANDING Light Switch** — At the **ON** position this switch turns **ON** the landing lights in the front right and left panels just behind the front tires. These lights shine toward the rear of the coach so are called Rear Landing Lights. Note that a small blue indicator lights when the switch is **ON**.

④⑬ **HEADLIGHT Switch** — The Headlight switch serves three functions. Pulling up to the first position (halfway) will turn on the parking lights, and the lights for each gauge in all dash panels. Turn counter-clockwise to increase or clockwise to decrease the brightness of gauge illumination. Pull to the second position (all the way out) and the headlights will come on also.

④⑭ **ENG. HOUR METER** — This operates whenever the ignition switch is on. The smallest increment is 1/10 hour or six minutes.

④⑮ **DASH DIMMER** — This control will only operate when the headlight switch is on. The background lighting (electroluminescent) for the dash can be brightened by turning counter-clockwise and dimmed by turning clockwise.

④⑯ **FRONT LANDING Light Switch** — To turn on the Front Landing lights, located in the rear side panels just in front of the rear wheels, push this switch to the **ON** position. The indicator next to the switch should be lit when the switch is on.

④⑰ **FUEL LEVEL Gauge** — Indicates the amount of diesel fuel remaining in the tank. This gauge reads only when the ignition switch is in **ON** or **ACCESSORY** position. The fuel gauge used on 31-

foot and 33-foot units is a dual-purpose monitor: when the fuel tank gauge selector switch is operated, it can also read the level of gasoline (30 gallons maximum) remaining in the generator fuel tank.

④⑱ **FUEL LEVEL switch location** — Fuel tank gauge selector switch is mounted here on 31 and 33 foot coaches.

④⑲ **REAR PARKING Light Switch** — This switch controls the on-off operation of the rear parking lights (rectangular halogen lights above the rear bumper) when transmission selector lever is in **R**. An indicator next to the switch lights when the rear parking lights are on.

④⑳ **CRUISE CONTROL** — These two switches operate in the following manner: The switch on the right turns the cruise control on or off. The switch on the left locks the cruise control in on the desired cruising speed.

Note that the coach must be traveling at least 35 mph before the cruise control will activate. When the desired speed is reached press the **ON-OFF** switch to the **ON** position then press the **SET-RESUME** switch to the **SET** position and hold for 2 seconds before releasing. The coach should automatically remain at that speed.

Note that the accelerator can be used to increase the speed of the coach, but the speed cannot be decreased unless the brake pedal is depressed, or the **ON-OFF** switch is turned **OFF**. If you use the brake to disengage the cruise control, and you would like to pick back up to your original cruising speed, press the **SET-RESUME** switch to the **RESUME** position for 2 seconds. The coach should automatically return to that original speed.

Engine idle speed can be increased, while parked, by means of the cruise control switches. Push the **ON-OFF** switch to **ON**; then push and release **RESUME** switch rocker until desired RPM is attained. RPM will return to normal idle speed when:

1. **CRUISE CONTROL ON-OFF** switch is turned off.
2. Transmission selector is moved from **N** position.
3. Parking brake is released.



## Note

Pressing on brake pedal will decrease RPM but speed will return to higher setting as soon as pedal is released.

⑤① **DRIVING LIGHTS** Switch — Driving lights are recessed in the front bumper. When the Driving Light switch is turned **ON**, the Driving Lights and an indicator next to the switch should come on.

⑤② **ACCESSORY** Position — See item (3).

⑤③ **MARKER LIGHTS** Switch — Press this switch to **ON** to turn on the clearance lamps located on the top sides and ends of the coach. This switch may also be flipped on and off to flash the marker lights as a courtesy signal.

⑤④ **RETARDER** Switch — Provides power to Retarder controller mounted on transmission gear selector console. The adjacent indicator lights when switch is **ON**.

⑤⑤ **ACCESSORY** Position — See item (3).

⑤⑥ **FAN OVERRIDE** — This switch operates the engine cooling fan in the engine compartment. The engine cooling fan is thermostatically controlled, and the activating temperature is 195°. To override the thermostat turn the Fan Override switch on, and the engine cooling fan will operate at any temperature continuously.

⑤⑦ **COMP. LIGHT MASTER** Switch — This switch in the **ON** position provides power to all of the exterior compartment light switches. As each compartment door is opened, the light automatically comes on; closing the door turns the light off.

⑤⑧ **BURGLAR ALARM** Switch — There are two switches that turn the Burglar Alarm on and off. The switch on the dash is used when you are inside the coach. The weather proof key switch, outside the coach next to the entrance door, is used when you are going to be leaving your coach for awhile.

Note that both switches operate independently of one another. If the Burglar Alarm is turned on at the dash, then it must be turned off at the dash. The outside switch works on the same principle.

⑤⑨ **LEFT TURN** Indicator — When the turn signal lever is pulled down into the left turn position, this indicator flashes in conjunction with the outside directional lights.

The left cornering light will come on continuously if the headlight switch control has been pulled out to either position while the turn signal lever calls for a left turn.

⑥⑩ **ACCESSORY** Position — See item (3).




Figure 2-4. Pilot's Area Overhead Dash and Radio Panel.

### Pilot's Area Overhead Dash and Radio Panel

The pilot's overhead panel is pictured in figure 2-4. Each item is identified by an index number which corresponds to the following description:

① **FM/AM STEREO TUNER/CASSETTE PLAYER** — Operation will be covered later in conjunction with figure 2-14.

② **DIMMER SWITCH** — For altimeter light.



③ **CB TRANSCEIVER UNIT** — Operation will be described later in conjunction with figure 2-19.

④ **LIGHT** — For altimeter.

⑤ **ALTIMETER** — Indicates coach height above sea level. (Zeroing adjustment can be used to calibrate unit at known elevations.)

⑥ **TV RECEIVER** — TV operation will be discussed with figures 2-14, 2-15, and 2-16.

⑦ **WATER IN FILTER** — Light and buzzer alarm.

⑧ **ANTENNA Switches** — Both switches must be pushed simultaneously to cause raising or lowering of TV antenna. Indicator will light when TV antenna is up from its secured position when ignition switch is turned on.

⑨ **ACCESSORY Position** — See item (3), figure 2-2.

⑩ **TRIP ODOMETER** — Depress bar to reset.

⑪ **SAFELINE ALARM** — The Safeline alarm operates whenever the shoreline is connected to the coach and the ignition switch is in **ON** position as a reminder to disconnect the shoreline before driving away.

With the Safeline switch **ON**, the alarm is given by buzzer sound and red light. The buzzer can be deactivated in favor of a flashing amber light by turning off the switch.

⑫ **GENERATOR START/STOP Switch** — Provides local control for generator operation. Press this center-off momentary switch to **START** position and hold until generator starts, as indicated by the switch indicator illuminating. If generator does not start within 15 to 20 seconds, release switch, wait 30 seconds, then try again. To shut down the generator, press to **OFF** position and hold until light extinguishes.

## Caution


**Do not start the generator when a heavy circuit load is on-line, such as the air conditioners. This can cause an excessive strain on the generator rotating components and may result in equipment damage.**

## Note

**When starting the generator during cold weather, press the switch to **STOP** position for a minute. This activates the glow plugs for easier starting.**

⑬ **CLOCK PANEL** — As shown in figure 2-5, this panel includes a digital readout. Four switches to the left of the display set clock timing. To set **TIME** display, press **HR SET/MIN SET** switch to **HR SET** position and hold until correct hour is displayed; repeat with switch in **MIN SET** position until correct minutes are displayed.

The **ELAPSED TIME** display will show elapsed time in terms of hours and minutes, or in minutes and seconds, depending on the position of the **HRS/MIN - MIN/SEC SWITCH**. Set this switch as desired, press **ZERO** to reset the display to a 00:00 readout, and the elapsed time will count. The **HOLD/GO** switch may be set to **HOLD** position to suspend operation of the elapsed time display; for elapsed time operation, leave switch in **GO** position.



**Figure 2-5.** Digital Clock/Elapsed Time Display

## Remote Spotlight Controls

The optional roof-mounted remote-control high intensity spotlight is operated by the **SPOTLIGHT** controls located in the overhead dash. The spotlight produces 100,000 BCP (beam candle-power) and can be turned on and off, positioned horizontally or vertically at an adjustable rate of speed, and can be used for spot- or flood-lighting. The following controls operate the spotlight:

⑭ **SPOTLIGHT AIM Control** — Controls horizontal and vertical beam position.





⑮ **SPOTLIGHT SPEED** Control — Adjusts speed of light head movement.

⑯ **SPOTLIGHT BEAM SELECTOR** Switch — Depressing left side of switch activates **FLOOD** while right side pressure selects **SPOT**. Center position is **OFF**.

⑰ **SPOTLIGHT SELECTOR** Switch — Depressing switch, left or right, selects L.H. or R.H. light operation. This switch is functional only when dual spotlights are installed.

⑱ **AIR CONDITIONER RIGHT FAN** Switch — Three speed blower for right front area of coach.

⑲ **AIR CONDITIONER** Temperature Selector — Thermostat setting controls temperature by cycling compressor.

⑳ **AIR CONDITIONER LEFT FAN** Switch — Three speed blower for left front area of coach. Left fan switch must be in either **HI**, **MED**, or **LOW** to energize compressor.

㉑ **CAMERA DEFOG** Switch — Energizes fan in compartment for Closed Circuit TV (CCTV) camera.

㉒ **DASH DIMMER** — This control will only operate when the headlight switch is on. The background lighting (electroluminescent) for the upper dash can be brightened by turning counter-clockwise and dimmed by turning clockwise.

㉓ **AUX. PUMP** Switch — Controls the auxiliary water pump (under floor at road side rear) that boosts the circulation of engine coolant through the water heater heat exchanger and chassis heaters in the bedroom, kitchen and living room.

㉔ **HEAT SELECTOR** Switch — Operates solenoid valves in engine coolant line to divert coolant flow through hot water heater and chassis heaters when this switch is in **WINTER** position. Setting the switch to **SUMMER** position causes the coolant to flow through the hot water supply heater coil only.

㉕ **PILOT'S LEFT OVERHEAD CONTROL PANEL** — Functions of this panel will be discussed with figure 2-6.

### Pilot's Left Overhead Control Panel Figure 2-6.

① **C.B.** — Jack for headphone listening with volume control.

② **STEREO JACK** — For headphone use with AM/FM Stereo Tuner/Cassette Player.

③ **DIGITELL COMMAND** Station — To discontinue an alarm condition, depress the **COMMAND** switch during the announcement.

④ **EXHAUST FAN** Controls for Living Room — Remote switches for raising or lowering vent lid turning lights and fan off and on.

⑤ **CLOSED CIRCUIT T.V.** Controls — Operation explained with Figure 2-15.

⑥ **AIR CONDITIONING** Remote Switches — Permit air conditioning control by the pilot. See Section III for full description.




Figure 2-6. Pilot's Left Overhead Control Panel

### Co-Pilot's Area Overhead Dash Figure 2-7

① **GENERATOR OIL PRESSURE** Gauge — Shows the oil pressure, not amount of oil in the generator engine reservoir. This gauge will normally read between 30 and 60 psi. Low oil pressure indications are often a symptom of possible generator failure. Oil level should be checked on a regular basis. Note that the generator has a low-oil pressure shut-off switch which operates if the generator oil pressure falls below 15 psi.

② **GENERATOR WATER TEMP.** Gauge — Displays generator engine coolant temperatures from 100 to 240 degrees. Normal operating temperatures vary from 175 to 190 degrees. If consistently high temperatures are indicated, shut down the



generator, wait for the engine to cool, then check radiator coolant level. Note that the generator has a high-temperature shut-off switch which operates if the generator temperature reaches 225 degrees F.

③ **GENERATOR VOLTS** — Expanded-scale voltmeter, with scale graduations from 10 to 16 volts, shows the condition of the generator battery. Normally, the battery voltage varies from 12 to 13 volts; under starting load it may drop to about 10.5 volts and then rise to about 14.0 when the generator starts and begins charging the battery through the external isolator unit and battery chargers. Battery voltage readings less than 10.5 or more than 15 are usually a symptom of an electrical system failure or impending battery breakdown.

④ **GENERATOR HOURS RUN METER** — Indicates total hours of generator operation.

center even when plugged into shore power (or running generator). This will gradually diminish and should eventually show some movement to the right with coach loads turned off.

Ammeter on right (labelled **DISCHARGE**) shows current demand of 12 volt load.

⑥ **A.C. VOLTAGE** — Voltmeter on left monitors LEG ONE while that on right monitors LEG TWO of 120 volt alternating current circuits.

### Caution

Appliances can be damaged by low voltage. Loads should be balanced so voltage does not drop below 110 volts for either leg. Low campground (shore-power) voltage can be detected quickly from gauge readings. If cause of low campground voltage can not be corrected, generator power will have to be used during periods of high appliance demands.

⑦ **A.C. AMPERAGE** — Ammeters show current flow in LEG ONE (left) and LEG TWO (right) of 120 volt alternating current circuits.

### Leveling Jacks Controls

The motorhome is optionally equipped with four heavy-duty leveling jacks; one at each corner of the chassis. The jacks are the fold-down type, and cannot be extended until they are unfolded.

Overall system operation is monitored at the lower dash, while each jack is independently operated by one of four respective **EXTEND-RETRACT** levers located on the floor to the left of the driver, figure 2-8. Separate dash indicators and a buzzer (when ignition switch is on) provide visual and audible signals to show that the associated leveling jacks are not stowed to a safe travel position.




Figure 2-7. Co-Pilot's Area Overhead Dash

⑤ **D.C. AMPERAGE** — Ammeter on left (labelled **CHARGE**) shows net current flow to or from batteries. Needle movement from the center of the gauge indicates discharge to the left and charge to the right. When parked, following highway travel, it is normal to see a needle position to the left of




Figure 2-8. Leveling Jack Controls.

### Caution

Be sure that the frame is securely blocked before changing tires or working beneath the coach.

Use the following procedures to operate the leveling jacks:

### Note

12 Volt master switch must be on to operate leveling jacks.

① Set **LEVEL MASTER** switch (item 36 figure 2-2) to **ON** position. Note that one or more blue **LEVEL SYSTEM** indicators may light. **LEVEL SYSTEM** indicators **LF**, **RF**, **LR** and **RR** are lit only when the respective corner of the coach is low.

② Unfold the leveling jacks by setting the floor controls to **EXTEND** position. As soon as the jacks contact the ground, as indicated by the characteristic landing gear **thump**, release the respective control lever to prevent further jack movement.

Note that the red **LEVEL WARNING SYSTEM** indicators will be lit to show that the jacks are no longer in the stowed (**RETRACT**) position.

③ De-pressurize the air suspension system by setting the **SUSP. DUMP** switch to **DUMP** (down).

### Caution

Do not dump the coach air suspension system until the leveling jacks are unstowed and vertical or the coach chassis may be too low to permit the jacks to be unstowed.

④ Operate the **EXTEND-RETRACT** levers for the leveling jacks as necessary to level the coach. The blue and **LEVEL SYSTEM** indicators will extinguish when the respective corners are leveled.

⑤ To restow the leveling jacks prior to moving the coach, start engine to initiate air compressor operation, repressurize the air suspension system by setting the **DUMP** switch to the **FILL** (up) position.

⑥ When the air suspension is once again stabilized, pull all four leveling jacks controls back to the **RETRACT** (locked) position. The red warning indicators will extinguish when the associated jack is in the stowed position; one or more blue indicators may be lit, but may be disregarded at this time.

⑦ Set **LEVEL MASTER** switch to **OFF** position. This completes one full operating cycle for the leveling jacks system.

### Note

If the jacks are not withdrawn before driving away, the buzzer will sound.



**Emergency Flasher Switch** — The emergency flasher switch is located on the right side of the steering column. Push the switch inward to turn on the flashing warning lights; pull switch outward to shut flashers off. Note that the dash directional lights flash in unison.

**Fuel Vacuum Gauge** — Located in engine cover. Racor fuel filter element should be changed when pointer goes into red!

**Parking Brake** — The **Parking Brake** control is located under the lower dash, to the right of the steering column. Note that the parking brake cannot be released unless the system air pressure is at least 65 psi.

**12 Volt Master Switch** — This switch is hidden on an inner dash panel directly in front of (and below) the **Parking Brake** control. Use this switch to shut off 12 volt battery power to all circuits except digital clocks, radio memory, monitoring panel functions, and burglar alarm.

### Floor Controls

**Headlight Dimmer Switch** — Close to outside wall.

**Air Horn Foot Switch** — Operates highway horns. Close to steering column.

**Accelerator Pedal** — Controls engine fuel flow to select power output. See Diesel Engine/Transmission Operation later in this section for detailed description.

**Brake Pedal** — The coach is equipped with a dual air brake system which includes independent systems for the front and rear service brakes. A separate reservoir and panel-mounted pressure gauge is provided for each service brake system (**AIR PRESSURE FRONT** and **AIR PRESSURE REAR**).

**Leveling Jack Controls** — Described previously with figure 2-8.




Figure 2-9. Steering Column Area Controls.

### Steering Column Area

The steering column area, figure 2-9, includes controls located on the steering column, and under the dash as well as a gauge on the engine cover.

**Horn** — Operate the horn by pressing in on the center section of the wheel. Select air or electric horn with the **HORN SELECTOR** switch on the dash.

**Turn Signal Lever** — Move lever forward to signal a right turn; move rearward to signal a left turn.



## Transmission Gear Selector Console Figure 2-10.




Figure 2-10. Transmission Gear Selector Console.

**Transmission Gear Selector** — Enables selection of desired 1 through 4 forward speeds or reverse **R**. See Diesel Engine/Transmission Operation later in this section for detailed description.

**Ignition Switch** — A four-position, standard-type key switch. In **OFF** position (center), ignition and accessory positions are disabled and the key can be inserted or removed. In **ON** position (right) the battery is connected to the engine-run ignition circuits and the key can be advanced to **START** to start the engine, providing that the transmission selector is in neutral **N** position. **ACCESSORY** position (left) allows operation of accessories without activating the engine-run circuits. Note that **CCTV** operation occurs only in **ON** position: turning the ignition **OFF** allows use of standard TV.

**RETARDER HAND CONTROL** — This five position switch allows full or partial application of the drive line retarder. Operation will be explained later in this section.

**LEFT VENT AND RIGHT VENT** Switches — Operate the air cylinder controlled air vents to direct fresh air to the pilot and co-pilot areas.

## Air Suspension System

Your motorhome is equipped with air suspension bags which **cushion** the front and rear axles. Dumping these air bags when the vehicle is parked allows the rubber bumpers to come together and eliminate vehicle **springiness**. The **SUSP. DUMP** switch controls the dumping and filling of the suspension air bags.

### Note

The accessory air tank must contain at least 65 PSI pressure for the air switch to function. The accessory air tank pressure does not register directly on the dash air pressure gauges but when the dash gauges register 65 or above, there is ample pressure.

Moving the **SUSP. DUMP** switch toggle down (to the rear) applies air pressure to three air pilot-operated valves on the suspension system. Two of these valves are located on the rear axle; and one is located on the front axle. The pilot air shifts the valves, cutting off the air supply to the air bags and allows the air in the bags to escape. After the suspension system has been dumped, and the ignition is turned on, a warning pilot light is illuminated on the dash to warn the driver that the system is dumped and not to drive the vehicle until the air switch toggle is set to the up position.

### Note

If the leveling jacks are to be used while the coach is parked, the jacks must be lowered to level the vehicle before the air bags are dumped. If the air bags are dumped before the jacks are down, the vehicle is too low for the jacks to unfold into lifting position properly. This could damage the jacks.

**SUSP. DUMP** Switch — This switch controls the inflation of the air suspension system. Move toggle down (to the rear) to dump the bags. Note that **SUSP. DUMP ACCESSORY WARNING** light is lit; set switch to **up** position to re-inflate the air bags before driving away. (System air pressure must be at least 65 psi.)

**WHEEL TILT** Switch — Move toggle down to release steering column so wheel may be moved to desired position. Move lever up to lock.



## Caution

Always make sure that lever is in the fully locked position in whichever de- tent setting is used. Do not change the wheel tilt setting while the coach is in motion.

## Radar Detector

A high-sensitivity superheterodyne microwave radar detector is installed as standard equipment on your coach. This unit, shown in figure 2-11, is designed to activate when transmissions are received from radar-type speed detection equipment.

## Note

Because some states have ruled radar detection equipment illegal, it is the responsibility of the driver or owner to obey the appropriate laws. (There are quick-disconnect features provided which allow for easy removal of the unit.)

**CONTROLS AND INDICATORS** — Operating controls and indicators are listed below:

**VOLUME ON-OFF CONTROL** — Adjusts volume of beeper alarm and controls **ON-OFF** operation.

**POWER Indicator** — Red LED that lights when power is on.

**SIGNAL STRENGTH METER** — Displays signal strength of the detected radar signals. Operates in conjunction with the 1,000-cycle beep tones from the built-in speaker so that high readings and rapid beeping indicate a radar in close proximity; while low signal strength readings and spaced beeps indicate the reverse. Learn to interpret the readings correctly. (Note that lowering the beep volume level will not affect the operation of the signal strength meter.)

**CITY-HIGHWAY CONTROL** — Set to **HIGHWAY** position for maximum sensitivity on both **X**- and **K**-bands. Set to **CITY** position for reduced sensitivity on **X**-band (usually used for highway and rural applications, but also commonly encountered in city driving by unit sensing **stray** radar transmissions) and continued high sensitivity on **K**-band (urban-type radars).

**ALERT Indicator and Dimmer** — In addition to its radar-detecting capability, the unit also includes a photoelectric ambient-light monitor to control the illumination intensity of the radar-warning **ALERT** indicator in proportion to coach interior lighting conditions.




Figure 2-11. Radar Detector.

## Note

The radar detector is designed to be removed and disconnected quickly and easily. Note that the electrical quick-disconnect connector also includes a low-amperage power line fuse to protect the unit. In the event that the unit is completely inoperative, check for a defective line fuse by disassembling the connector and replacing the fuse.

## Radar Operation

Although the detector is designed to prevent reception of false alarms, microwave tele-communications towers can sometimes cause a false alarm. The extreme sensitivity of the unit makes it most important for the driver to heed all warnings. Reflected radar scatter from a moving radar, going in the same direction ahead of you, or behind you, can be detected by your unit at a greater range than the effective distance of police radar!

Operate the radar detector as follows:

1. Turn on radar detector by turning the **VOLUME** control clockwise. A four-second tone will sound so that volume can be set and the operation of the **ALERT** indicator and signal strength meter can be checked. **ALERT** blinks in conjunction with the beep sounds; meter displays average signal strength.
2. Set **CITY-HIGHWAY** switch to appropriate position and unit is ready for operation.



## Note

The intensity of the **ALERT** lamp will vary in accordance with the ambient coach interior lighting level, as monitored by the photoelectric detector on the unit. Bright coach interior increases **ALERT** lamp intensity; dim interior lighting results in lowered lamp intensity.

### Interpreting Radar Alerts

When a radar is detected, the **ALERT** indicator flashes and a beep tone is heard. The rate at which these indications are given are a measure of the proximity of the radar to the detector: the closer the radar, the faster the beeping/flashing rate; the more distant the sound also indicates which type of radar is being picked up by the detector.

**X-band** radars will cause the unit to emit single beeps; while **K-band** radar transmissions will be identified by rapid dual beeps. The meter also indicates the proximity of the radar transmitter in terms of signal strength on a 1 to 9 scale. Generally, the detector will not sound the alarm alert until the signal strength is greater than a 5 reading on the meter. However, all indications should be heeded.

Use the **CITY-HIGHWAY** switch in **CITY** position to reduce the sensitivity of the detector when traveling in densely-populated areas to diminish detector responses to other types of microwave sources such as door openers, burglar alarms, etc. Leave this switch in **HIGHWAY** position for maximum sensitivity for most driving situations.

### Seat Controls

Electrically and air-operated six-way seat adjustments are built into the pilot's and co-pilot's seats. A typical control panel is shown in figure 2-12.




Figure 2-12. Seat Controls

Three electric **SEAT CONTROLS** are used to control seat bench tilt, up-down and front-back seat movement, and seat back tilt. The **SIDE SLIDE** switch operates an air cylinder which locks the position of the slide mechanism beneath the seat. Set switch to **SIDE SLIDE** to disengage the seat slide lock, adjust side-to-side position, then set to **LOCKED** to re-engage lock mechanism. This switch must be kept **LOCKED** to secure the seat during travel.




Figure 2-13. AM/FM Stereo Tuner/Cassette Player

**AM/FM Stereo  
Tuner/Cassette Player  
Operating Controls  
Figure 2-13**

- ① On/Off, volume (turn), balance (pull & turn), fader (push & turn)
- ② Bass
- ③ Manual Tuning momentary or hold (turn), signal seeking (push in)





- ④ Treble
- ⑤ Clock on and reset
- ⑥ 6 electronic station-presets on each band (1 AM and 1 FM on each preset)
- ⑦ Loudness
- ⑧ Local/distant
- ⑨ AM/FM selector
- ⑩ Cassette program selector on/off
- ⑪ CPS light
- ⑫ Cassette side change
- ⑬ Metal tape
- ⑭ Fast forward (FF) rewind (REW) cassette eject (push both buttons)
- ⑮ Dolby light
- ⑯ Dolby on/off
- ⑰ Tape travel lights
- ⑱ FM Stereo light
- ⑲ Cassette slot
- ⑳ Digital frequency/clock display
- ㉑ AM light
- ㉒ FM light
- ㉓ Memory entry, light
- ㉔ Memory entry, station preset or clock reset

### Cassette Deck Operation

#### Caution

The Tucson is designed for high quality C30, C45, C60 and C90 cassette tapes. Use only such high quality tapes. Inferior quality tapes or cassette housings can seriously damage the precision tape decks. **Do not use bargain, non-brand name tapes. Do not use C120 tapes.**

### Cassette Handling

Before inserting a cassette into the tape deck slot, make sure there is no excess slack (several loose turns) in the tape reels. Insert a pencil in the loose reel hub and turn it until snug while holding the other hub.

Store cassettes in their plastic boxes. They have retainers which prevent tape unwinding through handling or movement and protect the tape from moisture, dust and direct sunlight.

Do not leave cassettes on such exposed areas as the dash or rear deck.

Do not otherwise expose cassettes to extreme heat (over 122°F or 50°C) or direct sunlight. They will cause warpage that can seriously affect the sound quality.

Do not leave any cassettes in the vehicle in cold weather (14°F or -10°C).

Use cassettes and the tape deck only after the vehicle has been warmed to between 64° and 68°F (18° to 20°C) or normal room temperature.

Do not use a screw driver or other metal object near the tape head.

Clean all tape contact surfaces periodically with a soft lint-free cloth and a head cleaner solvent to remove dust or accumulated oxide.

1. **To Start a Cassette** — Turn left inner ON/OFF knob to right (clockwise) to turn power ON in radio mode.

Insert cassette, with tape opening on right, and desired side up, into the **BLAUPUNKT**-label slot (19). It will open inward and receive the cassette until it seats inside. The radio mode will then shut off automatically and the cassette will start.

One of the two arrows, (17) (top right on glass dial) will light up to show direction of tape travel. The direction depends on the side that is being played.

2. **To Control Volume** — The same ON/OFF knob (1) (step 1) will increase the volume as you turn it clockwise, decrease it as you turn left (counter-clockwise).
3. **To Balance Stereo** — pull the same ON/OFF knob (1) outward and while holding outward pressure, turn it right or left for the desired balance. A click at the mid-point position indicates equal balance of right and left channels.
4. **To Control Fader (Front and Rear Speaker Volume)** — Press same ON/OFF knob (1) inward and while holding it in, turn it left or right.



for the desired speaker balance. The click position provides equal balance of front and rear speakers.

5. **For Bass and Treble Tone Control** — To control the bass, turn **outer** knob (2) on same **ON/OFF** knob shaft, to right or left for desired bass sound.

To control the treble, turn **outer** knob (4) on **right** shaft to the right or left for the desired treble sound. Both knobs have mid-point click positions where sound is equally bass and treble; knob handles will be horizontal.

6. **Automatic and Manual Reverse** — When one side of the cassette is completed, the auto-reverse starts the second side automatically. If the tape is left on, it will continue to change sides as each side is completed, until shut off or ejected.

To change sides manually, press button (12) (See Figure 1).

The tape-travel light (17) will indicate the direction of travel. There is no need to eject the cassette to play the reverse side.

7. **Fast Forward or Rewind** — To **advance** the tape rapidly, press one of the two top protruding buttons (14) that **corresponds** to the direction indicated by the lit tape-travel arrow (17) it will lock, until released by lightly pressing the button still protruding. Both will pop out.

To **rewind** the tape, press one of the same two buttons that is **opposite** to the travel light arrow. Release with the other button.

8. **To Eject the Cassette** — Press both buttons (14). Radio mode will resume.
9. **To Play Dolby Cassettes** — Press the Dolby button (16). Play non-Dolby cassettes with button (16) **out**. Press to release button.

10. **To Play Metal or Chrome Dioxide Tapes** — Press the Metal button (13). In the **IN** position, this **tape equalization** switch selects playback equalization of 70 us. The **out** position is 120 us. Press to release.

11. **Loudness Switch** — To overcome the acoustic character of human ears which do not hear low or high notes when the volume is low, press the LD button (7). It boosts the low and high sound frequencies to compensate,

producing a rich sound quality at low volume. Press to release.

12. **Cassette Program Selection (CPS)** — Press the CPS button (10) and then the FF or RW button to get to the start of the next or previous musical division (symphony movement or program piece) CPS automatically seeks a pause of more than 3 seconds. The CPS indicator (11) above the button will light. After pressing the CPS button:

**To play the next piece** — press one of the two FF/RW buttons (14) (see paragraph 7) that corresponds to the lit tape direction arrow (17) (paragraph 1). The tape will advance rapidly as the applicable direction arrow blinks, until the start is located and the next piece plays.

The CPS pause-searching mechanism must traverse a tape length equivalent to at least 8 seconds worth of playing time, before stopping at a pause. In other words, if actuated at a point **less** than 8 seconds before the next pause, it will skip that pause and continue to wind up, through the next piece, stopping only at the pause that follows the latter.

The **8-second minimum** holds, regardless of the direction of tape travel (FF or RW). Thus, you can only use CPS (10) to replay a specific piece you are playing. If you are at least 8 seconds into that piece (or, by the same token, **less** than 8 seconds into the **next** piece).

**Examples** — If **B** is playing, the next piece **C** will be located if the search started: more than 8 seconds before the end of the piece **B** that is playing; or within 8 seconds before the end of the piece **A** that preceded it; or during the pause between **A** and **B**.

**To replay A, the completed piece** — or the one that is playing, press the appropriate button (14) opposite to the direction arrow (17) that is lit. The tape will rewind as the direction arrow blinks, until it locates the start, and the **A** piece will replay. You can make that replay choice for **A** any time between a point 8 seconds after **A** started until 8 seconds after the next (**B**) piece starts.

If you want to leap-frog past more than one



piece, leave the **CPS** button in. Then press the appropriate button (14) and press each time it starts a new piece until (winding forward or backward) you reach the piece you want. To return to normal play, press the **CPS** button (10); it will pop out.

## Note

Because **CPS** searches for a 3-second or longer pause in the program it may restart at such undesirable places as a pause in conversation or song, or a low-level point in music of comparatively higher sound levels. **CPS** may also skip over pauses of less than 3 seconds duration, or those with excessive background hum or noise.

## Radio Operation

1. **Power and Sound Controls** — These controls, shown in figure 2-14 and described in the Cassette Deck section, are used in the radio mode as well. (See preceding section on Controls, paragraphs 2 through 5, for power **ON/OFF**, volume balance, fader, bass and treble controls, and paragraph 11 for the loudness **LD** control. The **FM/Stereo** light (18) will go **ON** when stereo radio is **ON**.

2. **To Select waveband** — Press **IN** the **AM/FM** button (9) to get **FM**, and press to release for **AM** (button **out**). The appropriate **AM** or **FM** light (21 or 22) on the left side of the glass dial will indicate the selected waveband.

### 3. To Tune in a Station: 3 Methods

I. **Manually** — Turn the tuning knob (3) to left or right and **release**, to change frequency by steps. To scan frequencies, **turn** the knob to left or right and **hold**. It starts slowly, then increases speed of scan. In either method, the clock dial will indicate the frequency.

The frequency ranges are:

**AM**: 530 KHz to 1620 KHz in 10 KHz intervals

**FM**: 87.9 MHz to 107.9 MHz in 0.2 MHz intervals

II. **Automatic Station Seeking** — Push in the same knob and release. The automatic seeking scanner, a built-in microprocessor, will find and lock in on the nearest station. Press again to get the next station and repeat as nec-

essary. If the knob is pushed in **while** the scanner is seeking the station, it will stop seeking.

To prevent error in station-seeking caused by the influence of a very strong station, keep the local/distant button, **LOC** (8), pushed **in** in the local position (refer to paragraph 6). It reduces overloading.

III. **Station Memory Storage** (6 Numbered Buttons.) — For pushbutton tuning of frequently used stations (one **AM** and one **FM** for each button):

(a) Tune in desired station as described above, manually or automatically.

(b) Press and release the memory entry. **ME** button (24) (left side). The adjacent **ME** light (23) indicates you have 5 seconds to press one of the six numbered preset buttons below the dial; after 5 seconds the light goes off.

(c) Press the numbered button before the light goes off and your station is preset. (The light will go off when you press the button).

(d) Similarly, press **ME** plus another numbered button, for each station you tune in for memory storage on the same waveband (**AM** or **FM**).

(e) Press the **FM** button (9) to change the waveband. Again, tune-in in turn each desired station on the other waveband, and press the **ME** plus one of the numbered preset buttons, to enter the station in memory for pushbutton tuning. As stated, each button holds one **AM** and one **FM** station.

(f) When you select a station by pushing its numbered preset button, its frequency is shown on the clock dial.

(g) To change a preset station to another, just tune in the newly-selected station and enter it as described above.

(h) If you press the **ME** button and do not press any preset button before the **ME** light goes off in 5 seconds, the station will not be preset. Try again.

(i) Memory is not erased when power is **OFF** because of the direct connection to the battery.

4. **Frequency and Clock Display** — The digital display in the center of the glass dial indicates KHz frequencies on **AM**, or MHz on **FM**, when unit power is **ON**. To get the hours and minutes display, press the clock button (5) on the left



bottom of the dial.

#### 5. To Reset Digital Clock —

(a) With ignition and power **ON**, press the clock button (5) to get the time display.

(b) To correct the **HOUR**, press the **ME** button (24) on the left of the glass dial, and press in and turn the tuning knob (on the right) **counter-clockwise** (3). Release the knob when the display has advanced to the correct **HOUR**.

(c) To correct the **MINUTES**, press the **ME** button, and press in and turn the tuning knob **clockwise**. Release the knob when the display has advanced to the correct **MINUTE**.

6. **Local/Distant Switch** — When the **LOC** button (8) is pressed **IN** for AM or FM reception, the radio receives only local, strong stations. Press again for the **out** position to tune in all stations including weak and distant signals. The automatic signal-seeking (previous paragraph 3) will lock in on a strong station in **LOC** position **IN**.

7. **Dolby Broadcasts** — To get best reception from FM stations that broadcast in Dolby, press the Dolby button (16) (the light (15) will go on). It excludes more background noise and improves dynamic frequency range.

8. **ARI (Automatic Radio Information)** — This system permits reception of current traffic information in several operating modes. Although only recently introduced to North America, it has been in wide use in Western Europe. The TUCSON has a built-in connection for addition of an ARI adapter unit to receive the ARI traffic reports when broadcasts are started in your area. The media and advertisements will publicly announce the implementation of this ARI system. Within the next several years, ARI will help improve traffic flow and reduce jams during rush hours in many urban centers in North America.

## Closed Circuit TV/Receiver System

### System Components

Besides the TV receiver on the upper panel, the CCTV/TV receiver system also includes:

- CCTV camera, located in the rear of the coach, figure 2-14.
- VHF/UHF tuning and TV receiver controls, on the side panel above and to the left of the pilot, figure 2-15.
- Picture brightness and color adjustment panel, located in the compartment above the CCTV controls, figure 2-16.
- Roof-mounted TV antenna, figure 2-17, and remote control panel, figure 2-18, located in the overhead cabinet above and to the rear of the cockpit.




Figure 2-14. CCTV Camera Port

### CCTV Operation

When the system is used for CCTV operation, the rear-facing CCTV camera transmits images directly to the monitor via coach cabling. CCTV operation can only occur when the ignition is **ON**. For normal operation, when the ignition is **OFF**, the system functions as a conventional TV receiver, via the controls shown in figure 2-15 and 2-16.

Note that the system requires a brief warmup period before achieving full resolution. CCTV camera controls are preset and the standard lens supplied with the unit is designed to focus from about two feet to infinity.



## TV Operation

Use the monitor as a standard TV, with ignition **OFF**, via the TV panel controls.




Figure 2-15. TV Controls




Figure 2-16. Picture Control Panel

## TV Antenna and Rotator System

The control components of the antenna and rotator are a hand-held switch-operated rotator, radome-type TV roof antenna, coupler-switcher for the antenna or cable inputs and a switch for raising and lowering the antenna.

The **A-C** switch on the coupler antenna **A** or cable **C** input via connections in shoreline compartment at the rear of the coach. Additional switches on the coupler route the antenna/cable inputs to the TV receiver.

The antenna rotator controls the position of the TV antenna within the radome. The three-position momentary switch (center **OFF**) provides right/left antenna rotation, with antenna position displayed

on the control unit. The rotator power supply is also located in the radome, which, in addition to the antenna, also includes an amplifier and rotator mechanism. The remote power supply is designed to operate from either 120 volts ac or 12 volts dc. Low-loss coaxial cable and three-wire rotator control cable interconnect the antenna and power supply.




Figure 2-17. Extendable TV Antenna Radome

Note that a .8 ampere fuse is connected in the 12-volt dc supply line to the unit. In the event that the TV set exhibits problems relating to low antenna input (**ghosts, etc.**) check this fuse before servicing the TV set.




Figure 2-18. Antenna Control Panel

## Antenna Operation

With the TV on and a station tuned in, rotate the antenna by pressing the rocker switch located on the control unit. Press the right side of the switch to turn the antenna clockwise; press the left side



to turn the antenna counter-clockwise. Although the actual antenna movement is not visible, the indicator arrow on the control unit lights and shows the direction of the antenna. When the antenna has made one full turn (360 degrees), the End of Rotation light comes on. Observe the picture while rotating the antenna, first in one direction, then the other, to obtain best picture quality.

The switches for raising or lowering the antenna are located in the Pilot's Area Overhead Dash and Radio Panel, figure 2-4, item 8.

### CB Transceiver Unit

Operation of the CB transceiver unit located in the Pilot's Area Overhead Dash and Radio Panel, figure 2-4, item 3, is regulated by the Federal Communications Commission (FCC). According to FCC rules, the transceiver is designed for licensed Class D operation on any of the 40 channels designated as the Citizen's Band and you are required to read and understand Part 95 of the FCC regulations prior to operating your unit. (A copy of this document is supplied with the CB unit.)




Figure 2-19. CB Transceiver Unit

### Controls and Indicators

The functions of the controls and indicators shown in figure 2-19 are described in the following paragraphs:

① **MIC GAIN CONTROL** — Varies the microphone amplification and modulation level for best possible transmission. When CB is used in PA mode, this control allows adjustment of PA volume.

② **RF GAIN CONTROL** — Adjusts the receiver sensitivity to reduce interference from weaker transmitters on a busy channel. When turned fully clockwise, the receiver is at maximum sensitivity. As the control is turned counterclockwise, the receiver becomes less sensitive to interference from weaker transmitters, resulting in clearer reception of the desired signal. The **RF GAIN** control is very effective when used in a crowded urban area.

③ **S/R F METER** — S/R F scale of meter indicates strength of received signals in S units. Relative RF output power of the transmitter is also shown.

④ **CHANNEL INDICATOR** — Displays selected channel.

⑤ **CHANNEL SELECTOR** — This switch selects the desired channel for transmission and reception. All channels, except channel 9, may be used for communications between stations operating under different licenses.

Channel 9 has been reserved by the FCC for emergency communications involving the immediate safety of individuals or immediate protection of property. Channel 9 may also be used to render assistance to a motorist. This is an FCC rule and applies to all operators of CB radios.

⑥ **TX/RX INDICATOR** — The transmit/receive indicator lights red when transmitting, green when receiving.

⑦ **PRESS-TO-TALK Switch** — Used during operation to control reception and transmission. Press the switch in to transmit; release to receive.

⑧ **ON-OFF VOLUME CONTROL** — During normal CB operation, turns unit on and off and controls speaker volume.

⑨ **SQUELCH CONTROL** — Allows operator to set receiver squelch so that only signals above the set level are heard. Weaker signals and background noise are eliminated (**squelched**).



⑩ **PA/CB Switch** — When this switch is in **PA** position, the operator can use the transceiver as a public address system through the roof-mount speaker. Keep switch in **CB** position for normal operation.

⑪ **ANL CONTROL** — Automatic noise limiter control which reduces ignition noise and other man-made noises that may make received signals unintelligible.

⑫ **DIMMER Switch** — This switch is used to adjust the brightness of the LED channel display and the meter.

⑬ **CH9/OFF Switch** — Placing this switch in **CH9** position switches the receiver and transmitter to Channel 9 regardless of the channel selector position. Set to **OFF** position to restore normal operation.

⑭ **CH9 INDICATOR** — Indicator lights red to show that **CH9** switch is activated.

#### **CB Operation**

1. Turn **ON-OFF/VOLUME** control (8) clockwise and note these indicators light:

- S/RF meter (3)
- Channel indicator (4)
- TX/RX indicator (6) lights green

Radio will not operate unless microphone is connected.

2. Adjust **VOLUME** control (8) for desired listening level. Be sure that **PA/CB** switch (10) is in **CB** position.

#### **To Receive —**

1. Select desired channel. Note that the **S/RF** meter (3) indicates the relative strength of the signals.
2. Adjust **RF GAIN** control (2) for clearest reception of selected signal, reducing unwanted signals in strong signals areas.
3. Adjust **ANL** control (11) to reduce unwanted noise and maintain minimum audio distortion.
4. Set **SQUELCH** control (9) fully counter-clockwise, then advance control clockwise until background noise and undesired weak signals are eliminated.

#### **To Transmit —**

### **Note**

**Remember that Channel 9 has been designated as an emergency channel and that its use is primarily restricted to communications involving the immediate safety of life and protection of property; and, secondarily, to provide assistance to motorists. Many CB clubs, police, rescue units, hospitals and garages monitor Channel 9. Emergency calls made on any channel must be given priority!**

Before transmitting, make sure that the channel is clear.

1. Position microphone close to your mouth and at a slight angle.
2. Monitor the channel and, when clear, press and hold the **PTT** switch (7). The pointer on the **S/RF** meter (3) will deflect into the red area, indicating normal relative power output.
3. Contact the party you wish to speak with. Speak clearly and in a normal voice. To hear a reply, release the **PTT** switch.

#### **Interpreting S/RF Meter Readings**

The CB unit is equipped with a multi-function meter. The S/RF scale indicates both the relative transmitter output power and the received signal strength. By interpretation, the meter can also indicate the condition of the CB antenna circuit.

The received signal strength scale is calibrated in S units, the stronger the received signal, the more the meter deflects to the right. For example, S1 represents a very weak signal, S5 is an average signal, and S9 is an extremely strong signal. When using **RF GAIN** control (2) these readings apply when the control is clockwise (maximum gain). The meter will still show relative signal strength when **RF gain** is used and it should be used as a monitor when setting the **RF GAIN** to the correct level. As an example, the desired voice signals may be received at an S9 level but, at the same time, interfering signals are being received at an S3 level. (Strength of the interference can be read on the meter during a break in transmissions of the higher signal.) To cut down on the weaker signals, adjust receiver sensitivity with the **RF GAIN** control so that the strength of the S9 signal



drops to an S6 level, and this will eliminate the interference.

For best performance and system reliability, the antenna SWR (Standing Wave Ratio) must be as low as possible. A low SWR ensures that most of the RF output energy is being radiated through the antenna, instead of being reflected back into the transmitter. A high SWR reduces communications range and, if sustained, can shorten the life of the equipment.

### Using Squelch Control

With the control fully open (counter-clockwise) the receiver is so sensitive that even very weak signals from low power **Walkie-Talkies** and distant radio sets may be received. Many of these signals will be unintelligible due to range and atmospheric conditions. As the **SQUELCH** control is advanced clockwise, stronger and stronger signals are required to **unsquelch** the receiver. In this way, the operator can establish the desired level that a signal must exceed before it is audible.

### Public Address Operation

The PA feature allows the operator to hear CB transmissions from outside the coach, as well as make announcements over the PA speaker.

1. To hear received signals over the PA speaker instead of the internal CB speaker, place **PA/CB** switch in **PA** position. Adjust loudness with the **VOLUME** control.
2. To use the PA speaker for public announcements, or as a one-way intercom, place the **PA/CB** switch in **PA** position, press **PTT** switch and speak into the microphone. Speaker loudness depends only on voice level and **MIC**rophone **GAIN** setting. In this mode, the **VOLUME** control has no effect on voice level. To silence received signals that may be heard when the **PTT** switch is released, turn the **VOLUME** control fully counter-clockwise, but do not turn it off.

### Digitell Monitor

Although the Digitell Monitor is part of the Systems Monitor Panel located on the dinette wall, several of its warning functions are related to features which concern the driving of the motorhome. This unit provides speech-synthesized warnings of the following driving alarm conditions:

- Low on fuel

- Water in fuel

Alarm announcements for these conditions will be repeated every 45 seconds, providing that the alarm condition exists for at least 30 seconds.

Refer to Section 3 for additional information on Digitell operation.

### Diesel Engine/Transmission Operation

Proper operation and maintenance are key factors in determining the useful life and operating economy of a diesel engine. Follow these directions for trouble-free, economical operation.

#### To Start Engine

Caterpillar 3208 Engines will start at temperatures above 10 degrees F (– 12 degrees C) without using a starting aid. However, for colder temperatures it may be necessary to activate the engine block heater (120 volt ac-operated). The **ENGINE BLOCK HEATER** switch is located in the toe board in front of the co-pilot seat. Remember to turn switch **OFF** after starting.

1. Place transmission in **NEUTRAL**.
2. Turn ignition switch to **START**. Engine should start within 5 seconds. If engine fails to start within 30 seconds, release the starter switch and wait two minutes to allow the starter motor to cool before trying again.
3. As soon as the engine starts, reduce engine speed to low idle. After normal oil pressure is indicated, speed may be increased to build up air pressure more rapidly.
4. Do not apply a load to the engine or increase engine speed until oil pressure gauge indicates normal. Oil pressure should rise within 15 seconds after engine starts.
5. Operate the engine at low load and low rpm until the temperature gauge starts to move. Check all gauges during warmup period.

#### To Stop Engine

### Caution

**Before stopping the engine, operate at low idle for a minute or so. This will allow hot areas in the engine to cool gradually and extend engine life.**

With the vehicle stopped, apply the parking





brake and place the transmission shift lever in **NEUTRAL**. Turn the ignition switch to the **OFF** position. This shuts off the fuel supply to the engine.

### Using the Jacobs Drive Line Retarder

Your motorhome is equipped with a Jacobs drive line retarder system which provides electrical braking action. The system is electrically controlled by operation of the lever on the retarder hand control located on the Transmission Gear Selector Console, figure 2-10.

Turn on **RETARDER** Switch. (item 54, figure 2-2) and select desired amount of braking action by moving lever from **OFF** to positions 1-4 for progressively increasing braking action. Any selected setting is on full time. When acceleration is desired move lever to **OFF**.

### Trailer Hitch Capacity

Hitch capacity is 10,000 pounds tow and 1000 pounds tongue weight.

### Towing

Two towing eyes are provided behind the front bumper.

## Caution

**Do not tow a vehicle equipped with Allison automatic transmission unless the drive shaft has been removed, or the rear wheels raised from the ground. Do not attempt to tow unit by front axle or cross-member. Damage to wiring and/or air lines can result because of proximity of these items to front cross-member.**

### Transmission Operation

The Detroit Diesel Allison transmission provides four forward ranges and one in reverse. Speed selection is provided through the transmission shift lever located on the side wall.

The selector lever must be in **N** (neutral) position when the engine is started. If the engine can start in any other position, the neutral start switch deficiency should be corrected as soon as possible. Use **D** position for all normal driving conditions so that the coach begins moving in first gear and upshifts automatically into 2nd, 3rd, and 4th gears.

As the coach slows, the transmission automatically downshifts to the correct gear. Use a low gear **2** or **3** when road, load or traffic conditions make it desirable to restrict automatic shifting to a lower range; or use the Jacobs brake drive line retarder, as previously described. Use **1** or **2** when pulling through mud and snow or driving up steep grades. The vehicle should be completely stopped before shifting into reverse.

### Driving Tips

#### Accelerator Control

Foot pressure on the accelerator pedal influences the automatic upshifting or downshifting within each driving range. When the pedal is fully depressed against the floor pedal stop, the transmission automatically upshifts near the recommended governed speed of the engine. A partially-depressed position of the pedal causes the upshifts to occur sooner at a lower engine speed. Shift timing is accomplished by using a cam and cable from the throttle. This throttle-modulation method provides the accurate shift spacing and control necessary for maximum performance.

#### Downshift Control

The transmission can be downshifted or upshifted, even at full throttle, and, although there is no speed limitation on upshifting, there is a limitation on downshifting and reverse. Good driving practices indicate that downshifting should be avoided when the vehicle is over the maximum speed attainable in the next lower gear. Allison transmission incorporates downshift inhibitors within the valve body to prevent harmful shifts when the vehicle is traveling too fast for the next lower gear. If downshifts are attempted at excessive speeds, the inhibitors prevent the selected downshift until the vehicle reaches an acceptable speed.

#### Transmission Oil Temperature

Extended operation at low vehicle speeds, with the engine at full throttle, can cause excessively high temperature in the transmission. These temperatures may tend to overheat the engine cooling system as well as cause possible damage to the transmission. If excessive temperature is indicated by the engine coolant temperature gauge, stop the vehicle and determine the cause. If the cooling system appears to be functioning properly,



the transmission is probably overheated. Shift to **N** and accelerate the engine to 1,200 to 1,500 RPM. This should reduce the oil sump temperature to operating level within a short time. If high temperatures persist, stop the engine and have the overheating condition investigated by service personnel.

## Caution

**Do not operate the engine for more than 30 seconds at full throttle with the transmission in gear and the unit stationary. Prolonged operation of this type will cause the transmission oil temperature to become excessively high and may result in severe overheating damage to transmission components.**

If the transmission overheats during normal operation, check transmission oil level.

### General Information —

#### Caterpillar 3208 Engines

Check crankcase oil level before starting and when refueling. Always check oil level with engine stopped. The dipstick has 2 markings, **FULL** and **ADD**. Maintain oil level between these marks. Do not overfill. Refer to table 8-2 for recommended oil.

- Check (with engine stopped) drive belts for cracks, breaks and frayed edges. While checking belts, look for oil, water or fuel leaks.
- Check (with engine stopped) for water in the fuel. Drain a cupful of fuel from the bottom of the tank to remove water or sediment. Fill fuel tanks after completing a run. Partially-filled tanks will collect moisture if the coach is allowed to sit for an appreciable length of time. Use number 2-D diesel fuel (with a minimum Cetane number of 40). Keep fuel clean. Inspect Racor filter bowl periodically and observe **WATER-IN-FUEL** indications on the dash gauge. Remove and clean filter bowl as necessary.

Number 1-D diesel fuel may be used in cold temperatures or when operating in altitudes above 5,000 feet.

- Check coolant level (with engine cool and off). Fill to the proper level with water and permanent-type anti-freeze, adding one quart of Nalcool 2000 Cooling System Conditioner with replenisher coolant. Use clean water that is low in scale-forming miner-

als, not softened water. Leave space for expansion. (Note that Nalcool 2000 is compatible only with ethylene-glycol base coolants.)

#### Racor Fuel Filter

A Racor fuel filter/preheater is incorporated in the diesel fuel supply line and processes the fuel supply for maximum purity.

The fuel filter also includes a built-in preheater, which operates from the 12-volt battery supply and a water sensor, which lights a dash indicator when the water level in the filter bowl is high enough to require drainage.



## Section III

# Living Area Facilities


This section provides information on operation of the appliances and systems which contribute to comfortable living within your motorhome.

### Sofa

Your **Wanderlodge®** sofa converts into a double bed sleeper. To convert the sofa you must first release 2 latches under the front edge of the sofa seat. Then pull out on the seat until the sofa is fully extended and the back of the sofa is lying in the flat position. To fold the sofa back up into the sitting position pull up on the sofa back with the pull strap provided and at the same time push in on the sofa seat with your knees until the sofa latches **click** into the locked position.

### Vacuum Cleaner

The vacuum cleaner system, located in the closet in front of the stepwell, figure 3-1, is completely self-contained and supplied with a long flexible hose and wand, carpet, upholstery and crevice tools.




**Figure 3-1.** Vacuum Cleaner System

Install the flexible hose end-fitting into the corresponding intake hole, accessible when the spring-loaded door is swung aside. The disposable paper bag, located in the compartment to the right of the intake, is easily removed and replaced

when the compartment door is opened (vacuum cleaner should be off when changing bags). A new bag is installed by sliding the cardboard ring on the bag over the intake tube. Clean or replace foam filter periodically to keep system operating efficiently. A power **on-off** switch is located near the closet door opening. Set this switch to **on** and the vacuum will operate whenever the hose is inserted.

### Dinette Area

The dinette area, figure 3-2 includes the area thermostat and door chime.



**Figure 3-2.** Dinette Area

### Galley Facilities

The galley, figure 3-3, includes a double sink, food center, toaster, refrigerator/freezer, gas range and oven, and systems monitoring/control panel. The refrigerator operates from the LP gas supply, from the 120 volts ac supply, or from 12 volt alternator output while in transit (if so connected). The range and oven also operate from the LP gas supply. Operating procedures for these appliances given in the following paragraphs assume that the main LPG valve is on. An LPG leak detector, located below the refrigerator door, continuously monitors the area for LPG leakage, shutting off the LPG supply and sounding an alarm if leaks are detected.




**Figure 3-3. Galley Facilities**

### **Refrigerator**

Understanding just how the refrigeration process operates will help to explain one of the important reasons why it is necessary to level a parked motorhome. The gas-fired (or electrically-heated) boiler converts the ammonia-water solution to distilled ammonia vapor, which is carried to the finned condenser, where it liquifies. The liquid flows to the evaporator, where it creates a cooling effect by evaporating into a circulating flow of hydrogen gas. If the evaporator coil is not level, the liquid accumulates, forming pockets which do not readily evaporate and impair or block gas circulation, inhibiting the cooling process.

When the coach is parked, it must be leveled to assure comfortable living accommodations. The refrigerator will then also perform well. Place a bubble level (furnished with unit) on the freezer shelf. When the vehicle is moving, the continuous rolling and pitching movement will not affect the refrigerator as long as the movement passes either side of level; but when the coach is parked, the refrigerator must be level (within 6 degrees).

The operation of a thermostatically-controlled fan in the refrigerator compartment is controlled by the **Refrig Fan On-Off** switch located on the systems monitoring and control panel on rear dinette wall. Refer to figure 3-4 for location of refrigerator controls.



**Figure 3-4. Refrigerator Operating Controls**

### **Operation:**

Before starting the refrigerator, turn on the gas valves (align arrow and handle with tubing) in the back of refrigerator

1. To start the refrigerator turn knob A to position **On**. Lamp E shall now be green.
2. Turn the thermostat knob B to a suitable setting; try 4.
3. The unit is shut off by turning knob A to position **Off**.

This refrigerator is equipped with an automatic energy selector system. The control system selects the most suitable available energy source. The selection will be made with highest priority to 120 volt. Second priority is to 12 volt from the alternator (when so connected), and lowest priority is gas operation. No manual operation is necessary for change of energy. If the unit does not succeed in lighting the gas the lamp E will change from continuous green into red flashing light. Further information is given below under the heading **red flashing light**. If the battery voltage drops, the control system will start continuous gas operation. The lamp will not be lit. The thermostat will not be in operation. When the voltage increases, normal operation will start up again.

During normal operation, the control system shuts off the gas when correct temperature is obtained. The gas flame will be lit by the control system when the temperature increases above the preset one.



## Delay for Gas Start Up

In order to avoid a gas-flame at gasoline stations the refrigerator is programmed to delay gas start up for about 30 minutes after 12 volt operation. Please observe that this delay occurs even after only 1 minute of 12 volt operation from your engine in order to cover events when you have to wait in line for a gasoline pump. If you want a quick gas start up after 12 volt operation you can switch **Off** the refrigerator for a few seconds and then switch back to **On**.

## Note

**This operation is only available when the refrigerator is connected for three-way use.**

## Red Flashing Light

If the lamp E begins to flash with a red light, the refrigerator control system has tried to light the gas flame but did not succeed in doing so. We recommend the following operations:

1. Turn knob A to position **Off** and back to **On** again. The lamp shall now be green as the control system makes a new starting attempt. If the refrigerator has not been in operation for a while, or you have just refilled with gas, this operation may have to be repeated several times. Each start attempt will last for up to three minutes. If the starting is not successful the lamp will turn red again.
2. If operation 1. is not successful, check your gas supply.
3. If you have gas – make sure that all valves in the gas pipe are opened.
4. If none of these operations are successful contact a service center.

Selection of electric operation is not blocked during display of red flashing light. Provide electrical power (120 volt ac or alternator) to maintain cooling when LPG operation is unavailable.

## Food Storage Compartment

To maintain required low temperatures for food storage, the food storage compartment is completely closed and unventilated. Consequently, foods having a strong odor, or foods liable to absorb odors, should always be covered. Cover veg-

etables and salads to retain crispness. The coldest locations within the refrigerator are beneath the cooling evaporator and on the lowest shelves; the least cold locations are on the upper door shelves. Consider this when storing different types of food.

## Defrosting

Shut off the refrigerator.

Empty the refrigerator leaving the drip tray under the finned evaporator and the cabinet and freezer doors open. If desired, defrosting may be speeded up by filling the ice trays with hot water and replacing in the freezer.

When all frost is melted, dry the interior of the refrigerator with a clean cloth. Empty the drip cup at the back of the refrigerator which is reached through the lower side vent.

Replace the drip cup and ice trays. Replace all food stuffs and turn on the refrigerator.

## Frozen Food Compartment

Quick-frozen soft fruits and ice cream should be placed in the coldest part of the compartment, on or just below the shelf. Frozen vegetables may be stored in any part of the compartment.

The freezer compartment is not designed for deep or quick freezing of foodstuffs. Meat or fish foods, whether raw or prepared, provided they are pre-cooled in the refrigerator, can be stored in the frozen food storage compartment about three times as long as in the normal temperature compartment. To prevent dehydration, keep food in covered dishes, in plastic bags or wrapped tightly in aluminum foil.

## Ice Making

Place ice trays in direct contact with freezer shelf for fastest ice making. Fill trays with water to within 1/4 inch from the top. To release ice cubes grasp the tray with both hands and twist. Return unused cubes to the tray. Refill tray with water, dry outside, replace in frozen storage compartment. Clean compartment with dry cloth.

## Refrigerator Shutdown

To shut off the refrigerator turn the knob A to **Off** position. If the cabinet is not in operation over a period of weeks, it should be emptied and cleaned and the door left ajar. The ice trays should also be dried and kept outside the cabinet.



## Cleaning

Clean cabinet interior lining with a lukewarm weak soda solution. Clean evaporator, ice trays and shelves with warm water only. **Do Not** use strong chemicals or abrasives to clean these parts or protective surfaces may be damaged. Always keep cabinet clean.

## Gas Range and Oven

The gas supply for the range burners and oven, figure 3-5, is provided from the LPG tank. Make sure that the main valve (on tank) is turned **On** before lighting pilots. The appliance valve, marked **Range**, in the refrigerator vent compartment must be turned **On** as well as the valve at the range top connection.

## Caution

It is a good safety practice to leave oven control in **Pilots Off** position (maximum clockwise) when oven is not in use or while unit is in motion.




Figure 3-5. Gas Range and Oven

## Lighting Pilots

To light range and oven pilots, set oven control to **Off** position then hold a match near range pilot (lift up burner top surface to gain access to burner pilot); and then hold a match to oven pilot (located above and to the right of oven main burner).

## Lighting Range Burner

Once the range pilot is lit, light the desired range burner by pushing in and turning the respective burner control knob counter-clockwise.

## Note

**The oven in your motorhome has an automatic lighting device. There will usually be a short delay (30 to 40 seconds) after the oven is turned on before the burners will light. This is a normal condition and is not a sign of an oven malfunction.**

## Lighting Oven Burner

Once the oven pilot light is lit, turn oven control to desired temperature setting and oven burner will light automatically and maintain correct temperature.

## Shut Off Range and Oven Burner

Turn oven control to **Pilot Off** position (maximum clockwise).

## Galley Sink

The heavy-gauge stainless steel sink provides maximum durability with minimum care. After use, rinse sink thoroughly with warm water and wipe dry with a cloth to avoid streaks and spots. For stubborn stains, a mild abrasive cleaner can be used with care. Be sure to wipe in the direction of the steel finish to help maintain the original appearance. Always wash counter surfaces before applying a complete wax coating; regular cleaning prevents wax buildup.

Boiling water will not harm stainless steel; however, salt, mustard, ketchup and other similar food acids can cause pitting. If any of these are spilled on the surface, clean off immediately.



## Food Center

A built-in variable-speed motor-driven counter unit, figure 3-6, may be used with mixing and blending attachments for a large variety of food preparation tasks. The food center is designed for ac operation and is operable only when the generator is on; or when coach systems are connected to an external shoreline hookup.




Figure 3-6. Food Center

## Toaster

A two slice toaster is built in directly to the rear of the food center. After opening the door, the toaster can be run forward on its track by momentarily pushing the handle to the rear.

## Bathroom

### Water Pump Switch

Two **Water Pump On-Off** switch/indicators are provided for separate control of water pump operation. One switch is located on the control panel in the galley area; the second is located in the bathroom. The pump may be operated **On** or **Off** from either location. The associated indicator is lit whenever power is being supplied to the pump. Setting either switch **On** pressurizes the water system, with the pump operating on demand to maintain constant pressure. Continuous or erratic pump operation can indicate an empty water tank, system leakage, or air lock in hot or cold water lines. (Air locks are normally caused by movement of water in the tanks during pump operation.) Since

tank water level and water pressure can vary with road movement, leave water pump switch **Off** while the coach is moving. The water pump and air accumulator are located in the bed base cabinet.

## Tub/Shower Unit

The combination tub/shower unit, figure 3-7, includes a pressure-balancing single mixing valve, tub water spout with shower head diverter button, shower head and drain lever.




Figure 3-7. Shower Stall

## Toilet

The toilet, figure 3-8, operates from the fresh water supply, flushing wastes directly into the sewage holding tank. The double-flush foot pedal located at the bottom of the bowl controls the amount of water delivered into the bowl and opens the sliding valve to the tank. After use, depress bowl drain pedal until water swirls, draining wastes into tank, then release pedal. A water-saver feature, consisting of a manually-operated spray hose, is located at the side of the bowl. To raise the level of water in the bowl, press on the small foot pedal.




Figure 3-8. Toilet

### Roof Vents and Exhaust Fans

Lighted exhaust fans in the living room and bath, figure 3-9, are controlled by respective switch panels. A typical panel, shown in figure 3-10, includes switches for lid, light, and fan control.




Figure 3-9. Lighted Vent/Exhaust Fan




Figure 3-10. Exhaust Fan Control Panel

The **Lid Up-Down** switch raises or lowers (closes) the outside lid, the **Fan On-Off** switch controls fan operation; and the **Light On-Off** switch controls the operation of the built-in ceiling light.

### Bathroom

In addition to the exhaust fan previously described, with control panel above the lavatory, a combination vent/exhaust fan is included in the ceiling above the tub/shower. To operate the vent/exhaust fan, figure 3-11, push up on handle to open roof vent, then press switch to turn on fan motor.

### Kitchen

Another combination vent/exhaust fan (figure 3-11) is installed in the ceiling above the range. Operation is the same as the fan in the shower.




Figure 3-11. Bathroom Shower and Kitchen Vent/Exhaust Fan





## Heating Systems

Three types of comfort heating systems are used in your motorhome: gas/hot air heat; electric heat; and engine hot water circulating heaters.

Three gas/hot air furnaces are used in the coach. Each unit has a separate zone thermostat, figure 3-12.




Figure 3-12. Heater Thermostat

One furnace is located in the living room, another is in the galley area, and the third in the bedroom. The living room furnace is also used to supply hot air to the bathroom via a separate duct booster fan controlled by a thermostat in the bathroom.

Separate heating can also be provided by circulating hot-water heaters which function through engine coolant heat exchange when the engine is operating and the **Winter-Summer Heat Selector** switch is (located on the upper left auxiliary dash) in **Winter** position.

Four electric convection heaters (120 volt) are located in the bedroom, bathroom, galley area, and living area. **On-Off** thermostat switches are located on each heater. Two freeze-protection heaters (120 volt) are installed to protect plumbing and water supply tanks.

### Note

**Bathroom electric heater is standard; others are optional.**

## Gas/Hot Air Furnace

To operate the furnace, proceed as follows:

1. Turn manual valve (in refrigerator vent opening) to **Off** position and wait five minutes. Set thermostat to lowest setting.
2. Open manual valve. Correct furnace operation depends on this valve being fully opened; never operate the furnace with this valve partially open!
3. Set thermostat at desired position. Main burner will light within 15 seconds and furnace will then operate automatically. Switch at bottom of thermostat must be **On** (to the right).

When coach temperature drops below the thermostat setting, the internal relay contacts close to operate the main burner. The air flow created by the blower closes an air-actuated switch that, in turn, energizes the main burner gas line solenoid valve which then lights from the electronic ignition.

## Caution

**Do not store items in or near the burner compartment.**

When the coach temperature exceeds the thermostat setting, the relay contacts open. This shuts off the burner gas supply but the blower continues to operate until residual heat within the furnace is dissipated, when a thermostatically-controlled relay turns off the blower. Air for the sealed combustion chamber is pulled in from outside the coach, routed around the heat exchanger, then exhausted through the same vent. Recirculated fan-forced air blowing across the heat exchanger is used to heat the coach interior.

Switch at bottom of thermostat must be **Off** (to left) if operation of furnace at lower temperatures is not desired.

## Hot-Water Heating Systems

Four sources of hot water heating are provided which depend on heat generated from engine operation. One heater (90,000 BTU), which serves the pilot's and co-pilot's area, is controlled by the **Front Heat** switch on the dash. Three chassis heaters, (50,000 BTU) under the dinette seat, living room sofa, and in the bedroom are controlled by the **Chassis Heat** thermostat located on the curb-side wall over the half closet.



The engine coolant is normally routed through the engine cooling system and the water heater, which also can be heated electrically, to provide the hot water supply for the coach. However, by operating the **Winter-Summer Heat Selector** switch, the engine coolant can also be diverted through the previously-mentioned area heaters, via a solenoid valve. The coolant level in the engine radiator should be checked after these valves are opened. A pump is used to circulate hot water through the coolant lines. It is controlled by the **Aux. Pump** switch (located on the upper left auxiliary dash).

Chassis heater blower motors (dinette seat, front sofa and bedroom), are controlled by **On-Off Heat** switches adjacent to the heater louvers. **Hi-Lo** blower speed switches are also provided. The front heater is equipped with three squirrel-cage dual-speed blowers, operated from separate dash controls. One blower provides defroster air; one provides air to the pilot's side; the third provides air to the co-pilot's side. Use **Defrost Hi-Off-Low** switch for setting the defroster blower speed; use the left and right **Hi-Off-Low Heat** switches to control air flow to the pilot's and co-pilot's sides, respectively. To supply heat, the dash **Front Heat** switch must be **On**.

### Note

If additional defrosting action is needed, turn auto air conditioning temperature control to the warmest position and turn auto air conditioning fans to highspeed. This will circulate additional warm air about the windshield area.

Engine heat is picked up by the engine coolant which is pumped through the heaters inside the coach and back into the engine. A typical heater consists of a heat exchanger, or core, and a fan which moves the air across the core, transferring heat from the engine coolant into the room.

### Heating System Operation

Satisfactory performance of the hot-water circulating type of heating system depends on the following conditions:

1. Engine Coolant Temperature — Coolant temperatures vary between 180 and 195 degrees F, during normal engine operation.

2. Coolant Flow — Coolant flow varies with the engine speed. Setting the **Aux. Pump** switch (located on the upper left auxiliary dash) to **On** turns on the auxiliary pump to increase the coolant flow through the system. This feature may also be used to reduce engine overheating during normal driving conditions.

3. Proper Fan Operation — All fan motors are two-speed and can easily be checked for proper operation by listening to the motor speed change as the switch is operated.

More heat will be generated by the engine when it is also used to move the coach. Be sure that the engine radiator is full and that all coolant flow valves are open. Warm engine to operating temperature and set heating system switches as follows:

- 1) **Winter-Summer Heat Selector** to **Winter** position;
- 2) **Aux. Pump** to **On**;
- 3) **Front Heat** switch to **On**;
- 4) Left and right **Heat** blower switches to **Hi** or **Low**;
- 5) **Thermostat** to desired temperature.

### Duct Booster

The duct booster system, installed in the hot air duct between the living room furnace and bathroom, is controlled by a separate thermostat in the bathroom. The hot air vent is located at floor level, below the bath tub seat. Note that the living room furnace must be running for the duct booster to operate.

### Electric Heaters

Optional electric forced-air heaters (120 volts) are located in the bedroom, bath (standard), galley and living room areas. Each heater is controlled by a combination **On-Off** switch/thermostat. Heater operating voltage is provided from the same switches which control the air conditioners. Air conditioner **On-Off** toggle switches, on the TV control panel above the pilot, must be in **On** position and individual **A/C** switches **Off**.

### Freeze Protection Heaters and Heat Tape

Optional freeze protection heaters (120 volts) are thermostatically-operated to turn on and protect the water supply tanks and associated plumbing in the event that temperatures drop below 40°.



Two heaters are used; under the kitchen sink and within the bed base cabinet.

Two thermostatically controlled heat tapes (120 volts) are run on the copper water tubing and then wrapped with insulation. The heat tape for the kitchen/bathroom is plugged into the refrigerator receptacle as is that for the bedroom. Heat tapes start to heat at 36°F and stop at 43°F.

### **Note**

**This freeze protection will greatly decrease the chances of frozen water lines provided the coach is plugged into outside power (one 50A. or two 30A. power cords) or the generator is run continuously during cold weather periods.**

### **Hot Water Supply Heater**

The electrical hot water supply heater has a 10-gallon capacity and the heater core is also a part of the engine cooling system loop. When the engine is operating, the heat exchanger ensures a constant supply of hot water at about 150 degrees F. In addition, the water supply can be electrically heated by electric coils in the heater unit. The 120 volt, ac-operated, heater is controlled by an **On-Off** pilot switch in the bed base front. This heater can be operated only when the shoreline is connected, or when the generator is running.

### **Caution**

**Be sure that the electric heater element is turned Off if there is insufficient water in the tank.**

### **Dry Tank Switch – Water Heater**

In order to preclude the possibility of water heater element burn-out, a dry tank sensor circuit has been added in 1984 model coaches

This circuit consists of a sensor in the outlet of the hot water tank which sends a signal through a printed circuit board to energize a relay whenever the tank is not full.

When the 12 volt coil of the relay is energized, it breaks the 120 volt ac circuit to the heater element.

### **Central Air Conditioning Systems (Standard 35 foot Coaches)**

Conditioned air is maintained throughout the coach by three interior 14,000 BTU air conditioner units. Each unit provides variable-speed fan cooling operation for high velocity air movement through individually-controlled outlets. Air conditioning cool-down occurs faster if all windows, doors, and vents are closed after initial purge of warm air.

Maximum air conditioning efficiency also depends on the outside temperature and operating voltage level. Because the air conditioners represent the largest load for the electrical system, never start more than one unit simultaneously. (Air conditioner starting current can be much greater than the normal operating current.)

### **Caution**

**To ensure the full efficiency of the air conditioning units, periodic removal and washing of the air conditioner filters is recommended. This is easily done by removing the filters from the retaining screens, washing in a warm soapy solution, rinsing and drying with paper toweling, then replacing filters and screens.**

If an external ac hookup is being used, and the system is not operating efficiently, this may be caused by low shoreline supply voltage or a low-amperage-rated supply. (Check power line voltage monitors.) Starting the generator and switching over to generator operation will supply enough power to ensure correct air conditioner operation.

Before starting the generator, check that each air conditioner is off to prevent the generator from starting under load. Allow generator to warm up to the proper voltage and frequency before turning on the air conditioner(s).

The ac power supply to each air conditioner control panel can be remotely switched **On** or **Off** from the driver's compartment by the **Front A/C**, **Center A/C** or **Rear A/C** toggle switches located in the control panel above and to the left of the driver. These toggle switches operate 12-volt dc relays which, in turn, control the 120 volt ac supply to the respective central air conditioner units. Once the remote switches are **On**, each air conditioner can



be controlled locally from its own control panel. Note that the individual heater switches throughout the coach must be in **Off** position before operating the air conditioners.

### Control Panel

A typical control panel for a central air conditioning unit is shown in figure 3-13. Operation is as follows:

**Off-Start-Run Switch** — Applies power to system for fan operation (**Start** position); and next activates compressor (**Run** position).

### Note

**Do not turn the compressor off and on without allowing a few minutes delay between switching. This will prevent overloading the compressor motor.**

**Fan Switch** — Variable-speed fan motor control. Set as desired for normal operation; set between mid-range and **High** for higher cooling capacity.

**Thermostat Control** — Clockwise rotation provides greater cooling; set as desired.




Figure 3-13. Air Conditioner Controls

### Systems Monitoring and Control Panel

The systems monitoring and control panel, figure 3-14, is located on the rear galley wall. This one panel provides a convenient means of displaying inside and outside temperature, time, level of potable water supply, holding tanks, and LPG supply, as well as other monitoring and alarm functions discussed in the following paragraphs.




Figure 3-14. Systems Monitoring and Control Panel

### Clock/Thermometer

The clock/thermometer, figure 3-15, provides, on demand, a digital display of inside and outside temperature, digital time display, and an alarm function. Operate the panel controls as follows:




Figure 3-15. The Thermometer and The Clock

1. Monitor inside or outside temperature ( $^{\circ}\text{F}$ ) by pressing the **Temp In** or **Temp Out** buttons. There is an internal adjustment, at the rear of the unit, which may be used to calibrate the temperature readings. (Calibration of this unit is described in Section VIII.)
2. Set the clock by depressing the **Fast** or **Slow Set** button until the correct time is shown. **PM** is indicated by lighted dot in the upper left corner. The dot in the center of the display marks the seconds.
3. Set alarm as follows: depress **Alarm Display** button then depress the **Fast** or **Slow** button to set the alarm time. Dot in upper left corner will light when alarm is set for **PM**. After setting the



alarm, release **Alarm Display** button to return to the normal time mode. To activate the alarm feature, depress **Alarm On/Off** button to **On**; to shut off the alarm, depress **Alarm On/Off** button and release so it pops out to **Off**.

### Note

**When 12 V. power has been interrupted (batteries disconnected or Electronic Master switch turned off) clock display will flash "12:00". Reset clock to eliminate flashing. Alarm will also have to be reset.**

### Tank Monitor

The Tank Monitor panel, figure 3-16, provides an illuminated readout of the content level of the pure water, gray and waste water tanks, and the LPG tank level. When full, each of these tanks has the following capacity: pure water supply, 96 gallons (See Table 8-4); gray water holding tank, 56 gallons ; body waste tank, 50 gallons (40 gallons for 31 and 33 foot coaches); and LPG tank, 43.5 gallons (148 lb.). Use the features of this panel as follows:




Figure 3-16. Tank Monitor Panel

1. Monitor **Pure, Gray or Waste Tank** levels by depressing the respective button. The content level remaining in the tank is indicated by five sets of lit readings. The E lamp, at the left of the display, is lit all the time; if the next indicator is lit, the level is approximately 1/4 tank; if the center indicator is lit, tank level is between 1/2 and 3/4 full; if the 3/4 indicator is lit, tank level is between 3/4 and full; and if the F indicator is lit, tank level is full. If only the E indicator is lit, the tank level is between empty and 1/4.
2. LPG tank level can be monitored in the same

manner as the water tank level by depressing the **Propane Tank** button. Note that this display is pre-calibrated. However, if it is necessary to recalibrate the display, this can be done when the tank is full by setting a rear-panel adjustment. Note that the display will read **Full** when the LPG tank float reads 80% because the remaining 20% volume is needed for expansion.

### Gas/Smoke Alarm

The gas/smoke alarm, figure 3-17, is a gas leak detector designed to sense dangerous concentrations of LP gas or carbon monoxide within the coach. There are four (4) sensors mounted at floor level (LP gas is heavier than air) for the three furnaces and the refrigerator. One sensor is located above the 120 volt ac distribution panel (load center) to monitor carbon monoxide. Carbon monoxide, of course, is the most deadly of the products of combustion. It will provide an alert in the event of a short circuit, at the load center, causing an electrical fire.




Figure 3-17. Gas/Smoke Alarm

The alarm has been factory-calibrated to an alarm point of 2,000 PPM propane for standard conditions (temperature, 20 degrees C +/- 2 degrees; relative humidity 65% +/- 5%). This provides for a minimum of false alarms consistent with providing reasonable safety.

The sensors have a long life and high reliability. In normal use, recalibration or replacement will not be necessary for 5 years or longer.

To turn on the unit, set **On-Off** switch to **On** and observe that **Power On** indicator is lit. Excessive propane PPM conditions are indicated by the sounding of the audible alarm and lighting of an indicator associated with the danger area. The



alarm, if left turned off for a period of time, has a warmup period of about one minute. During this time, the alarm may sound. This is a normal response and should stop once the unit is warm.

### A/C Voltage Monitor

The dual-channel power line monitor, figure 3-18, continuously monitors ac line voltage and shoreline hookup(s) polarity. Each channel includes an expanded-scale ac voltmeter, reading from 90 to 130 volt ac, a **Polarity Normal** indicator (green), lit whenever the shoreline hookup is properly connected and grounded and line polarity is compatible with coach wiring and a **Polarity Reversed** indicator (red) which lights when hookup is reversed. Note that shaded area on the meter face indicates normal voltage range.

A faulty ground connection is indicated if none of the LEDs is lighted.




Figure 3-18. A/C Voltage Monitor

### Waste Odor Control Panel

This panel, figure 3-19, controls the cycling and electrolysis action of two pairs of stainless steel electrodes contained within the body waste holding tank. A 12-volt current is passed between each pair of electrodes for a 16-minute **On** period (green LED); and switched off for a 48-minute **Off** period (red LED). For each cycle, the current is reversed so that the electrolytic action does not excessively erode the steel electrodes.

As current flows through the waste liquid, it oxidizes the organics and eliminates associated odor. To increase odor control effectiveness, a tablespoonful or two of salt may be added through

the toilet if desired.

The electrodes (probes) are replaceable.




Figure 3-19. Waste Odor Control Panel

### Digitell Monitor

The Digitell is a verbal information system that supplements a number of informational and warning indicator components.

In addition to the main control center at the dinette, Figure 3-20, command stations are located near the pilot and co-pilot, in the bathroom and in the bedroom overhead panel.




Figure 3-20. Digitell Control Center

Operating features are selected by a ten-position thumbwheel with functions as follows:

#### Switch

#### Position / Function

- 0 / Set Hours for Time
- 1 / Set Minutes for Time
- 2 / Set Hours for Alarm
- 3 / Set Minutes for Alarm
- 4 / Time on Command
- 5 / Time on Command with Alarm
- 6 / System Functions/Time on Command
- 7 / System Functions/Time on Command/ with Alarm
- 8 / Elapsed Time
- 9-F / Not used

Note that positions 1 through 5 apply to time-keeping functions which operate continuously and



are independent of the remaining functions.

Set in **Time** in hours by setting the thumbwheel switch to 0 position, then press the pushbutton until the correct hour is announced. Repeat for minutes (switch position 1), alarm hours (switch position 2) and for alarm minutes (switch Position 3). Announce **Time** by setting the thumbwheel switch to position 4 and press the pushbutton. Announce **Time** and **Alarm Time** by setting the thumbwheel switch to position 5 and press the pushbutton.

**Count Elapsed Time** by setting the thumbwheel switch to position 8. Press pushbutton once to start time operation, press it a second time to announce the elapsed time. The timer will continue to measure elapsed time from zero (first time pushbutton is pressed) until the pushbutton is pressed twice in sequence. The total elapsed time will be announced and the timer will stop counting.

**Systems Monitor Functions** are accomplished when the thumbwheel switch is in position 6 or 7. The Digitell will continuously announce an alarm if any of the following conditions exist when the ignition is turned on:

1. Generator door is unlocked.
2. Leveling jacks are still down.
3. TV antenna has not been fully retracted.
4. Shoreline is still connected.
5. Headlights ("driving lights") left on (after ignition is off).

The following conditions are monitored while driving and announced at 45-second intervals:

1. Low fuel level.
2. Water in fuel.

To discontinue an alarm condition, push the command switch at any Digitell speaker command location during the announcement. (Digitell speakers are recessed behind overhead cabinetwork.)

### Generator Switch


The generator **Start-Stop** switch, figure 3-21, provides the same features as the generator switch located above the driver. Press switch to **Start** position and hold until generator starts as shown by the switch indicator light. Press switch to **Stop** to shut-down the generator (light extin-

guished). Press switch to **Stop** (and hold) for engine pre-heat.



**Figure 3-21. Generator Switch**  
**Switch and Monitor Panel**

The switch and monitor panel, figure 3-22, monitors the battery voltage level, activating an audible alarm if a low-voltage condition is present (**Low Battery Alarm**). It also monitors the refrigerator temperature when the **Refrig. Alarm** switch is **On**. Normally, the **On** indicator is lit; if the refrigerator temperature increases to an unsafe level, the **Warm** indicator lights with an accompanying audible alarm. The thermostatic refrigerator fan is controlled by the **Refrig. Fan On-Off** switch. The indicator above the switch is lit when power is being supplied to the fan. However, the fan will not operate until vent column temperature reaches approximately 100 degrees F.



**Figure 3-22. Switch and Monitor Panel**

Water pump operation may also be controlled from this panel with the **Water Pump** switch; the **On** indicator will be lit when power is being supplied to the pump.



### LP Gas Leakage Detector

The gas leakage detector, figure 3-23, is located below the refrigerator door. In the event of an LP leak, the unit sounds an alarm and closes down the main LPG supply by activating the leak detector solenoid shutoff valve located in the gas line just after the low pressure regulator. If it is necessary to reset the solenoid (red band is visible inside clear plastic valve housing), open the outside refrigerator vent compartment door, remove plastic housing by gripping locking levers and lifting upward, push valve plunger down until it remains down, then replace the cover. For continuous operation of the leak detector, set **Off-On** switch **On**; to test alarm operation, press the test switch located on top of the detector unit. Alarm must sound for at least 15 seconds before the shutoff valve will be activated.




Figure 3-23. LP Gas Leakage Detector

### Electronic Door Chime

The door chime, figure 3-24, is located on the rear dinette wall.

The door chime can be preset to play any one of 60 different tunes when the doorbell button is pressed. As shown, all controls for tune selection, volume, tone and tempo are easily accessible. Tunes may be selected as follows:

1. Refer to tune index, at bottom of chime, and note the code number for the desired tune. For example, "William Tell Overture" is identified by D8.
2. Press in the left-hand tune selector button and move it to position D.
3. Press in right-hand button and move it to posi-

tion 8.

4. Press test button to play selected tune and adjust volume, tone and tempo as desired. Note that tunes identified with an asterisk (\*) will play longer if the button remains depressed.

### Caution

**Do not use a lighted door button with this chime or chime may be inadvertently activated.**





Figure 3-24. Electronic Door Chime

### Portable Fan


The portable oscillating fan is shown in figure 3-25. The 12-volt hookup cable is coiled within the base section when the fan is not in use. This will supply air circulation within the coach when it is too cool for air conditioning.





**Figure 3-25.** Portable Oscillating Fan  
**Security Timer**

The **Watchdog** security timer, figure 3-26, is a randomly-switched electrical timer which can be used to control the on-off operation of an appliance, light, etc., to give your coach that 'lived-in' look when it is unoccupied. The three-position switch may be set to **Off**, to shut off the controlled appliance; to **On**, for manual control; or to **Security**, for random operation.



**Figure 3-26.** Security Timer

### **Burglar Alarm/Anti-Theft Features**

The security of your motorhome and contents are assured by an intruder alarm system which protects windows and entry door. Each window is protected by a magnetic proximity switch which triggers an alarm if the window is opened. The entry door uses a door jamb switch which operates when the door is opened. When the system is **secured** it may be activated from outside the coach by a key-switch adjacent to the entry door. From inside the coach, a master burglar alarm switch may

be operated at the front instrument panel.

In addition to the alarm system, an anti-theft switch for the ignition circuits (A/T switch on dash) can be operated so that the unit cannot be started. Lastly, the 12 volt **Master** switch (hidden behind the right side of the dash) can be operated to turn off all but essential 12 volt circuits.

### **Bedroom Overhead Panel**

The bedroom panel is directly above the head of the bed.

It contains two stereo jacks and a volume control, security light switch (illuminates front and rear landing lights, driving lights in front bumper, and rear Halogen parking lights), night (aisle) light switch, alarm clock, Digitell command station, and entrance door lock.

Most of these are duplicates of previously described controls and are added for your comfort and convenience.

### **Alarm Clock**


The setting procedure for this clock is identical to that on the Systems Monitoring Panel. This clock has a dimming feature and the lighted dot, marking seconds, has been eliminated.

### **Fire Extinguisher**

A portable, multi-purpose dry chemical fire extinguisher is located under the aisle end of the front dinette seat. A second fire extinguisher is located in an outside compartment. To use, release the clamp and remove the fire extinguisher from the bracket, pull safety pin from handle, squeeze handle and apply chemical under flame.

### **Intercom System**

The optional intercom system used in your motorhome, figure 3-27, is a master-to-master system so that any station can originate calls to any other station. Just lift the handset, push in the button corresponding to the called station, and carry on your conversation. Intercom stations are located on the floor to the left of the driver, in the bathroom, dinette, and on the rear bedroom wall.



**Figure 3-27. Intercom System**

### **Stepwell Area**

The stepwell cover is hand operated and is retained in the upright (stowed) position by two latches.

The **Step** and **Step Light** switches are accessible after opening the door of the stepwell compartment, figure 4-3.

The **Step Light** switch makes it possible to turn off the step lights if the step is to remain in the extended position for a time.

If it is desirable for the step to be left in the extended position, for repeated trips into the coach, the **Step** switch may be used.

### **Smoke Detector**

A smoke detector (now code mandated) is installed in a ceiling location just outside the entrance to the bedroom area. Operator instructions are attached inside the overhead cabinet where the warning label is displayed on the exterior door trim.

It is possible for the smoke detector to be activated by the cold air coming from an Air Conditioner outlet. Slight downward rotation of the outlet louvre is all that is necessary to discontinue activation.



## Section IV

# Electrical Systems

There are actually two interrelated electrical systems used in your motorhome: the 12-volt dc supply system; and the 120-volt ac supply system. The 12-volt dc supply system is divided into several branches, or zones, each functioning from the common 12-volt battery source. One branch provides the 12 volts required for the automotive starting, ignition and lighting systems; remaining branches supply those motorhome circuits and appliances which require 12 volts dc for operation.

The 120-volt ac system includes those motorhome appliances which require 120-volts for their operation, supplied from either the internal generator; or from the external 120-volt ac (or a split 240-volt ac) supply, via the shoreline hookup; or from the battery-powered 120-volt motor generator unit.

### 12-Volt DC Supply System

Wiring diagrams of the 12-volt supply and distribution system are included in Section X.




Figure 4-1. Typical Load Center

The 12 volts supplied to all motorhome appliances, outlets and accessories is routed from the batteries through a main 12-volt master switch and routed through busses to the individual branches, or zones, that are serviced from this supply. Circuit breakers are located behind the access panel at the top front left side of the coach, lower front load

center (behind left headlight panel) and at each of the zones. The circuits supplied and fuse- or circuit-breaker-protection at each zone are shown on a diagram attached to each zone panel. Copies of these diagrams are included in Section X for reference purposes. A typical load center is shown in figure 4-1.

### Battery Heaters

120 volt ac battery heater pads provide faster engine starts during cold weather conditions by increasing the available cold cranking power. Heaters operate only from the ac supply line via the **Battery Heater** switch located on the living room sofa front (behind pilot's seat).

### Note

To avoid premature deterioration of the batteries, heaters should be used only when the temperature is below 32°F.




Figure 4-2. Battery Compartment

### Battery Chargers

The 12-volt engine battery supply, figure 4-2, and the generator battery are maintained fully-charged by either the engine alternator (when engine operates); or by two 50-ampere battery charger/converters. These automatic electronic battery chargers operate whenever a source of 120 volts ac is supplied to the coach circuits. The two chargers furnish a total of 100 amperes of ser-



vice to the 12v. d.c. motorhome circuits. Chargers are in left (road) side compartment in front of rear wheels.

coach batteries.

The **DISCHARGE** ammeter, also located on the upper right auxiliary dash, shows the load drawn by coach circuits.

**ENG. VOLT METER**, located on lower dash, shows voltage at **Master** switch behind lower dash.

While in transit, this should reflect an alternator regulated setting of 14v. When parked, with 120v. source supplied, this should read between 12.5 and 14.0v. depending upon load. When parked, without 120v. source, do not permit voltage to drop below 11.5.

After a trip, **CHARGE** ammeter will show some discharge reading, even when 120v. source is supplied, if there is a load on the 12v. coach circuits. The **Float** type battery chargers allow a voltage of 12.5-13 when there is a load.

### AC Supply System

Motorhome ac-operated appliances are supplied from either an external shoreline hookup or from the on-board generator. Selection of shoreline or generator power source is determined by a four-position ac power selector switch located in the stepwell compartment, figure 4-3. Set this switch to either **Gen**, **Shore 50A**, **Shore 30A** or **Off**, depending on the power source availability. Leave this switch in **Off** position to completely disconnect the motorhome 120-volt ac circuits normally supplied by these inputs.

### Power Line Monitors

A dual power line monitor is located on the galley wall to monitor the voltage in both legs of the ac shoreline supply (or generator supply). Each monitor has polarity and ground detector circuits to indicate possible electrical hazards due to incorrect hookups.

### AC Circuit Breaker Panels

Two main ac circuit breaker panels are located within the curb-side closet adjacent to the galley closet. Refer to figures 4-4 and 4-5 for identification and location of load center distribution panel board and 30 A. shoreline circuit breakers, respectively.




Figure 4-3. Stepwell Compartment

Batteries can become discharged because of coach 12-volt loads, while parked, without a 120-volt ac source. For overnight stops this presents no problem, with judicious use of 12v. service, because the engine alternator will recharge the batteries rapidly during the next day's travel. When operating from shoreline or generator power, the batteries obtain the major portion of the charge during "sleeping" time, while coach loads are low, so that the battery chargers can "top off" the batteries.

If it is planned to leave the coach parked without exterior power for a week or longer turn off the **Electronic Master** switch in overhead cabinet adjacent to left front load center. This will ensure that there is no drain from the circuits which remain on when the **Master** (under dash) switch is **Off** (clock, memory and LPG leak detector).

### DC Supply Monitors

The **ENG. AMP. METER**, located on the lower dash, indicates the total current flow from the charging source (engine alternator or battery chargers).

The **CHARGE** ammeter, located on the upper right auxiliary dash, shows the current flow into the




Figure 4-4. Load Center Circuit Breakers




Figure 4-5. 30A. Shoreline Circuit Breakers

### Generator Operation

The generator plant has its own 12-volt starting battery so that it can be started independently of the coach 12-volt batteries.

The generator can be started and stopped from either of two locations within the coach: at the driver's instrument panel; or at the systems Monitor Panel. In addition, the generator can also be started in the generator compartment.

To start the generator, push the **Generator** switch to the **Start** position and hold until the generator starts, as indicated by the generator **On** indicator light. **Do not hold switch on for longer than 15 seconds at a time!** If the

generator does not start the first time, wait a minute and try again. Release the switch when the indicator light in the switch glows. The generator may be stopped at any time, from either of the two locations in the coach, or with the **Start-Stop** switch in the generator compartment, figure 4-6, by holding the switch to the **Stop** position until the generator stops (light in switch extinguishes).




Figure 4-6. Generator Tray

It is not advisable to start the generator under a heavy load, especially with the high current demands made by the air conditioners. This may cause hard starting and possible damage to the generator electrical system. It is a good practice to remember to set the **Main Selector** switch to **Off** (figure 4-3) before turning on the generator so there will be no electrical load on the line. Also, remember to set the selector switch to **Gen** position when the generator is being used; and to reset the switch to either **Off** or **Shore** position, as appropriate.

The generator is housed within an air operated extendable tray which is normally locked into place by a hand-latch located underside, figure 4-6. To open, unlock the latch by moving forward and extend the tray outward by operating the **Out-In Gen. Tray** switch in the stepwell compartment, figure 4-3. **Note: Latch handle for 7.5 K.W. generator is on door exterior and upward movement will unlatch.** If the ignition switch is turned **On** while the generator tray is still in the extended position, or if the tray is not locked properly, the Digitell unit will continuously announce — **Secure door on APU.**



## Caution

The generator tray is heavy and moves in and out with a great deal of force. **Keep Hands Off Tray When Operating Switch!**

### Shoreline Operation (Commercial Power)

Set the power selector switch, figure 4-4, to **Off** position **before** the motorhome electrical system and external supply are joined.

## Caution

Your motorhome has been wired in accordance with the National Electrical Code. All 120-volt ac wiring is two-wire service with ground; all 240-volt wiring is three-wire service with ground. If the motorhome is connected to an external hookup which has only a two-wire circuit, ground the third wire on the adapter to the external supply metal junction box or conduit. For personal safety, check the polarity detector indicators on the power line monitors to be sure that lines are properly connected and grounded.

For purposes of safety, observe all precautions when making these connections. First, connect the shoreline to the coach (**rotate plug clockwise to assure firm connections**) (the coach receptacles are located in the same compartment as the water hookups, in the rear pilot's side, figure 5-1); then connect it to the power source. Set the power selector switch to the appropriate **Shore** position. Poor grounding or incorrectly-wired receptacles can cause personal harm as well as equipment damage or fire hazards. Check power line monitors on Systems Monitor Panel to verify correct supply voltage, polarity and grounding of hookup.

In many instances, the shoreline hookups will not be rated to operate all electrical appliances in your coach. Check with facility personnel to determine the maximum current capability of the hookup. Sometimes, only one air conditioner may be operated. The current ratings for appliances designated for standard or optional (identified by \*) usage in your coach are listed in table 4-1.

Table 4-1. Electrical Ratings for Motorhome Appliances

Item	Current Rating (Amperes)
Air Conditioners	
14,500 BTU	(Start) 19.0
Water Heater	10.0
Television Receivers	
Black-and-white	.5
Color	1.0
Battery Chargers (depends on battery condition/load)	0 to 12.0
Engine Block Heater	10.0
Electric Heaters	
"Cheater Heater"	12.5
Battery Heaters	1.2
Heat Tapes	3 watts/ft
*Microwave Oven	14.0
Food Center	4.0
Vacuum Cleaner System	9.0
Refrigerator	2.5
*Ice-Maker	2.5
*Washing Machine/Dryer	25.0
Instant Hot Water	6.5

\*Optional item

### Shoreline Operation — Troubleshooting

Your coach is designed and tested to make sure the 120v. ac **Neutral** (white) wire and the **Ground** (bare copper or green) are not tied together (no continuity). This will prevent any danger of a "hot skin" if the source of power has reversed polarity (red LED lit).

#### Problem

— Probable Cause

— Corrective Action

#### Green LEDs lit - Normal (desired)

#### Red LEDs lit

— Reversed Polarity at power source.

— Convince park management to correct or change lot assignment.

#### Neither red or green LED lights

— No ground connection with park service

— Use jumper lead from ground pin on shore cord to service box.



Power source (park) circuit breaker trips.

- Reversed polarity in park and coach neutral and ground tied together.
- Use on-board generator until qualified electrician can correct coach problem. (Generator polarity is correct).

Green LED's lit plus Red LED's glow when additional load is turned on (Air Conditioner or Water Heater).

- Poor ground connection at park (floating ground).
- Make sure shoreline plug is fully engaged twist locked (clockwise) at coach.

### **Safeline Alarm**

Your coach is equipped with a shoreline disconnect alarm, which is located on the upper left auxiliary dash. This device will provide an audible or visual alarm whenever the shoreline is left connected to the coach at the same time that the ignition switch is turned **On**. This assures that the coach is not inadvertently driven away while still connected to the shoreline hookup. In addition to the Safeline-originated alarm, the Digitell unit will announce continuously that the shoreline is still connected.

### **Electronic Filter**

12v. d.c. power for electronic equipment is supplied directly from the coach batteries through an electronic filter to the audio-video systems and monitoring panel. This eliminates electrical noise interference.

### **Electronic Master Switch**

Most of the electronic circuits are de-energized when the main **Master** switch (behind dash) is turned **Off** (relay action). Circuits that still receive power when the **Master** switch is off serve the monitor panel, clocks, radio memory, and LPG leakage detector. If coach is to be stored for a week or more without external power, the **Electronic Master** switch in overhead adjacent to left front load center should be turned off.

### **Battery Jumper Terminals**

For your convenience and safety when jump starting (usually someone else's vehicle), terminal posts are provided at the top front of the battery compartment, figure 4-2. Utilization of these terminal posts is described in Section VIII.







## Section V

# Water Distribution and Drainage Systems

Your motorhome is equipped with a completely self-contained water system which includes piping, heating and drainage facilities similar to those used in home installations. The water supply and distribution system includes three networks: (1) a potable water supply system, which includes the water tanks, pump, air accumulator, pressure switch, water purifier and input supply lines; (2) water heater and interior hot water heating systems; and (3) waste, winterizing, quick drain and sewage drainage systems. Refer to Section X for potable water system and plumbing drainage system piping diagrams.

### Water Supply and Distribution System

As shown in figure 5-1, the dual purpose **Tank Water Fill/Commercial Water** inlet connection is located in the rear utility compartment. The **Tank Fill On-Off** switch controls a solenoid-actuated water valve to divert the commercial water input to fill the pure water storage tank(s). Located beneath the rear bed(s), the tank(s) are non-pressurized types so that system water pressure is developed by pumping action directly into the supply lines, rather than by tank pressurization. A bacteriostatic water purifier system purifies the cold-water supply to the cold-water taps in the galley sink and bathroom lavatory, ice-maker and Konstant Hot water tap.

### Commercial Water Hookup

When facilities are available, the **Commercial Water** hookup can be used to supply all coach water system requirements. In this manner, the coach water tank and pump system is automatically bypassed by the supply line check valve and water pressure is developed by the external connection. Water input pressure is regulated by a 40-pound in-line valve.

### Note

The **Tank Fill** switch should be **On** only when the water tank is being filled. This switch must be in **Off** position at all other times.




Figure 5-1. Location of Commercial Water Hookup

### Filling and Sanitizing


**Filling the Tanks** — To fill the water supply tanks, connect the water hose to the commercial water inlet, set **Tank Fill** switch to **On**, then turn on the water supply. When the tank is full, as indicated by water overflow beneath the coach, set the **Tank Fill** switch to **Off** position, shut off the water supply and disconnect the hose. At this time, check that the Monitor panel readout on the galley wall indicates a full water tank. To check, press the **Pure** tank switch and observe that the **E** through **F** indicator segments are lit.

**Sanitizing the Water System** — Since the only source of potable water in the motor home is contained in the supply tank(s), it is extremely important that this water supply be as free as possible of impurities and contamination. Accordingly, water tank sanitizing procedures should be followed before the tank is filled for the first time; after long idle periods, where water may become stagnant; or after any suspected contamination of the water supply. Whenever possible, use a commercially-approved tank sanitizer and follow the procedures on the product package. If it is not possible to use a commercial product, prepare your own mixture and sanitize the tank in accordance with the following procedures:

1. Empty the Water Tank(s) — To drain tank(s),



set the **Water Tank Drain** control (on the control panel in the bed base cabinet) to **Open**, figure 5-2. After tank(s) is completely drained turn **Water Tank Drain** control to **Closed**.



**Figure 5-2.** Water Purge Air Pressure, Water Heater Drain and Water Tank Drain Controls

2. Prepare the sanitizing solution using  $\frac{1}{4}$  cup of household bleach (sodium hypochlorite solution) for each gallon of water. Use one gallon of the solution for each 15 gallons of tank capacity. This procedure will result in a residual chlorine concentration of 50 ppm in the water system. If a 100 ppm concentration is required use  $\frac{1}{2}$  cup of household bleach with one gallon of water to prepare the chlorine solution. Nine gallons of solution will be most adequate for the largest tank(s) (128 gallons).

3. Add sanitizing solution to water tank(s) — Disconnect overflow hose from tank(s) and pour solution into vent fitting. A curved piece of  $1 \frac{1}{4}$  I.D. hose, clamped to the vent fitting, will facilitate this process. Reconnect overflow hose.

4. Fill tanks to Capacity — Connect the hose to the commercial water inlet, set the **Tank Fill** switch to **On** and fill water tank(s) completely. Shut off hose, and set **Tank Fill** switch to **Off**. Turn on water pump. Open each faucet (hot and cold) and run the water until a distinct odor of chlorine can be detected. Shut off water pump.

5. Allow the system to stand for at least 4 hours when disinfecting with 50 ppm residual chlorine. If a shorter time period is desired, then a 100 ppm chlorine concentration should be permitted to stand in the system for at least 1 hour.

6. Drain Tank(s) — Open the **Water Tank Drain** control and allow the tank(s) to drain completely.

7. Refill Tanks — Close the **Water Tank Drain** control, and turn on the water supply to the commercial water inlet, set **Tank Fill** switch to **On** and fill tank(s) completely. When the tanks are full, set **Tank Fill** switch to **Off**, shut off water supply and disconnect hose, replace fill cap and turn on water pump. When water flows from opened faucets, close them and open other faucets until water flows. This flushes the system, removing trapped air from the piping and ensures that the fresh water supply is ready for use.

### Note

**Residual tastes or odors can be removed by again draining and rinsing the system with a vinegar solution mixed to the ratio of one quart of vinegar to five gallons of water.**

### Potable Water Distribution System

The major components of the potable water distribution system are the water tanks, water pump, air accumulator, water heater, piping and fixtures. In addition, a bacteriostatic water purifier is connected in the cold water supply line to the galley sink, lavatory, Konstant Hot tap and ice-maker (option).

The air accumulator and water pump are located below the kitchen counter as shown in figure 5-3. The water purifier is behind location for optional ice-maker, and water tank drain valve is located under the bed.

### Water Pump

The water pump, figure 5-3, is equipped with a factory-calibrated pressure control switch which is preset to turn the pump on when the system pressure falls below 20 psi; and turn the pump off when the pressure reaches 35 psi. If the pump has been out of service for a period of time, it is advisable to open a faucet before turning the pump on. This will allow for easier starting by reducing the pump starting load. When water flows steadily from the opened faucet, close faucet and observe that pump shuts off when system becomes pressurized. (it may also be necessary to bleed the air from the other faucets as well.) When the potable water supply tank(s) level is low, or empty, shut the



pump off to prevent possible damage to the pump motor. In addition to integral motor overload protection, the pump mechanism is also protected from jamming by the presence of an inline filter (pump guard) between the pump and the supply tank.




Figure 5-3. Water Pump Location

### Water Purifier

The bacteriostatic water purifier, figure 5-4, filters and purifies the potable water supply to eliminate tastes, odors and coloration produced by chlorine, rust, insecticides, detergents, sediment and other foreign objects. All water-borne disease-carrying bacteria are neutralized and removed from the water supply through bacteriostatic action. This is accomplished by a hygienic filter bed which consists of silver ions absorbed on sponge silver metal which is deposited in a finely divided form on activated carbon of high surface area.

The water purifier is a self-contained unit requiring no routine or periodic maintenance.

Each time the filtered water supply is used for drinking or cooking purposes, run the tap for a few seconds to clean out the line prior to using the water. This is particularly important if the water tap is not used on a daily basis. If the water supply has not been in use for extended periods, allow the water to flow for several minutes before use.

**Filter Material Replacement** — The filter material used in the purifier will process 75,000 gallons of water before replacement. Refer to the manufacturer's service manual for maintenance and replacement procedures.

### Water Heater

The 10 gallon Marine Electric Water Heater has a "motor aid" heat exchanger to ensure a supply of hot water while in transit and upon arrival at your destination. Engine coolant circulates through this heat exchanger as shown in the chassis heater piping diagram in Section X. The electrical heater can be used whenever 120 volts ac is available. The heater switch, located in the bedfront, should be switched **Off** when heated water is not needed.

### Drainage System

A diagram of the drainage system is provided in Section X. Separate holding tanks for gray water (56 gallons) and waste (50 gallons - 40 gallons for 31 and 33 foot coaches) are located beneath the coach mid-section. The gray water holding tank is the receiver for the gray water from the kitchen sink and the shower. The waste holding tank stores toilet wastes and waste water from the bathroom lavatory. Each holding tank has a separate drain valve, dumping gray water and wastes through a common single discharge connection on the road (left) side. Separate vents from each holding tank extend through the roof of the coach.

### Draining the Holding Tanks

The waste holding tank is drained first, then the gray water tank. Drain the holding tanks as follows:

1. Check that both drain valves are in a closed position before removing drain cap. Note that the valve handles are turned clockwise to lock the valve.




Figure 5-4. Location of Holding Tanks Drain Valve

2. Remove the safety cap from the single dis-



charge connection by turning the locking ring in a counter-clockwise direction and connect the 3-inch sewer hose coupling to the end of the valve. Tighten locking ring securely, in a clockwise direction. The sewer hose is stored within a tube accessible through a compartment door located above the drain cap, figure 5-4. Place the discharge end of the hose into the sewer connection and check that all connections are secure to prevent accidental spillage.

3. Open the drain valves, by turning the handles to the left (counterclockwise) to unlock, then pull the handles straight outward.

4. After contents are emptied, flush out holding tank to dislodge remaining solids.

### Note

**To clean the holding tank, add a detergent solution into the tank after it is emptied. The agitating action from vehicle movement will clean the tank.**

5. Close drain valves by pushing handle inward and turning to the right (clockwise) into the locked position.

6. Disconnect and wash out drain hose, replace hose and replace safety cap securely.


### Tank Level Detectors

Each of the holding tanks and the potable water supply tank has a level detector which provides an electrical input to the Systems Monitor panel on the galley side wall. Activate the display to read the level of liquid remaining in each tank by pressing the appropriate pushbutton switch.

### Winterizing

To prevent freezing of water supply lines, they are wrapped with heat tapes that operate automatically when the temperature drops below 38 degrees F. The heat tapes are connected to the ac outlets in the rear of the refrigerator compartment and behind the kitchen sink base.

If you are planning on storing your motorhome in an unheated area during cold weather, it will be necessary to winterize the water system to prevent damage from freezing conditions. Winterizing procedures are covered in the following paragraphs.



**LOW POINT DRAIN VALVE**

**Figure 5-5. Lavatory Plumbing**

### Draining and Winterizing the Fresh Water Supply System

The following procedures show the use of the various drain valves, controls and pressurized air system to remove the water from the plumbing and appliances in the fresh water supply system. Refer to figures 5-2 through 5-5 for the location of controls and valves.

1. Open the main circuit breaker box, figure 4-4, and set the **Water Heater** and **Konstant Hot** switches to **Off**.

2. Set **Water Pump** switch to **On** and open all faucets (galley sink, lavatory, shower, outside hose connection and toilet water valve — after depressing pedal insert block to maintain position). Note that the outside water hose connection should always be left open when freezing temperatures are expected. Also, remove thumbscrew from bottom of toilet valve, and drain screw at bottom of **Konstant Hot**. If equipped with Ice-Maker refer to **Draining the Ice-Maker** below.

3. Open the low-point drain valve located beneath the lavatory, figure 5-5.

4. Turn the **Water Tank Drain** control to **Open** position, and the **Water Heater** switch to **Drain** position. Both controls are located on a panel in the bed base cabinet, figure 5-2.

5. Allow water to drain completely before proceeding to the next step.

6. Move the **Water Heater** switch to **Fill**.

7. Set **Water Purge Air Pressure** switch, figure 5-2, to **On** to activate the solenoid which applies air pressure to the input water line to purge the



water system. Note that it may be necessary to start the engine to build up air pressure. An air hose must be connected momentarily to the valve fitting on top of the accumulator, figure 5-3, to be sure that no water remains.

8. When only air remains in the line, close both low-point drain valves and all faucets except the cold water galley sink faucet. This will ensure that the water purifier is cleared of residual water. Momentarily operate the Konstant Hot instant water heater valve to clear the heat exchanger of remaining water.

9. Turn **Water Purge Air Pressure** control to **Off**, set **Water Pump** switch off, and shut down engine.

10. Disconnect both hoses from the water pump to prevent residual water from backing up into the pump.

11. Open all faucets slightly, open both lowpoint drain valves and toilet valve.

12. Drain the holding tanks and add RV anti-freeze (several quarts) to each tank through the toilet (into the sewage tank); and through the galley sink (gray water tank).

13. At this point, the only water remaining in the system is contained in the U-traps (P traps) beneath the lavatory and shower drain. To prevent this water from freezing and damaging the traps, pour one pint of RV system anti-freeze into each trap.

**Draining the Ice-Maker** — If your motorhome is equipped with an ice-maker it will also have to be drained so that no water remains in the line or ice-making mechanism.

1. Remove the cover from the bottom compartment and turn the switch **Off**.

2. Disconnect the water line from the solenoid valve fitting.

3. This line must be blown free of water, and can best be done while clearing the purifier in step 8 above. Do not reconnect the water line at this time.

4. Turn **On** the ice-maker and allow it to operate until all remaining water is drained (approximately one hour). Remove any water remaining in the ice-maker mold, drip tray, or cube compartment.

5. Turn ice-maker **Off**, reconnect water line, and

leave door slightly ajar to prevent interior humidity build-up from corroding the ice-making mechanism micro-switches.

### **Battery Storage in Freezing Weather**

Batteries that are not kept full-charged must be given protection against freezing. Partially-charged batteries will freeze at low temperatures, so batteries must either be left charged or removed from the vehicle and stored in a warm location.

The motorhome can be left connected to the shoreline ac supply and the coach battery chargers will keep all batteries charged. Note that even in a warm location it is advisable to keep the batteries charged to prevent deterioration. The four main coach batteries should be checked for proper electrolyte level: add water, as required. The battery used for the generator is a sealed battery.

### **Note**

**Remove all items from the coach which may freeze, including canned foods, miscellaneous liquids, etc. Remove all contents of the refrigerator/freezer, clean unit and leave doors ajar.**

### **General Storage Notes**

Drawing draperies will reduce fading of rugs and upholstery. Leaving an air freshener agent will minimize odors from plastics and other materials. Slight opening of windows and vents will allow air circulation without worry of water entering. Covering wheels to eliminate direct rays of the sun on tires will reduce sidewall cracking.





## Section VI LPG System

The coach is equipped with a permanently mounted 43.5 gallon (148 pounds of fuel-net) LP gas tank which is the energy source for the range/oven, three gas furnaces and alternate source for the refrigerator. A piping diagram of the LPG system is shown in Section X.

### LPG Tank and Controls

The LPG supply tank is located in a curbside compartment, as shown in figure 6-1. LPG system controls include a main gas service valve, high pressure regulator, filler connection with Auto Stop (80%) fill valve, 80% (stop filling when liquid appears) valve, and the pressure relief valve.

A flexible hose from the high pressure regulator connects to tubing which carries the LP gas to the refrigerator vent compartment. Conveniently located in this compartment are the low pressure regulator (set at 11 inch water column), manual shut off valve, electrical solenoid shutoff valve, and manifold to individual appliance shutoff valves shown in figure 6-2.

The solenoid valve is actuated by either a high-pressure condition (caused by a defective regulator), or by the remote LP leak detector, located below the refrigerator door. Tank level can be monitored at the Systems Monitor panel on the galley wall. To read the digital display, press the **Propane Tank** button.




Figure 6-1. LPG Tank Compartment

### Caution

**Be sure to shut off all gas appliances before filling the LPG tank. Check gas lines and fittings periodically for tightness and leakage.**

### Fuel Requirements

Liquefied petroleum gas is a material composed of various hydrocarbons such as propane, butane, or a mixture thereof. In its gaseous form (vaporized) it is colorless and has a garlic-scented additive to ensure detection. In addition to being highly inflammable, it is also dangerous to inhale. For ease of transportation and storage, LPG is compressed into a liquid state and stored, in this form, within the LPG tank. As fuel is used, vapor passes from the top of the tank, via the high-pressure regulator, to the low-pressure regulator, and to the various gas appliances.

Appliances will not function if the LP gas does not vaporize. Butane will not vaporize below 32 degrees F. (the freezing point of water), but propane will continue to vaporize down to 44 degrees below zero. Propane has become the main type of LP gas used in RV's in recent years. Your LP supplier will have the correct type or blend for your locale. If your travels will take you into an area where climate differs, ask your LP dealer for his recommendations. The names of LP suppliers can be found in the yellow pages of your telephone directory under "Gas-Liquefied Petroleum - Bottled & Bulk".



Many campgrounds now have LP gas fill facilities, as do some service stations.

Prevent condensation and possible regulator or line freeze-ups, when filling the tank, by requesting the dealer to add a small amount of Methyl Alcohol to the fill-up. A common mixture is one ounce of Methyl Alcohol to each 20 pounds of LPG.

### Filling the LP Gas Tank

When the tank is being filled, the Service valve must be **Closed** and the 80% liquid level valve must be **Open**. The 80% **Auto** stop fill valve may close before liquid appears at the 80% liquid level valve, but if liquid does appear, stop filling immediately; the tank is filled to its LP capacity. Close the liquid level valve. Do not use a wrench to tighten this or the **Service** valve; they are designed to be closed leak-tight by hand. If you cannot hand-tighten properly, the valve probably needs repair or replacement.

### LP Gas and Vapor Detectors

The Gas/Smoke alarm, on the galley wall, monitors various locations through the coach and sounds an alarm if the safe amount of LP gas or carbon monoxide in air is exceeded. The LP gas leakage detector below the refrigerator door monitors the area near the refrigerator and the range, sounding an alarm and actuating the LP gas solenoid shut-off valve if a leak is sensed.

### Regulator Pressure

The low-pressure regulator, located in the refrigerator compartment, figure 6-2, regulates the pressure of the LPG supplied to the appliances. The regulator functions automatically and is factory-preset to provide the correct line pressure. **Do Not** attempt to tamper with or reset the regulator! Even a small variation above the normal gas line pressure can be sufficient to create a dangerous situation and cause possible damage to individual appliance components. If there is any doubt about the regulator setting it can be checked by your Wanderlodge® dealer or LPG supplier. The correct setting is 11 inch water column.

### Operation

To operate any LPG appliance, the main gas (Service) valve, figure 6-1, must be **Open** as well as the individual appliance valve in the refrigerator vent compartment. The range also has a shutoff

valve behind the range top. When first used, or after a refill, there may be some air in the gas lines which will escape when you open a range burner or similar LP gas valve. The air may extinguish your match or igniter the first time or two, before you get ignition. Remember, too, that when you close the tank's Service Valve some of the gas will remain in the lines. To completely bleed the lines of gas, **Close** the tank's **Service** valve and light a range burner to use up the excess. When the flame burns out, turn the range burner **Off**.

### Checking For Leaks

Periodically check the LPG system for possible leakage. Do not wait for an alarm condition to occur before correcting a leak! Although the entire system and associated appliances undergo extensive factory testing for leakage, road shocks and heavy vibrations may loosen or damage piping or fittings. Leaks will usually become noticeable by the characteristic odor of the garlic-scented gas additive. To check, turn off all burners and pilot lights. Open all doors and windows. Open LPG tank service valve and use an ammonia & chlorine free soap-bubble solution on all connections. Any bubbles are evidence of leakage.




Figure 6-2. LPG Low-Pressure Distribution





## Note

The gas leakage detectors may momentarily sound an alarm when the engine is initially started or when a heavy electrical load is placed on the system. Further, the ultrasensitive response of these units may also cause an alarm to be given in the presence of certain pressurized-can sprays or cleaning agents. **Do Not Assume! Always Determine the Reason For This Vital Alarm Being Given!**

### LPG Consumption

Most gas appliances are intermittently operated. However, operation during cold weather conditions does cause a heavy use of the gas furnaces. Extensive oven usage also consumes a great deal of fuel. The amount of LPG consumption depends on the total use and manner of use of these appliances.

Note that each gallon (4-1/4) lbs of LPG fuel produces approximately 91,500 BTU's of heat energy. The LPG tank used in your coach will furnish over 3 million BTU's.

For your guidance in estimating your anticipated fuel consumption, the following is a listing of typical appliance consumption ratings when the appliance is operated for one hour:

Refrigerator	1,500 BTU's
Range Oven	10,000 BTU's
Range Top Burners	5,200 BTU's
Furnaces (3)	16,000 BTU's Each

### LPG System Warnings

#### Warning

**LP gas containers shall not be placed or stored inside the vehicle. LP gas containers are equipped with safety devices which relieve excessive pressure by discharging gas to the atmosphere.**

#### Warning

**It is not safe to use cooking appliances for comfort heating.**

Cooking appliances need fresh air for safe operation. Before operation:

1. Open overhead vent or turn on exhaust fan.
2. Open Window.

This warning label has been located in the cooking area to remind you to provide an adequate supply of fresh air for combustion. Unlike homes, the amount of oxygen supply is limited due to the size of the recreational vehicle, and proper ventilation when using the cooking appliance(s) will avoid dangers of asphyxiation. It is especially important that cooking appliances not be used for comfort heating as the danger of asphyxiation is greater when the appliance is used for long periods of time.

A warning label has been located near the LP gas container. This label reads.

**Do not fill container(s) to more than 80 percent of capacity.**

Overfilling the LP gas container can result in uncontrolled gas flow which can cause fire or explosion. A properly filled container will contain approximately 80 percent of its volume as liquid LP gas.

#### Warning

**Portable fuel-burning equipment, including wood and charcoal grills and stoves, shall not be used inside the recreational vehicle. The use of this equipment inside the recreational vehicle may cause fires or asphyxiation.**

#### Warning

**Do not bring or store LP gas containers, gasoline or other flammable liquids inside the vehicle because a fire or explosion may result.**

The following label has been placed in the vehicle near the range area:

#### If You Smell Gas:

1. Extinguish any open flames, pilot lights and all smoking materials.
2. Do not touch electrical switches.
3. Shut off the gas supply at the tank valve(s) or gas supply connection.
4. Open doors and other ventilating openings.
5. Leave the area until odor clears
6. Have the gas system checked and leakage source corrected before using again.



LP gas regulators must always be installed with the diaphragm vent facing downward. Regulators that are not in compartments have been equipped with a protective cover. Make sure that regulator vent faces downward and that cover is kept in place to minimize vent blockage which could result in excessive gas pressure causing fire or explosion.

### **Warning**

**Never check for leaks with an open flame. Do not check copper plumbing lines for leaks using ammoniated or chlorinated household-type detergents. These can cause cracks to form on the line and brass fittings. If the leak cannot be located, take the unit to your Wanderlodge® dealer or LPG supplier.**



## Section VII

# Air Brake System

Your motorhome is equipped with dual service air brake systems for front and rear brakes, with integral fail/safe operation; and manual/automatic rear spring (parking) brakes. As shown in the air brakes system diagram in Section X, the service brakes are completely independent systems, each including a reservoir and separate distribution lines and valves. A separate reservoir is also supplied for the rear spring brakes, which function independently of the service brakes. All three reservoirs are pressurized from a single compressor. Both service brake systems are brought into operation each time the brake treadle is depressed to slow or stop the coach. Reservoir pressure for each service brake system is monitored by a respective pressure gauge on the front panel; system failure(s) are indicated by low pressure readings, illumination of the **Low Air** failure lamp, located above the Blue Bird Wanderlodge Logo in the center of the dash, and by sounding of the low air warning buzzer.

### Operation

When the coach is parked, and the engine off, the rear spring brakes will normally be set by operating the parking brake. The spring brakes cannot be fully released until the air pressure is above 65 psi. These brakes are in the released position when the control is pushed in. In the event that there is a loss of air pressure, the spring brakes will set automatically, at the brake-applied position, and will not release until the air reserve has again built up to required value. Consequently, there will be a normal delay, after the coach is first started, before the compressor builds up sufficient pressure in the three reservoir tanks, before the brakes can be released and the coach driven. When the brake treadle is depressed, to slow or stop the coach, reservoir air is applied simultaneously to both front and rear service brakes to effect the braking action. The spring brakes are held in a released position by the air pressure supplied from the associated reservoir tank.

## Caution

**Do not attempt to drive the coach until system pressure is above 90 psi.**

### Brake Failures

To compensate for normal lining wear, each brake system is individually self-adjusting.

A combination of fail/safe features provide protection against brake system failures. Each service braking system, front and rear, has a backup capability in the event of partial or total system failures. If the front brakes fail, operating the brake treadle activates the rear service brakes normally providing sufficient braking action to effectively stop the coach. If a failure occurs in the rear, the front service brakes and rear spring brakes provide braking action. Under these conditions, the spring brakes do not lock in, as in a normal set position, but instead their application is "modulated" in the same manner as the service brakes, thereby providing a normal braking "feel".

In the unlikely event of a failure where both service braking systems are disabled, the rear spring brakes will apply automatically and bring the vehicle to a stop. As a safety factor, the coach should not be moved until brake failures (any type) are corrected.

## Note

**With the front brake system service reservoir fully charged, enough air pressure is available to provide four full releases of the rear spring brakes. This will allow the coach to be brought to a safe position until repairs can be accomplished.**

### Additional Air-Operated Equipment

Besides providing the compressed air supply for the coach braking systems, the compressor also provides the air supply for the entry step, side-slide mechanism on pilot's and co-pilot's seats, front air vents, steering wheel tilt mechanism and air suspension system (air bags) — all via separately-controlled solenoid switches operated from the dash, or at other locations throughout the coach. (This compressed air source is furnished from the front right side reservoir.) A compressed air outlet fitting, tire gauge, and spiral hose are contained in the center storage compartment on the left side of



the coach, convenient for blowing out the water system, inflating tires, and so on. A Schraeder valve (air connection) is available at the rear of the front right side air tank to allow the air system to be pressurized from a "shop" source without the necessity of starting the engine.

### **Compressed Air System Air Dryer**

The air dryer unit collects and removes moisture and contaminants from the compressor air output before the air reaches the reservoirs. This unit is different from a reservoir drain or an aftercooler in that it provides dry air for the brake system by eliminating the possible accumulation of condensate in the system reservoirs. Note that each reservoir also has a drain cock on the bottom for draining accumulated moisture. This assures a long maintenance-free life for air brake system components due to the removal of system contaminants.

The air dryer is located between the compressor discharge (output) line and the compressed air reservoirs. A safety valve mounted in the air dryer housing assembly protects against excessive pressure buildup. The desiccant cartridge and pleated paper oil filters are easily removable and replaceable as a complete serviceable unit. The desiccant "beads" which provide the drying action have a large capacity for absorption due to their combined surface area. In addition, an internal thermostatically-controlled heating element prevents freezeups on the purge drain valve when the unit is used during sub-freezing temperatures.

Purging of the dryer is automatic, exhausting combined oil and water residue to the atmosphere. At the same time that the contaminants are purged the reverse air flow across the desiccant material removes the accumulated moisture and reactivates the desiccant. Cartridge replacement should be accomplished at 12-month periods; sooner, if the cartridge has become contaminated.



# Section VIII

## Owner Maintenance Data

This section provides general information for use in performing scheduled services as well as preventive and routine maintenance on your Wanderlodge®.

### Specifications and Data

**Table 8-1  
Engine and Chassis Specifications**

Engine	
Caterpillar 3208T	250 HP
Transmission	Allison MT643 4 speed
Chassis GVWR	34,000 lb.
Front Axle	13,200 lb.
Rear Axle	23,000 lb.
Wheelbase	216.5 in. (35 ft.); 194 in. (33 ft.) 179 in. (31 ft.)
Air Brake System	
Front Axle	Self adjusting 16.5 in. × 5 in. brakes
Rear Axle	Self-adjusting 16.5 in. × 7 in. brakes
Air Reservoirs	Three Air Tanks 4,760 cu. in.
Retarder	Jacobs Drive Line
Wheels & Tires (6)	Aluminum rim, 11R22.5, 16 ply tubeless steel-belted radial
Tire Inflation	115 lb., front; 110 lb., rear;
Axle Ratio	4.88:1
Leveling Jacks (Hydraulic)	
Front (each)	20790 lb. rating
Rear (each)	10990 lb. rating

**Table 8-2  
Engine/Chassis Capacities**

Diesel Fuel Tank Capacity	
35 ft. side bath	265 gallons
31 & 33 ft. side bath	235 gallons
33 & 35 ft. rear bath	225 gallons
Lube Oil System	
Refill Volume with Filter Change	20 quarts
Crankcase Capacity	Low Mark 12 quarts High Mark 16 quarts
Cooling System Capacity	25 quarts (approx. 64 quarts with cockpit & living area heaters)
Oil Specifications for Engine	
API	CD/SE, CD/SF, CC/SE, or CC/SF
30 degrees to 100 degrees F	SAE 40, SAE 30, SAE 15W-40, or 10W-30
Below 30 degrees F	SAE 10W-30, 15W-40, 5W-20, or SAE 10W
Frequency of Oil Change	
Every 300 engine hours with —	CD/SE or CD/SF oil
Every 200 engine hours with —	CC/SE or CC/SF oil
Frequency of Filter Change	Every oil change
Oil Filter W/L p/n 3743481, CAT 9N6007	
Power Steering	
Specification	Dextron II
Capacity	4 quarts
Leveling Jacks	
Specification	Dexron II
Capacity	10 quarts
Transmission	
Specification	Dexron, Dexron II
Capacity (less external circuits)	16 quarts

**Table 8-3  
Generator Capacities and Specifications**

Electrical Rating	12.5KW at 120 Vac 7.5 k.w. in 31 & 33 ft. coaches
Fuel Supply	
Diesel	Tee in engine supply line.
Gasoline	7.5 k.w. has separate 30 gal. tank located at right rear.
Coolant System	Water-cooled 12.5k.w. 10 quarts; 7.5 k.w. 7.5 quarts
Crankcase Capacity	5 quarts w/ filter, Oil Filter
12.5 k.w. W/L P/N 3759453	Motorcraft FL-1A
7.5 k.w. W/L P/N 2267417	WIX 51764
Oil Specifications for Generator	



API .....	CC/SE, CC/SF, CD/SC CD/SE, or CD/SF
30 degrees to 100 degrees F .	SAE 10W-30
0 degrees to 30 degrees F ...	SAE 10W-30
Below 0 degrees F .....	SAE 5W-20
Battery .....	12 volts, 90AH

**Table 8-4  
Motorhome Capacities  
and Specifications**

Potable Water Tanks .....	96 gallons (100 gallons w/rear bath)
Holding Tank, Gray Water .....	56 gallons (52 gallons w/rear bath)
Holding Tank, Waste .....	50 gallons (40 gallons, 31 & 33 ft. side Bath; 56 gallons w/rear bath)
LPG Tank .....	148 lbs.-net (43.5 gallons)
Water Pump .....	3.5 GPM
Water Heater .....	10 gallons
Batteries .	Four 6-volt batteries, series-parallel connected to supply 12v at 440 AH
Battery Chargers .....	50 amperes output each
Air Conditioners*	
Automotive .....	18,000 BTU
Central (3) .....	14,000 BTU ea.
Roof (std. w/rear bath & 31 & 33 ft. side bath)	13,500 BTU ea.
Hot Water Circulating Heaters**	
Living Area (3) .....	50,000 BTU ea.
Cockpit Area .....	90,000 BTU
Gas/Hot Air Heaters*	
Living Area (3) .....	16,000 BTU ea.
Electric Heaters, 120 volt (4) .	1500 watts ea.
NEMA Rating* .....	SBBMA Rating**

**Table 8-5  
Maintenance Schedule Summary**

**Item**  
— Frequency  
— Type of Service  
**and Specification**

**Transmission**

- At 5,000 miles, thereafter at normal oil change intervals
  - Replace transmission filter (W/L P/N 0998542, AC25011900) — in cooler return line.
- At 25,000 miles, or 12 months, whichever occurs first
  - Replace transmission oil (Dexron or Dexron II)
  - Replace transmission internal filter (Kit DDA P/N 23019201)

**See Section X Diagram, Lubrication Guide for service of other Engine/Chassis components**

**Batteries**

- Every 500 miles to 1,000 miles
  - Replenish cells with distilled water to 3/8-inch above plates.
  - Coat Battery terminals with lubricant

**Air Cleaner**

- 10,000 to 15,000 miles
  - Replace when air cleaner indicator (if so equipped) shows red after high power run. Loss of power and black smoke also indicate need for change. W/L P/N 0819698, DYNACELL T-512

**Fuel Filters**

- 10,000 to 15,000 miles
  - Replace as required
  - W/L P/N 2236677, CAT 1P-2299 Racor Filter and Water Separator
    - Change when vacuum (Racor) gauge goes to red
    - Element W/L P/N 2254035 (Racor 2040SM)
    - Gasket (large) W/L P/N 3747359 (2) (Racor 11007)
    - Gasket (T-handle) W/L P/N 3747342 (Racor 11350)



## Air Brakes System

### Reservoir Tanks

- Daily or depending on usage (not necessary with air dryer)
- Drain each reservoir tank of moisture by opening petcock at bottom of tank.

### Air Compressor Air Dryer

- 23,000 miles, or every 3 months, or every 900 hours. Refer to Bendix Air Dryer Manual.
- Check/replace air dryer cartridge W/L P/N 2107753 (Bendix 287313)

### Air Suspension System

- 1,000 miles to 3,000 miles, or every month
- Check air springs for even inflation
- Check for tightness of nuts, bolts, air connections
- Check shock absorbers for oil leakage, worn bushings
- No lubrication is required

**Table 8-6**  
**12-Volt Lighting Equipment,**  
**and Fuses, Current Usage**

Item	Specification (Qty)/Amperes
Automotive Lighting Marker/Clearance/ Identification, bulb # 1895	(16)/4.5
Stoplights, bulb upper # 1156	
lower # 1157	(4)/8.4
Parking Lights (lower F&R)	
bulb # 1157	w/tag (5)/3.0
Turn Signal Lights (upper F.&R)	
bulb# 1156	(6)/7.1
Cornering Lights, bulb # 1156	
Side Turn Lights, 2/side, 2 # 1895 bulbs/light	
Indicator Light W/L P/N 2271955	
Relay - rear lights, W/L P/N 1077718, located at upper front load center	.14A. ea.
Hazard Warning	(6)/12.6
Tag Light, bulb # 67	(1)/.55
Headlights and Taillights (with park & tag)	
G.E. Halogen Sealed beam units 1C1 & 2C1	
Hi-beam operation	(9)/13.7
Low-beam operation	(7)/8.0
Driving Lights, bulb	
W/L P/N 2126019	(2)/15.6
Ignition (solenoids)	7.0

### Instrument Panel—Electroluminescent

(inverters)	(3)/1.0
Instrument Panel—	
Gauges, bulb # 53	(14)/1.7
Spot Light, bulb W/L P/N 2103760	6.8
Stepwell outside, bulb # 53	(1)/.12
Stepwell inside, bulb # 67	(1)/.55
Landing Lights, bulb assy.	
W/L P/N 2261626	(4)/27.2
Backup Lights, bulb # 1156	(2)/3.8
Rear Parking Halogen	(2)/13.4
Engine Compartment Lights	
bulb # 1416	(1)/.8
Luggage & Stepwell Compartment Lights	
bulb # 1416	.8A. ea.
Porch light, bulb # F8T5/CW	(2)/2.2
Interior Lighting	
Reading Spots, bulb # 1383	(15)/1.54 ea.
Front Living, Flush,	
bulb# F15T8/CW	(8)/14.0
Aisle, Bulb # 53	(3)/.36
Bathroom Mirror	
bulb # F8T5/CW	(2)/2.2
Bathroom, Flush,	
bulb# F15T8/CW	(2)/3.5
Shower, bulb # 1141	(1)/1.5
Dinette, Flush, bulb # F15T8/CW	(2)/3.5
Kitchen, Flush,	
bulb# F15T8/CW	(2)/3.5
Bedroom Flush bulb # F15T8/CW	(4)/7
Ceiling, Flush, bulb # F15T8/CW	(2)/3.5
Vent Fans, bulb # 912 @1.0A.	(3)/4/Vent
Windshield Wipers	(2)/8.0(max.)
Windshield Wiper Heaters	(2)/3.0
Water Pump	(1)/6.2
Blower Motors	
Front Heater (Hi/Lo) Right	(1)9.0/4.5
Defroster (Hi/Lo)	(1)/9.0/4.5
Foot Warmer (Hi/Lo) Left	(1)/9.0/4.5
Chassis Heater (Hi/Lo)	(3)/9.0/4.5 ea.
LPG Furnace	(3)/9.0
Portable Fan	(1)/1.0
Duct Booster	(1)/1.0
Ceiling Vent (Round)	(1)/4.0
Vent Fan (Square)	(3)/6.6
Stereo System	(1)/15
Motor Generator(Option)	(1)10.4



## Fuses

Electronic equipment fuses are located in left front and left rear 12 volt load centers. Diagram is inside covers.

**Radio Amplifier** — left front load center, # 72 orange/black wire, AGC 10

**Amplifier On-Off Relay** — right front load center, blue wire, AGC3

**Refrigerator** — left front load center, # 14 gray wire, AGC10

**Spot Light Rotation** — upper front load center (behind rubber flap), red wire, AGC3

**Burglar Alarm** — under dash left side of steering column, red wire, AGC2

**Turn/Hazard Flasher** — under dash left side of steering column, black wire, AGC15 (some directly from circuit breaker)

## Changing Wheels/Tires

The wheel/tire assemblies used on your motorhome are heavy-duty truck-type. They are **heavy** and may be difficult to handle. If at all possible, changes should be accomplished by a service station equipped to handle truck equipment. However, if a situation arises where no service facilities are available, the following procedures may be used.

1. Drive motorhome out of traffic lane onto a level surface.
2. Turn on hazard flasher and apply parking brakes before leaving coach.
3. Turn off ignition and set transmission selector to **Neutral (N)** position.
4. Remove white plastic wheel saver, jack, lug wrench and handles from front curb side storage compartment.
5. Place wheel chocks against front & rear of tires on opposite side.
6. Place jack under axle and raise slightly until securely in place. See figure 8-1 for location of typical jacking point.



**Figure 8-1.** Locating Jack

7. Remove spare wheel assembly from mounting and place on ground near work area.
8. Pull off lug nut covers.
9. Install wheel saver.
10. Loosen lug nuts slightly, then jack up coach until tire is clear of ground.

### Note

Lug nuts on right side of coach are righthand threaded (turn counterclockwise to loosen, clockwise to tighten); lug nuts on driver's side of coach are lefthand threaded (turn clockwise to loosen, counterclockwise to tighten).

11. Remove lug nuts and wheel assembly.
  12. Install spare and replace lug nuts. Tighten progressively in the sequence shown in figure 8-2 starting with # 1 and proceeding to # 10.
- Final torque will be 450 to 500 foot-pounds.





20. Turn off hazard flasher before returning to traffic.

## Caution

**Check lug nuts for tightness every 1,000 miles. Lug nuts should be torqued to 450 to 500 foot-pounds.**

### Using the Optional Mountz Power Wrench

The Mountz Power Wrench, figure 8-3, is a 12-times force multiplier which is designed for easy removal of wheel lug nuts. This tool is supplied as a kit which includes a 1/2-inch square ratchet drive with extension sleeve, a precalibrated ratchet torque wrench, and both hex and square wheel lug nut sockets.

To remove the lug nut, jack up the side of the coach where the defective tire is located, or use the appropriate leveling jacks. Select the appropriate lug nut socket, fit the tool over the wheel nut (after installing wheel saver), as shown, attach the 1/2-inch drive reaction bar and remove the nut(s). After the wheel is replaced, replace all nuts fingertight, remove the reaction bar and use the precalibrated torque wrench to tighten the wheel nuts to the proper torque. Do not use the reaction bar to tighten the lug nuts. When tightening nuts, work opposite sides so that all nuts are equally torqued. Note that the torque wrench is factory calibrated to provide an inner cap nut and lug nut torque of 450 foot-pounds; an audible **click** indicates proper torque. For maximum accuracy, the torque wrench should be recalibrated on a yearly basis.




Figure 8-3. Mountz Power Wrench




Figure 8-2. Lug Nut Tightening Pattern

13. Snap front hub cover into front wheel opening after front lug nuts have been properly torqued.
14. Install rear inside tire and wheel assemblies using inner lug nuts.
15. After rear outside tire and wheel assemblies are placed on the inner lug nuts, install outer lug nuts on lug numbers 5,6,7,8,9,10 and torque. Place rear hub covers over lug nuts and install lug nut lock rings (provided with rear hub cover) and lug nuts over lug numbers 1,2,3,4 and torque.
16. Place lug nut covers on all outer lug nuts, front and rear. Make certain that these nut covers fit snugly which is accomplished by squeezing the dimpled sides together before installing.
17. Lower coach to ground and remove jack and handle.
18. Replace wheel saver, lug wrench, jack and handles in storage compartment and tie down to prevent road noise. Return damaged wheel/tire assembly to holder and have it repaired as soon as possible.
19. Remove and stow wheel chocks.



## Battery Maintenance

Your motorhome is equipped with four 6-volt batteries, connected in a series-parallel arrangement to provide 12 volts for engine and motorhome use. This arrangement makes available 440 AH (20 hour rate). Batteries are located on a slide-out tray in the front compartment on the road side, as shown in figure 4-2. A separate 12-volt battery is contained in the generator compartment and is used only for the generator. All batteries are charged from either the engine alternator or battery chargers (when 120 volts ac is available). Note that the generator will supply 120 volt ac to the battery chargers.

### Periodic Battery Checks and Maintenance

Periodically check electrolyte level in the four six-volt batteries. The generator battery is sealed so it is not necessary to check the level of the electrolyte. Battery condition depends on battery usage and proper utilization of the battery chargers.

## Caution

**Do not wear metal rings, watches or jewelry when working on or near the batteries, cables, solenoids, or chassis wiring. These can short out electrical wiring and cause injury**

To make sure that the batteries are always ready for use, periodically check and charge as necessary. Check batteries at least every two weeks in freezing weather; at least every four weeks in warmer weather. A fully-charged battery will not freeze under normal circumstances, so it is imperative that the batteries remain charged during winter. A safe level of charge is a specific gravity reading of 1.225 to 1.280. Always use a battery hydrometer which has a temperature correction scale. It is advisable to have the coach shoreline connected to the 120 volt ac supply so that the batteries remain fully charged.

A dirty battery may eventually dissipate its charge through conductive surface contamination. Clean battery top surface with a damp cloth and dry thoroughly. Check that battery terminals and associated battery jumper terminals are tight and free of corrosion. To clean terminals, neutralize corrosive deposits with a solution of baking soda, rinse with clear water, and dry. Note that commer-

cial type spray-on battery cleaners are available at automotive supply stores. Use as directed to keep the batteries clean. Spray-on cable and terminal protective coatings are also available, easy to use, and effective.

### Exterior Care

Exterior paint finish life can be extended by periodic cleaning and waxing. This will preserve the paint and allow easier removal of dirt and road tars. Use touch-up paint for small areas to keep the coach finish in like-new condition.

Frequent washing of the coach is necessary to prevent corrosion in areas where heavy salt sprays are evident. A clear acrylic spray may be used, with care, to control corrosive effects of salt spray on metal surfaces.

## Caution

**Avoid spraying water through the refrigerator vent door.**

### Interior Care

The interior can be kept in good condition with the use of approved cleaning agents for vinyl walls and ceilings, plastic fixtures, stainless steel, formica and so on. Never use abrasive cleaning agents on interior of refrigerators, or on the lavatory, tub/shower, or toilet, as they can cause permanent scratches. Be sure that the cleaning agent will not damage the material. Note that some plastics are incompatible with certain cleaners. Read the directions on the container before using. For the most part, the cleaners and polishes that would normally be used in your home are equally well-suited for use in your motorhome.

### Fluid Level Checks

#### Crankcase Oil Level

The crankcase oil dipstick is readily available inside the engine cover at the right front corner of the air cleaner.

The oil level must be checked only with the engine off. Maintain oil level at the proper fill line. If checking oil level immediately after engine has been operating, allow a few minutes for the oil to drain back into the crankcase before checking the oil level reading.

The best time to check the oil is before getting underway because the engine is cool and the



reading will be most accurate.

### Power Steering Reservoir Fluid Level

Regularly check fluid level in the power steering reservoir. Add Dexron II as necessary to maintain the correct dipstick reading, depending on fluid/engine temperature. (Note that the dipstick is attached to the T-handle plug on top of the reservoir). If the fluid is at normal operating temperature — about 150 degrees, and hot to touch — the dipstick should indicate **FULL** or just below. If engine is cool, fluid level should read about 1/2 way between the **ADD** and **FULL** marks.

### Transmission Fluid Level

The transmission dipstick is located just inside the engine cover opening (at the right rear).

### Importance of Proper Oil Level

Since the transmission oil cools, lubricates, and transmits power, it is important that the proper oil level be maintained at all times. If it is too low, the converter and clutches will not receive an adequate supply of oil. This can result in poor performance or transmission failure. If the level is too high, the oil will aerate, causing the transmission to overheat. Check the oil level at intervals specified in your vehicle service instructions, or more frequently, if operating conditions indicate.

### Oil Check Procedure

Always clean around the end of the fill tube before removing the dipstick. Dirt or foreign matter must not be permitted to enter the oil system. It can cause valves to stick, cause undue wear of transmission parts, or clog passages. Check the oil level by one of the following procedures and report any abnormal oil level to your maintenance personnel. Check for abnormal oil level, milky appearance or any trace of coolant in the oil.

### Hot Check

1. Operate the transmission in a drive range until operating temperature (160-200°F; 71-93°C) is reached.

### Note

**The oil must be hot to ensure an accurate check. The oil level rises as temperature increases.**

2. Shift through all drive ranges to fill the clutches

and oil passages.

3. Park the vehicle on a level spot, shift to neutral **N** and apply the parking brake. Let the engine run at idle speed.
4. Wipe the dipstick clean and check the oil level. The safe operating level is any level within the **Hot Run** band on the dipstick.
5. If not within this range, add or drain oil as necessary to bring the level to the middle of the **Hot Run** band.

### Cold Check

1. A cold check may be made when the sump temperature is 60-120°F (15-40°C).
2. Run the engine for at least one minute to clear the oil system of air.
3. With the engine running at idle, wipe the dipstick clean and check the oil level. Any level within the **Cold Run** band is safe for operating the vehicle. If the level is at or below the bottom of the **Cold Run** band, add oil until it reaches the middle of the **Cold Run** band.
4. Operate the vehicle and make a hot oil check when operating temperature is reached (160-200°F; 71-93°C).

### Racor Filter and Water Separator System

#### Filter/Separator Operation

The three stages of the Racor filter/separator, figure 8-4, work in series to progressively clean the diesel fuel. Because virtually all water and larger particles of solid contamination are removed in the primary and secondary stages, the effective life of the fine micron replaceable element is 2-3 times longer than standard filters.




Figure 8-4. Racor Filter/Separator

**Primary Stage (Separation)** — In the primary stage, liquid and solid contamination down to 30 microns are separated out by centrifugal action created by the turbine centrifuge. There are no moving parts in this highly efficient design. Because the contamination is heavier than the fuel it falls to the bottom of the clear bowl.

**Secondary Stage (Coalescing)** — This stage functions when minute particles of liquid contaminants (lighter than the fuel) remain in suspension and flow up with the fuel into the lower part of the filter/separator shell. Here the minute particles tend to bead on the inner wall of the shell and the bottom of the replaceable cartridge. As the beads accumulate, they become larger and heavier and will eventually fall to the bottom of the filter/separator bowl.

**Final Stage (Filtration)** — In this stage the fuel enters the replaceable cartridge where the minute solids are removed.

#### In-Filter Fuel Heater

Internal automatic thermostats turn on the Racor in-filter fuel heater as the fuel temperature drops below 35°F. (1.7°C.)

The in-filter fuel heater operates from the 12-volt

battery source, supplying heat to the fuel filter just below the replaceable element. This critical placement provides increased fuel temperature as the fuel passes through the fine micron filtering element.

When the engine is not running and the temperature is below 35°F., the heater is operated by turning on the ignition switch for a maximum of 10 minutes prior to starting the engine. With the diesel fuel temperature above 35°F, there is no waxing or icing of the filter element. The in-filter heater is primarily a cold starting aid. Note that the top two terminals imbedded in the glass filter bowl connect to the internal heater.

#### Water-in-Filter Alarm

The electronic water sensor alerts the operator when liquid contaminants filtered out of the system should be drained from the collector bowl, thereby maintaining maximum filter/separator efficiency.

When water reaches a pre-determined level in the collector bowl, sensing probes activate the **Water-in-Filter** alarm circuit. The light illuminates, warning the operator to drain excessive water contamination collected in the bowl. Shut down engine before draining the bowl to avoid sucking air into the system. Note that the bottom two terminals imbedded in the bowl connect to the water sensors.

#### Maintenance

**Filter Element** — Routine maintenance of the Racor unit consists of periodic filter replacement and drainage of the moisture collected at the bottom of the bowl. (Engine is off during maintenance.)

**Filter Element Replacement** — Replace the element as follows:

1. Loosen handle and remove lid.
2. Inspect lid gaskets and replace, if necessary.
3. Remove filter element by grasping bale and lifting upward while rotating.
4. Replace Racor element by positioning over center return tube and twisting downward into place.
5. Top off by pouring clean diesel fuel into filter cylinder until full.
6. Replace lid and hand-tighten handle.



**Draining** — Drain bowl of accumulated moisture by opening petcock on bottom of bowl. Allow to flow until clean fuel appears.

**Leveling Jacks Reservoir**

The leveling jacks oil fill is located beneath the center entry step. Lift up the hinged step top (hinge at door side) and remove the screws attaching the square metal cover plate to gain access to the oil fill to check oil level.

**Engine Cooling System Refill**

Use of anti-freeze (ethylene glycol type only) is recommended for summer or winter operation because of it's corrosion inhibition and lubrication properties. A 50-50 solution of antifreeze and water is preferred and it gives freeze protection to about 30°F below zero. Ultimate protection is attained at 68% antifreeze (about 92°F below zero): a higher concentration of antifreeze should never be used. The approximate (dry) cooling system capacities are:

Engine, Radiator, & Engine Hoses	.....	10 gallons
Right front heater system	.....	2 gallons
Rear coach heater system	.....	4 gallons
<b>Total</b>	.....	<b>16 gallons</b> (64 quarts)

... so the system would require 8 gallons of anti-freeze for a 50% solution or 11 gallons for a 68% mixture. Final solution should always be tested with a thermo-hydrometer or equivalently reliable testing device to determine actual protection.

If it becomes necessary to completely re-fill the chassis coolant system, the following procedure must be followed (see figure 10-1). Pure antifreeze can be used initially until prescribed amount has been installed, and then water for final filling.

**1. Fill the Engine, Radiator, and Engine hoses.**

Locate and close the manual gate valves separating the engine from the heater systems. Both pressure and return valves for the coach heaters are under the pilot's floor. The pressure valve for the front heater is electric solenoid operated and the return line has a gate valve at the engine (right side front). Close the front heater electric solenoid valve by placing the **FRONT HEAT** switch in the pilot's control area to the **OFF**

position. Remove the radiator cap and fill to the top. Replace radiator cap and run engine @1500 to 2000 RPM for one minute to purge air from the engine water jacket. Shut off engine, carefully remove the radiator cap, re-fill the radiator, and replace the cap.

**NOTE**

**Use extreme care at all times when removing the radiator cap as hot coolant under pressure can cause injury.**

- 2. Fill the Front Heater and Rear Heater Systems.** Air bleeder valves are located under the pilot's floor (at the return gate valve) for the coach system and over the radiator fill (in black tubing) for the front heater. Leave the return line gate valves closed and open the pressure line valves for front and coach heaters. Place the electric **FRONT HEAT** switch (item 26, figure 2-2) to the **ON** position and the **HEAT SELECTOR** switch (item 25, figure 2-4) to the **WINTER** position. Press the **AUX. PUMP** switch (item 24, figure 2-4) to **ON**.

Set **CHASSIS HEAT** thermostat on the living room wall (in front of door) to the maximum high temperature position. Using suitable containers to catch coolant, open the bleeder valves and run the engine slightly over 2,000 RPM until a steady flow of coolant passes through the valves.

The radiator must be refilled often during this time as coolant from the engine will be filling the heater lines. When steady flow is attained from the bleeder valves, close them and open return line gate valves allowing coolant to flow back into the engine. Re-fill radiator using coolant caught from bleeder valves and additional water as necessary.

- 3. Fill SUMMER by-pass.** Push electric **FRONT HEAT** switch to the **OFF** position. Place the **HEAT SELECTOR** switch in the **SUMMER** position. Leave the **AUX. PUMP** switch on. Run engine slightly over 2000 RPM until engine thermostat opens (when upper radiator tank gets hot) and then place **HEAT SELECTOR** switch back to **WINTER** position and test heater blowers to see that heaters are filled with hot fluid. Push **FRONT HEAT** switch back on. Rev the engine to maximum governed RPM/five or six times to allow the engine pump to help



purge the system of remaining air and then turn the engine and all systems off. Allow the radiator to cool and then remove the cap and fill completely.

### Cooling System Additives

Automotive cooling systems are subject to various types of corrosion, rust, pitting and cavitation-erosion. These are common factors which prevent efficient cooling and contribute to engine overheating and higher maintenance costs resulting from replacement of hoses, fittings, filters and cracked heads. The manufacturer of the engine used in your motorhome recommends the use of Nalcool 2000 — a chemically buffered liquid additive which effectively neutralizes the formation of acids caused by dissolved exhaust gases, and inhibits the cooling system against corrosion and scale formation. This additive is compatible with most commercial automotive anti-freeze solutions containing ethylene glycol; however, its use is not recommended in cooling systems using Dow Therm 209. When refilling the coolant system, add four pints of Nalcool before topping off with anti-freeze solution. To ensure constant system protection, replenish Nalcool 2000 additive, periodically, in accordance with manufacturer's instructions.

### Windshield Washers

Check reservoir fluid level periodically and use a prepared washer solution if possible. (Note that low reservoir levels are indicated by a dash monitor light.) During freezing weather, use a solution additive, or a solution specifically designed for cold weather usage. The washer reservoir is accessible through the front curb side storage compartment.

### Battery Jumper Terminals and Jump-Starting

For your convenience and safety when jump-starting, terminal posts are provided at the top front of the battery compartment, figure 4-2. Proper procedure for jump-starting is as follows:

1. Turn off all main battery-operated accessories in both vehicles — lights, radio, etc.
2. Connect one end of the positive-coded jumper cable to the positive (red) battery jumper terminal, and the opposite end of the cable to the positive (+) terminal on the other battery.
3. Connect one end of the negative-coded jumper

cable to the negative (-) terminal on the other battery and the opposite end of the cable to the negative (black) battery jumper terminal.

4. Once the engine of the disabled vehicle is started and brought up to idle, reverse the above procedure to remove the jumper cables. Always remove the jumper cable connected to the Wanderlodge® negative (black) battery jumper terminal first to prevent sparks at the other battery.

### Caution

**Avoid sparks in the vicinity of a charging battery: the gas produced is explosive.**

### Generator 12.5 k.w.

Keep the generator operating at peak efficiency by following a regular schedule for inspections and servicing, based on operating hours. Keep an accurate logbook record of maintenance, service and hours of operation, following regular schedules for normal operating conditions, and a more frequent service schedule for operation under dusty or dirty conditions. Check condition of crankcase oil and change air filter frequently until the proper service/time periods can be determined based on your usage.

### Maintenance Schedules

Use the generator maintenance schedule in table 8-7 as a guide for routine and periodic maintenance. Neglecting generator maintenance can result in failures or permanent generator damage. Refer to the generator service manual for detailed repair and maintenance.

**Table 8-7**

### Generator Maintenance Schedule

#### Frequency

#### — Service

Daily, or before each startup

- Check oil level
- Check coolant level
- Clean radiator intake screen



Every 100 hours, or 6 months, whichever occurs first

- Change lubrication oil
- Change oil filter
- Service air cleaner
- Check engine for oil, water, or fuel leakage
- Check belt tension

Every 200 hours, or 12 months, whichever occurs first

- Check hoses and clamps
- Check and tighten electrical connections
- Check exhaust system for leakage
- Check and tighten mounting bolts
- Check generator brushes, commutator and slip rings
- Replace fuel filter element
- Check electrical system for frayed wires, corroded connections

Every 400 hours or 12 months

- Contact authorized service center for tuneup to include:
  - Injector inspection
  - Check and adjust valve tappets
  - Clean sliprings and inspect brushes
  - Check governor operation and adjust as necessary.

Periodically, perform a complete visual inspection of the generator when operating at full load.

## Caution

The generator tray is air operated and extends outward with considerable force. To extend the tray, figure 8-5, unlock the hand-latch, located underside, by moving forward and then operate the Out-in switch in the stepwell compartment. Be sure that there is sufficient clearance in front of the tray and that nobody is in the way! Use extreme caution when observing an operating generator with tray extended.




Figure 8-5. Generator Unit, Tray Extended

## Battery

Check the condition of the generator battery periodically. See that battery connections are clean and secure. A light coating of nonconductive grease will prevent corrosion at terminals. Refer to Battery Maintenance procedures provided earlier in this section.

## Air Cleaner

Proper maintenance of the air cleaner, figure 8-6, is extremely important. Allowing this vital element to become clogged with dirt restricts the flow of intake air into the engine. Operating with an over-rich fuel mixture caused by a poorly serviced or clogged air cleaner leads to formation of harmful carbon/sludge deposits.

This oil bath air cleaner should be serviced every 100 hours or six months as follows:

1. Loosen thumbscrew in Marman clamp while holding bottom (oil reservoir) bowl.
2. Remove bowl.
3. Unlock element (twist) and remove.
4. Wash bowl and element in non-flammable cleaner. Allow to air dry.
5. Reinsert and lock element.
6. Fill bowl with engine oil (see Table 8-3) to indicated level.
7. Replace bowl and tighten Marman clamp



thumbscrew.

If operating under extremely dusty conditions, use dry compressed air to blow out generator at frequent intervals. Do this with the generator set operating and direct the stream of compressed air in through the cooling louvres at the end of the generator.

### Oil Pressure

Always ensure that with the engine running, oil pressure is registering on the upper dash generator oil pressure gauge.

Pressures do vary according to climatic conditions and even between individual engines, but the oil pressure range at normal working speed and temperature will usually vary between 30 to 60 psi. The pressure will drop while the engine is idling and also a slight drop will be experienced when the oil is hot.



**Figure 8-6.** Generator Air Cleaner

### Oil Filters

To ensure cleanliness of the lubricating oil, a sump strainer and a main full flow type of oil filter are used. The sump strainer consists of a gauze wire container which is fitted over the end of the lubricating oil pump suction pipe. All oil must pass through this strainer before it reaches the oil pump.

The main full flow type oil filter is mounted externally on the side of the cylinder block. All the oil passes through this filter after it leaves the pump, but before it reaches the bearings.

The full flow filter is a spinon cartridge in which

the element is an integral part. Filter should be replaced at each oil change.

### Replacing Oil Filter Cartridge

1. Unscrew the cartridge from the filter head.
2. Check that the threaded adapter is secure in the filter head and discard the old cartridge. Clean the filter head.
3. Using clean engine lubricating oil, lightly oil the top seal of the new cartridge
4. Screw the new cartridge on to the filter head until the seal just touches the head and then tighten by hand a further half of a turn. If the cartridge is overtightened, it may be difficult to remove later on.
5. Since the filter cartridge will normally be changed at the same time as the engine lubricating oil, refill the sump with oil, run the engine and check for oil leaks. Recheck the oil level after running the engine and add oil as necessary.

### By-Pass Valve

If the lubricating oil filter element becomes contaminated to the extent where the lubricating oil has difficulty in passing through the element, a pressure difference will build up between the inlet and outlet sides of the filter assembly. When this pressure exceeds 50 psi (approximately), a ball valve opens in the filter head casting and allows unfiltered oil to by-pass the filter element to protect the engine from oil starvation.

### Oil Check

To be on the safe side, check oil in engine crankcase daily, or before each start, to ensure that the level is in the safe range between the **L** and **F** marks on the dipstick. Do not operate generator if level exceeds **F** mark, or is below **L** mark.

## Caution

**Do not check oil level while engine is operating. Engine must be stopped to obtain a true reading, as well as for safety reasons!**





## Oil Change

On a new engine, change the oil after the first five hours of operation and, thereafter, at 100 hour intervals, or every six months, whichever occurs first. Whenever possible, drain the oil while the engine is still warm. To drain, place a container below the unit, open the oil drain and allow sufficient time for the old oil to drain completely. After draining, close drain plug and tighten securely.

## Cooling System

To avoid having the inconvenience of the generator shutting down due to overheating, or becoming damaged as a result of an overheat condition, be sure to keep the cooling air inlets to the compartment clean and unobstructed at all times.

Cooling system capacity is about 10 quarts of liquid (12.5 k.w.). When operating in climates subject to freezing temperatures, make sure that enough antifreeze solution is added to the coolant to prevent system freeze-up. (A drain petcock is provided on the underside of the radiator.) When draining the coolant, remove the radiator cap and open the block drain valve near the oil filler cap to prevent air pockets from forming and blocking water in passages in the block.

Check coolant level frequently and add anti-freeze mixture as needed to maintain correct level.

**Table 8-8**  
**Anti-Freeze Protection Chart**

Anti-Freeze Protects to:	Mixture Proportions (ethylene glycol)
+ 16 degrees F (- 9 degrees C)	20%
+ 3 degrees F (- 16 degrees C)	30%
- 11 degrees F (- 24 degrees C)	40%
- 31 degrees F (- 35 degrees C)	50%

## Generator Troubleshooting

Refer to the generator service manual for repair and maintenance data. Generator repairs should be accomplished by a qualified repair agency.

## Generator Overloads

If the rated capacity of the generator is exceeded, the safeguard circuit breaker, located in box on rear wall of generator compartment, will trip to protect the generator against damage. This condition could be caused by a short in the coach ac supply circuits, or by operating too many appliances simultaneously, resulting in an overload condition. If the safeguard circuit breaker trips, the generator will continue running but no ac output will be supplied. Before resetting the circuit breakers, turn off some of the coach appliances and lighting to reduce the load to within the operating limits of the generator. If this is done, and the generator breakers still trip, a short circuit is indicated. Turn off the generator, locate and correct the cause of the short circuit.

## Generator Battery Charging

Generator battery charging current is supplied through the isolator from either the engine alternator or the battery chargers (when ac power is available).

## Storage Procedures

If the generator is to be out of service for a long period of time, perform the following procedures before placing the unit in storage:

1. Drain oil from crankcase (while hot) then flush with clean lightweight oil. Refill crankcase with regular-weight oil after flushing.
2. Clean exterior surfaces of generator set then spread a light film of oil over any unpainted metallic surfaces which could corrode.

## Refrigerator

To ensure that your refrigerator will provide trouble-free operation, the following routine maintenance procedures should be performed at least once each year.

1. Inspect all gas connections for leakage, using a solution of soapy water. Tighten, as necessary.
2. Remove and clean the gas burner jet, figure as follows:
  - a. Remove burner housing cover screw and cover (removal of drip cup will provide better access to screw).



- b. Unplug 120 volt ac cord.
- c. With refrigerator **on**, observe the burner flame. It should be clear blue over the slots of the burner, encircling the feeler point of the thermostat. If flame is otherwise, proceed as follows:
- d. Shut-off LPG supply and disconnect 12 volt dc leads.
- e. Disconnect lighter cable from electrode.
- f. Remove burner attachment screw and withdraw burner.
- g. Clean burner tube with brush and blow out with air nozzle.
- h. Unscrew burner jet, clean with alcohol and blow out with air nozzle. Inspect jet against light to see that it is clean.

### Note

**Do not clean jet with pin or sharp object. This will affect the size of the opening.**

- i. Reassemble burner jet and replace burner being careful that end of burner fits into slot on bracket with slots of burner centrally located under the boiler tube. Reconnect 12 volt dc leads. Turn LPG supply and refrigerator **on**. Leak test burner jet seat.
- j. Observe burner flame. It should be as described in item 4. If not, take it to an authorized service center for proper adjustment.
- k. Replace burner housing cover and plug in 120 volt ac cord.




Figure 8-7. Refrigerator Gas Burner

### The Electrode

For proper ignition it is necessary to keep the electrode insulation dry and free from dirt. The gap between burner tube and electrode shall be maximum 3/16" (5 mm) and minimum 1/8" (3 mm).

### General

It is important to keep the refrigerator vent area clear and free from combustible materials, gasoline and other flammable vapors and liquids. Check the venting system. The flow of combustion and ventilating air must not be obstructed.

Check that the flue baffle is clean and reasonably free from soot. Heavy soot formation indicates improper functioning of the burner. Clean baffle and flue, cooling unit, and floor under refrigerator.

Check the energy selector system by connecting/disconnecting main voltage, start/stop the engine etc.

Compare and check that the system operates as described in Section III. If in doubt please contact a service center.



## Air Conditioning Systems

Central conditioning units require periodic cleaning of the air filters. This is the only user maintenance recommended for these units. Under normal operating conditions, filters should be cleaned at least once each month. More frequent cleaning may be necessary in dusty areas.

1. Turn unit off.
2. The filters (10" x 10") used for the central air conditioning evaporators are located behind aluminum air return grills in the living room and galley areas. In the bedroom, the filter is dropped into a slot on the inlet of the evaporator which is located at the rear of the bedroom over the engine compartment. It is accessible through the curb side closet at the rear of the bed. The filters behind the air return grills are accessible after rotating plastic tabs and pulling outward on grill top.
3. Wash filters in hot soapy water. **Do not use solvents in an alkali solution or allow to soak.**
4. Rinse filters with fresh water and air dry.
5. Replace filters.

### Caution

**Do not cycle compressor on and off rapidly or compressor damage may result. Once the compressor has been turned off, wait several minutes for system pressure to equalize before restarting unit.**

To avoid damaging the air conditioning unit:

1. **Do not** turn the air control knob from a cool position to **Off** and then immediately back to a cool position.
2. **Do not** turn air control knob from any **Cool** position to a **Fan Only** position and then back to **Cool**.
3. **Do not** turn temperature control from a colder setting to a warmer setting and then back again rapidly.

Periodically check for proper drainage in the condensing unit (central air conditioning system) drip tray by rapidly pouring two quarts of water directly into the tray. The water should drain com-

pletely within 30 seconds. If not, clean tray and check drain holes for obstructions.

## Toilet

No routine maintenance is required. If the bowl sealing blade fails to operate freely or does not close completely, clean foreign material out of sealing groove with stiff bristle brush.

To clean the toilet, use a high-grade, non-abrasive cleaner. Do not use highly concentrated or high-acid household cleaners. They may damage seals and finish.

## Water Pump

Under normal usage, the water pump should require no periodic maintenance other than ensuring that the input water supply is properly filtered of particles that could damage the pump mechanism. Pump failures can generally be tied in to the plumbing system, or to electrical wiring. If the pump fails to operate properly, refer to the general trouble-shooting guide given in table 8-9. Note that detail pump repairs and overhaul should be performed by a qualified repair facility.

A pumpguard filter is provided on the suction side of the water pump. This should be cleaned periodically.

**Table 8-9**

### Water Pump Troubleshooting Guide

#### Symptom

— Possible Cause

— Corrective Action

Pump operates but no water flows through faucet.

— Low water level in tank.

— Add water.

— Suction lines or filter clogged.

— Clear water lines and clean filter.

— Kink in water suction hose.

— Check water hose connections to tank and straighten or replace, as necessary.

— Air leak in suction line.

— Replace suction line.



Pump cycles on and off when faucets are closed.

- Water leak in plumbing.
  - Check for signs of leakage and tighten or replace fittings, pipe, etc.
- Defective toilet flush valve.
  - Repair flush valve.

Pump operates roughly and has excessive noise and vibration.

- Intake line is restricted, kink in suction hose or fittings too small.
  - Check input hoses and straighten or replace, as necessary.
- Loosened screws at pulleys and connecting rod.
  - Tighten screws.
- Deformed or collapsed pulsation dampener in pump.
  - Replace dampener.

Pump fails to start when faucet is opened.

- Clogged pressure piping.
  - Blow out water lines with compressed air.
- No voltage to pump.
  - Check input wiring, circuit breaker and switches.

Pump fails to stop when faucets are closed.

- Empty water tank.
  - Add water.
- Insufficient voltage to pump motor.
  - Check battery voltage. If voltage is OK, pump is defective.

### **Clock/Thermometer Calibration Procedures**

The thermometer section of the Clock/Thermometer indicates either the inside temperature or outside temperature, depending on the position of the panel pushbutton. It may be necessary to recalibrate the unit if there are differences between the actual inside or outside temperatures and the corresponding displays.

### **Thermometer Calibration Procedures**

1. Place an accurately calibrated thermometer unit next to the outdoor temperature probe (located under metal shield on outside of lower roof rail near refrigerator vent) while the coach is in a protected environment away from direct sunlight, rain, winds, etc. Note the thermometer reading.
2. Press in the outdoor panel switch and compare the digital display reading with the actual outside temperature noted previously. If the reading disagrees sufficiently to require calibration, open the monitor panel so that the rear of the thermometer unit is accessible. (If the readings agree, proceed to step 3.) Adjust the outdoor calibration control, located in the extreme left center of the rear panel, as necessary, to make the display agree with the thermometer reading.
3. Place the calibrated thermometer unit next to the indoor temperature probe and note the thermometer reading.
4. Press the **Indoor** panel switch and compare the digital display reading with the actual inside temperature noted previously. If the readings disagree sufficiently to require calibration, open the monitor panel so that the rear of the thermometer unit is accessible. Adjust the indoor calibration control, located on the lower left-hand side of the rear panel, as necessary, to make the display agree with the thermometer reading. Replace the monitor panel.

### **Motor Generator (Redi-Line)**

The optional motor generator is designed for unattended operation. Unlike a dc-to-ac inverter, which electronically changes the dc battery voltage to an ac line voltage, the motor generator includes a dc motor which generates an ac output in the same manner as commercial electricity is produced. Because of this, the ac output is completely isolated from the dc source. The stabilized ac output is used to operate the optional ice-maker.

User maintenance of this equipment is not recommended.



## Tub/Shower Mixing Valve

The water mixing valve used in the tub/shower contains a spool valve, figure 8-8, which may require periodic cleaning. Water mineral deposits which can accumulate in the valve body and spool valve can affect the normal operation of the mixing unit. To gain access to the valve body, remove the screws which hold the faceplate to the shower wall. (Water supply must be turned off.) Remove the control knob, then lift off the faceplate.

To remove the spool, unscrew the large center screw and carefully withdraw the spool from the valve body. Inspect O-rings for damage and replace, if necessary. Flush out spool of any foreign material, then replace in valve. Replace faceplate and secure with screws. Replace knob.




Figure 8-8. Tub/Shower Mixing Valve





## **Section IX**

### **General Information**

# **Equipment Manufacturers**

#### **Equipment Manufacturer Model or Type Number**

**Air Conditioner (Automotive)**  
Motive Manufacturing Division  
3657 10th Avenue, North  
Birmingham, AL 35234  
Motivair

**Awning**  
Zip-Dee Incorporated  
96 Crossen Avenue  
Elk Grove, IL 60007  
Model BB (specify length)

**Bath Vent**  
Hammond Manufacturing Corp.  
P.O. Box 5393  
2220 Raymond Drive  
Lansing, MI 48905  
Model CB-350-B Compact Blower

**Burglar Alarm**  
Kolin Industries, Inc.  
Box 357  
Bronxville, NY 10708  
Cat. No. 120

**CB Radio**  
American Radio Corporation  
6330 Castleplace Drive  
Indianapolis, IN 46250  
Model AX-44 President

**Central Air Conditioner**  
Marine Development Corporation  
P.O. Box 8570  
Richmond, VA 23226  
Cruisair Model ACA 14U

**Central Vacuum**  
Central Vac International  
3133 East 12th Street  
Los Angeles, CA 90023  
Model 612 Floor-Recessed

**Chime**  
General Electric Co.  
Providence, RI 02940  
CE 861

**Closed Circuit TV Camera**  
RCA Corporation  
Electronic Components Div.  
New Holland Avenue  
Lancaster, PA 17604  
Monitor Model TC 1206 Camera

**Closed Circuit TV Receiver**  
P.M.M.I., Inc.  
Drawer 10  
Old Ocean, TX 77463  
CT0911/10200

**Digitell System**  
P.M.M.I. Inc.  
Drawer 10  
Old Ocean, TX 77463  
Digitell

**Duct Booster**  
A and E Systems  
3100 Segerstrom  
Santa Ana, CA 92704  
Mobile Heat

**Electric Heaters**  
FASCO Industries, Inc.  
810 Gillespie Street  
Fayetteville, NC 28306  
Model 2450  
Living room, galley & bedroom

**Martin Industries**  
Electric Products Division  
P.O. Box 128  
Florence, AL 35630  
Model CPT 1215 Bathroom

**Intermatic, Inc.**  
Intermatic Plaza  
Spring Grove, IL 60081  
Heat Wave JH 300  
Freeze Protection

**Electric Heat Tapes**  
Easy Heat, Inc.  
31977 U.S. 20 East  
New Carlisle, IN 46552  
MT Cables



Fan, Exhaust  
Jensen Mfg. Co.  
Los Angeles, CA 90040  
262

Fan, Portable  
Guest Corporation  
17 Culbro Drive  
West Hartford, CT 06110  
12-volt Oscillating

Fan, Roof  
Kool-O-Matic  
1831 Terrace Road  
Niles, MI 49120  
RU-12

Faucets  
Stanadyne Moen Division  
377 Woodland Avenue  
Elyria, OH 44036

Flourescent Lights  
Lighting Specialists, Inc.  
P.O. Box 610  
Marble Springs, TX 78654  
NP-IT5-8  
Bath Mirror  
F-15R  
Flush Mount

REC Specialities, Inc.  
530 Constitution Avenue  
Camarillo, CA 93010  
Porch Light

Food Center  
Scovill Industries  
NuTone Division  
Madison and Red Bank Roads  
Cincinnati, OH 45277  
Power Unit, Model 251  
Food Processor Model 256

Fuel Filter - Water Separator  
Racor Industries, Inc.  
1137 Barium Road  
Modesto, CA 95351  
Model 900FG

Furnace  
Suburban Manufacturing Co.  
P.O. Box 399  
Dayton, OH 37321  
Dyna-Trail Model NT-16SW

Gas/Smoke Alarm  
P.M.M.I., Inc.  
Drawer 10  
Old Ocean, TX 77463

Ice Maker  
U-Line Corporation  
8900 North 55th Street  
Milwaukee, WI 53223  
Model BI-45A

Instant Hot Water  
Emerson Electric Co.  
4700 21st Street  
Racine, WI 53406  
Konstant Hot  
E-340-4

Intercom System  
Newport Engineering  
P.O. Box 1306  
Newport Beach, CA 92663  
Model TP-6S NEW MAR

LPG Alarm/Control  
P.M.M.I., Inc.  
Drawer 10  
Old Ocean, TX 77463

LP Gas Grill  
Charmglow Products  
P.O. Box 127  
Bristol, WI 53104  
Model TPC

LPG Tank  
Manchester Tank & Equipment Co.  
2738 Lithonia Industrial Blvd.  
Lithonia, GA 30058  
No. 6042

Leveling Jacks  
HWH  
105 Ninth Street  
Rock Island, IL 61201  
AP 3179

Microwave/Convection Oven  
Sharp Electronics Corp.  
P.O. Box 588  
Paramus, NJ 07652  
Carousel R8340





**Motor Generator**

Honeywell Motor Products  
P.O. Box 106  
4301 Kishwaukee St.  
Rockford, IL 61105  
Model DA 14-L

**Mountz Power Wrench**

Mountz, Inc.  
1080 North 11th Street  
San Jose, CA 95112  
MP2

**Power Generator**

Kohler Company  
Kohler, WI 53044  
12.5 KW

**Radio (AM/FM Stereo Cassette)**

Robert Bosch Sales Corp.  
2800 South 25th Avenue  
Broadview, IL 60153  
Blaupunkt Tucson

**Range and Oven**

Magic Chef, Inc.  
P.O. Box 1145  
Elkhart, IN 46514  
Model BRT 743S-5T

**Reading Lights**

Wemac  
3433 West Harvard  
Santa Ana, CA 92904  
Model 5019

**Refrigerator**

Dometic  
P.O. Box 490  
Elkhart, IN 46515  
RM 1303

**Safeline Warning Device**

Omnifac Corporation  
1700 East Whipp Road  
Dayton, OH 45440  
Model 2

**Shower Hose Kit**

Alsons Corporation  
42 Union Street  
Hillsdale, MI 49242  
500 PB59

**Shower Valve**

Stanadyne Moen  
377 Woodland Avenue  
Elyria, OH 44036

**Tank, Water**

Inca Plastics, Inc.  
11555 Packard Drive  
Middlebury, IN 46540

**TV Antenna**

Tandy Distributor Products  
Swannanoa, NC 28788  
Model 5MS550

**Toilet**

Thetford Corporation  
P.O. Box 1285  
Ann Arbor, MI 48106  
Aqua Magic Galaxy Model 08445

**Washer/Dryer**

Sears Roebuck and Co.  
675 Ponce De Leon Ave., N.E.  
Atlanta, GA 30308  
Washer: 26K4090  
Dryer: 26K8090

**Water Heater**

Mor-Flo Industries, Inc.  
18450 S. Miles Road  
Cleveland, OH 44128  
Marine 10

**Water Pump**

ITT JABSCO  
1485 Daleway  
Costa Mesa, CA 92626  
Model 36950-1180

**Water Purifier**

Astro-Pure, Inc.  
4900 North 15th Street  
Margate, FL 33063  
Astro-Pure Model AP35

**Windshield Wiper Blades (Heated)**

Clear-Vu, Inc.  
924 N. Sugar Avenue  
Nampa, ID 83651  
20 in.





## Section XI Equipment Options

### Awnings

The awnings are standard equipment on your coach and designed for simplicity of operation and long-term use. To open the awning, refer to the figures below and proceed as follows:

#### Open Awning

1. Loosen clamp wheels and tilt inward, as shown in **figure 11-1** (may easily be hand loosened while standing on step).




Figure 11-1.

2. Completely unroll awning by first pulling the tab toward you with the hook and then grasping strap with hands as shown in **figure 11-2**. Fold or roll the strap so the Velcro strips meet and hold tab in place next to the roller. Now move beneath the awning and proceed with step 3.
3. **Extend spring arm** by releasing snap stud and placing claw on shaft of roller, **set spring arm tension** by pushing briskly in direction of arrow as shown in **figure 11-3**. Be sure pin in cap of ratchet stud is facing toward arrow.




Figure 11-2.




Figure 11-3.

4. Referring to **figure 11-4**, raise awning to desired height by extending main arm. Release snap stud and push outward on underside of roller-release snap stud so it will engage at desired height. Lean, so that body weight — rather than arm strength — carries out this step.

### Caution

Be sure to raise high enough to allow for clearance with the top of the door.




Figure 11-4.

### Close Awning

1. Release snap stud on spring arm. Remove spring arm claws from roller shaft and place them on claw pins (on inside of main arms). This **scissors-action** guides the main arms evenly and upward.
2. Release snap stud on main arms and lower awning.
3. While facing the awning, and holding the tab loosely in one hand, give the roller an upward push until the spring takes over. Control the roll-up speed by holding the tab until all but 6" of fabric has rolled up. Release tab and allow awning to roll free for these last few inches and snap closed.

### Note

**The tab must be spiraled around the roller to prevent a loose roll and the bunching-up of fabric.**

4. Tighten clamp wheels before moving vehicle.
5. Observe if the roll-up is even and in-line with clamps. If not, then unroll and give roller a slight push toward the direction required to line up the roller. If you wish to have the awning roll up more in either direction spiral the pull tab in that direction.

### Fabric Care

The fabric of your awning is made of acrylic fibers which cannot rot or mildew. Your awning can be rolled up wet if necessary, but be sure to open it to dry as soon as possible.

The acrylic fabric of your awning is a synthetic

and cannot support mildew or other plant growth. However, mildew can find a home on any pollen, grain dust, plant spores, or other airborne plant material that can accumulate on the awning. If mildew forms on any of these elements, it can leave a stain which can be unsightly and difficult to remove, even though it will not weaken the fabric itself. To minimize the chance of a stain, keep your awnings as clean and dry as possible by hosing it down frequently between seasonal washings.

### Washing

On a monthly basis, loosen hardened dirt and dust with a dry, medium bristle brush, then thoroughly rinse both top and bottom with a hose. For more stubborn stains, use a mild solution of 1/2 cup bleach and 1/2 cup soap flakes diluted in one gallon of lukewarm water.

Wash both sides of the awning with the solution while scrubbing with a soft brush. Saturate the fabric and leave the solution on for 15-20 minutes. (Keep the fabric saturated by reapplying solution as needed.) Rinse **thoroughly**. Repeat if necessary until most of the stains disappear.

### Caution

**Never use a strong detergent (super spray) or stain remover on your awning. These can destroy the water repellency of the fabric.**

### Water Leaks

If leaking occurs after washing, it is usually the result of insufficient rinsing. If water drips through the needle holes in the stitching, you can use a commercial seam sealer available in canvas and trailer supply stores. You may also apply a paraffin wax to the top of the seams. However, as the awning **weathers**, these holes will normally seal themselves.

It is normal for slight leakage to occur through the fabric where water is allowed to accumulate or **pocket** on the fabric. See **Storm Precautions** for information on awning settings for proper water drainage. Sometimes soap or chemical residue, such as from active agents in insect fogs or sprays, can wet the fabric so that it appears unable to repel water. Rinse the fabric thoroughly and test for water repellancy after it dries. If leakage continues, wash the fabric or contact the manufacturer for in-



formation on treating the fabric.

### **Storm Precautions**

Because there is no warranty for damage caused by acts of God, steps should be taken to prevent damage from occurring due to wind, rain or storm.

If you are leaving or retiring for the night, close the awning. This takes only a few seconds (less time than closing your windows) and gives you the best protection. If for some reason you can't close the awning, lower both ends of it as far as you can without removing the spring arms. This will create a sufficient slope for water run-off. If you are remaining with the awning, you may lower one end only sufficiently to divert water.

### **Hardware and Mechanism Maintenance**

Although your awning requires less maintenance than any other awning, a little care (about the same amount that you give to your coach) will keep the metal parts in top shape. The rafter arm assemblies, main arm tubes, and the awning case are bright-anodized aluminum; the castings are polished, high-strength aluminum alloys. To keep these parts new looking they should be cleaned once a year with a good quality chrome or aluminum polish.

The main arm bar and all fasteners and stress bearing shafts are stainless steel. These need only be cleaned occasionally to remove accumulated grime that might hinder their operation.

#### **At the end of each season:**

- Tighten any loose bolts or screws. (Replace missing parts only with factory authorized replacements.)
- Polish accessible hardware.
- Use a silicone lubricant only on the 1/2" round shafts that protrude from each end of the roller.
- Extend all telescoping arms as far as possible to wipe off accumulated sand and dirt that can clog and scratch the protective aluminum finish.

### **Ice-Maker**

The ice-maker, figure 11-5, is designed to provide a continuous automatic supply of ice cubes. It will operate unattended providing that the water supply line is open and the ac power is applied to the unit. This may be supplied from shore power, the power generator, or from the optional motor generator (Redi-Line).

### **Ice-Maker Operation**

The power on-off switch is located on the front grillework. When the ice cube supply is full, the ice-making mechanism shuts off automatically. However, the refrigeration system continues to operate to prevent the prepared ice cubes from melting. When removing cubes, do not use a sharp instrument to separate the cubes that are frozen together or the interior may be damaged.

Note that the ice-maker may supply small cubes the first time that it is used. This is due to accumulated air in the water line and subsequent batches will be normal-sized.

If the machine is used only intermittently, empty the ice periodically (every week to 10 days) to ensure a fresh supply of cubes.

Do not clean the cabinet interior with solvent-type cleaners, abrasives, or other cleaners that might cause ice cubes to acquire a bad taste. The exterior should be cleaned with a furniture-type cleaner/polish. Clean condenser (behind grille) with a blower/vacuum at least 3 to 4 times each year, depending on usage.

### **Caution**

**The ice-maker grille must be free from all obstructions. Any interference with free air flow to the grille will cause faulty operation.**

To shut down the ice-maker, set power switch to off, and remove all cubes. Leave the door slightly ajar for ventilation to avoid mold or odors.




Figure 11-5 Ice-Maker Details.

### Ice-Maker Maintenance

Other than periodic cleaning of grillework, condenser and interior, no other maintenance procedures are required. Remove the grille as follows: take out screw at top, put fingers in slots and lift up and out.

### Winterizing

Follow procedure in Section V. To facilitate draining of water line, remove garden hose type fitting shown in figure 11-5

### Microwave/Convection Oven

The microwave/convection oven provides programmed microwave cooking, convection operation for crisp, even browning, or a combination of both. It may be used whenever your coach is plugged into shore power or the power generator is running.

### Caution Notes:

1. Unlike microwave-only ovens, all microwave/convection ovens have a tendency to become hot on the cabinet and oven door, as do conventional range ovens and convection-only ovens. Be careful when touching parts other than the handle or control panel during or immediately following cooking that uses convection heat.
2. Do not cook eggs in the shell. Steam builds up inside the shell and it may explode from pressure. Shelled hard-cooked eggs should be sliced or cut up before reheating in the microwave oven. You may hard-poach eggs for salads and casseroles.
3. Pop popcorn only in special microwave poppers, following manufacturer's directions. Do not use oil unless specified by the manufacturer, or heat longer than recommended. Never pop popcorn in paper bags or glass utensils.
4. Do not heat oil or fat for deep-frying. The temperature of the oil cannot be controlled and it may overheat.
5. Do not attempt to can in the microwave oven as it requires prolonged high temperatures.
6. Do not operate the oven empty.

This oven uses a microprocessor, the electronic brain that provides a wide variety of cooking programs which could not be achieved by conventional control methods. The operation of the oven is controlled by touching the appropriate pads arranged on the surface of the control panel, figure 11-6. The lighted digital readout will display the cooking time, convection temperature, memory or time of day, and indicators show the variable cooking setting or cooking function you have programmed.

An audible entry signal tone should be heard each time you touch the control panel to make a correct entry. If you do not hear this sound,

1. You have not used enough pressure in touching the pad,
2. You have made more entries than the control panel will accept,
3. You have made an incorrect entry.



In addition to the entry signal tone, an audible signal will sound for approximately 2 seconds at the end of the cooking cycle.




Figure 11-6. Control Panel.



Basic operation, only will be presented here. For complete information, refer to the Operation Manual and Cook Book supplied for you by the oven manufacturer. It is suggested that you first practice operating the oven with a glass measuring cup full of water rather than food.

### To Set the Clock

Set the clock as follows:

1. Touch the **AUTO START CLOCK** pad.
2. Enter the correct time of day by touching the numbers in sequence.
3. Touch the **AUTO START CLOCK** pad again. Time will be displayed with a colon between the hours and minutes.

### Note

If power is interrupted, and then restored, 88:88 will show intermittently. When an incompatible clock time is entered, such as 13:61, two E's (EE) will show in the readout.

### Microwave Cooking

1. Make certain the metal turntable is seated and in place. The oven should not be used without the turntable in place, and it should never be restricted so that it cannot rotate.
2. Select the rate of cooking (or defrosting). There are four levels or settings for cooking: **HIGH**, **MED HIGH**, **MED** and **MED LOW**. If you do not touch a setting on the control panel, the oven will automatically cook at **HIGH**.
3. Enter desired cooking time by touching numbers. One minute, thirty seconds will show on the display as 1.30.
4. Touch **COOK**.

### Microwave Utensils

The ideal material for a microwave utensil is transparent to microwaves; it allows energy to pass through the container and heat the food. Many ordinary household items, such as paper, plastic or wooden bowls may be used to warm foods to serving temperature.

When a utensil is used for cooking, it must also be able to withstand contact with very hot food or

boiling liquid. Manufacturers are now marketing dual-purpose, heat resistant paper and plastic utensils which can be used in both microwave and conventional ovens; in addition, many traditional cooking containers are suitable for microwaving.

Usable metal includes aluminum foil for shielding, small skewers, and shallow foil convenience food trays. The amount of metal used must be in proportion to the volume of food; foil trays should be two-thirds to three-fourths full.

Keep metal at least 1 inch away from oven walls to prevent arcing. Deep trays and metal pans are unsuitable because they reflect too much energy away from food. Foil-lined cartons shield food completely, so it does not heat at all.

### Convection Cooking

During convection heating, hot air is circulated throughout the oven cavity to brown and crisp foods quickly and evenly.

1. The oven should not be used without the metal turntable in place and it should never be restricted so that it cannot rotate. You may remove the turntable when preheating the oven or when preparing food to be cooked directly on the turntable; cookies, for example.
2. Preheating may be accomplished by the following:
  - a. Touch the **CONVECTION** pad.
  - b. Touch the desired pre-heating temperature.
  - c. Touch the **COOK** pad. Convection fan symbol will flash on and off. When the oven reaches the programmed temperature, the convection fan symbol will stop flashing and begin rotating with an audible signal sounding four times. Preheat temperature will be held for 15 minutes. After this period the audible signal will again sound four times and the oven will turn off.
3. **Convection – Only** cooking may be performed as follows:
  - a. Enter desired cooking time by touching numbers. Twelve minutes will show on the display as 12.00.
  - b. Touch **CONVECTION** pad.
  - c. Enter desired temperature.





d. Touch cook pad. **COOK** indicator will light and Convection fan symbol will rotate. When the timer reaches zero (0), **COOK** and **CONV** indicators and the convection fan symbol will go out. An audible signal will sound and the time of day will reappear on the display. You may check the oven temperature setting, while cooking, by touching the **CONVECTION** pad.

### **Convection Utensils**

Microwave-only paper and plastic products should not be used for combination cooking or placed in the oven while it is still hot from convection cooking.

Be sure to use hot pads when handling utensils. They become hot from convection and combination cooking.

The metal carousel is a utensil itself: a drip pan under the broiling trivet during roasting and broiling, or a baking sheet for breads and cookies.

Baking rack serves as a shelf for two-level cooking, such as layer cakes or cookies. Use it for convection and combination cooking, not for microwaving alone.

Metal and aluminum foil pans are safe for combination as well as convection cooking. During the convection cycle heat transferred from the pan cooks the bottom and sides of food. During the microwave cycle, energy penetrates from the top.

Oven glass is excellent for convection, combination and microwave cooking. Stoneware and pottery utensils designed for use in ovens may be used if they are also microwave-safe.

Ovenable paper is designed for use in both microwave and conventional ovens up to 400°, so it's suitable for convection or combination cooking too.

### **Mountz Power Wrench**

Useage described in Section VIII.

### **Konstant Hot Water Dispenser**

Operated from 120V. ac (shoreline or power generator) to provide instant hot water.

Winterizing instructions are provided in Section V.

### **Kool-O-Matic Ventilation Fan**

This 12V. dc power ventilator has the capacity to move a large volume of air.

In many low humidity regions it will eliminate the need for operating air conditioning units.

### **Operation**


Remove fabric cover and open inlet dampers (where applicable) before turning the control knob to one of three speeds for the ventilation level required.

Be sure windows are open to provide proper air flow cooling and ventilation.

Some installations have been provided with a wall mounted thermostatic control in place of the integral switch. This will make sure the fan operates automatically whenever the temperature rises above a desired level.

### **Redi-Line Motor Generator**

The motor-generator unit is an ac-generator that is driven by a 12-volt dc motor to provide the isolated 120-volts ac for the ice-maker. The motor-generator operates automatically, on demand, whenever the external control circuit to the respective appliance is completed and the ignition switch is on.







Figure 10-1. Diagram, Chassis and Water Heater / Circuits



CIRCUIT BREAKER CHART

1	14-GA. RED	RACOR RELAY
2	14-GA. YEL.	AIR DRYER
3	14-GA. YEL.	RACOR RELAY
4	14-GA. TAN.	AIR WARNING
5	14-GA. WH/BLK.	ACC. TERM., CONTAM & LOW FUEL
	14-GA. RED	ENG. WARNING
6		
7		
8	16-GA. #8-ORN.	W/S WIPER HEAT ---Ⓞ
	14-GA. #8-BLK.	LEV. JACK MASTER SW. ---Ⓞ
9	14-GA. #9-BLK.	CIGAR LIGHTER ---Ⓞ
	14-GA. #9-ORN.	ELECTRIC DOOR LOCK ---Ⓞ
10	14-GA. #10-BLK.	W/S WASHER ---Ⓞ
	14-GA. #10-PURPLE	DEFROSTER BLOWER ---Ⓞ
11	14-GA. #11-GRN/WH.L.H.	HEATER BLOWER ---Ⓞ
	14-GA. RED	ELECTRIC SEAT L.H.
12	14-GA. #12-ORN/BLK	RH HEATER BLOWER ---Ⓞ
	14-GA. #12-GRN	COMP. LT. MASTER ---Ⓞ
	14-GA. RED	ELECTRIC SEAT RH
13	14-GA. #13-BLK	MIRROR HEATERS SW ---Ⓞ
14	14-GA. #14-PINK	DOOR LOCK LT. ---Ⓞ
	14-GA. #10-RED	DIGITEL
15	14-GA. PINK	REDILINE GEN. SOL.
	14-GA. #15-PURPLE	FRONT HEAT SW. ---Ⓞ
	14-GA. #15-RED	LEV. JACK BUZZER & LIGHT. ---Ⓞ
16	14-GA. #16-BLK.	SUSP. DUMP LIGHT ---Ⓞ
	14-GA. #16-GRN	MAX. F/F LIGHT ---Ⓞ
	16-GA. #16-ORN.	BULK OIL FILL AIR PRESS. LT. ---Ⓞ
17	14-GA. #17-BLU.	LEFT W/S WIPER ---Ⓞ
	14-GA. #17-RED	INTERMITTENT WIPER ---Ⓞ
18	14-GA. #18-BLU.	RIGHT W/S WIPER ---Ⓞ
	14-GA. #18-RED	LOW WASHER FLUID IND. ---Ⓞ
19	14-GA. #1-GRN.	PARK & TAIL LYS.
20	10-GA. #2-YEL.	DRIVING LT. SOL.
21	14-GA. #3-GRN.	STOPLIGHTS
22		CIRCUIT BREAKER NOT IN USE.
23		
24	10-GA. #5-YEL.	DIRECTIONAL SOL. RH & LH REAR
	14-GA. #6-RED/BLK.	BACK UP LIGHTS SW.

NOTE: Ⓞ DENOTES WIRES TO BE EXTENDED OFF BREAKERS 24" @ THE TOP OF THE BREAKER PANEL.

ALL OTHER WIRES WILL BE CONNECTED AFTER PANEL IS INSTALLED IN THE COACH.

NOTE: BEGIN WITH BODY NO. 63422

Figure 10-2. 12 Volt Diagram, Lower Front Load Center




Figure 10-3. 12 Volt Diagram, Overhead Front Load Center




Figure 10-4. 12 Volt Diagram, Left Front Load Center

Right Front Ld. Ctr. Side Bath




Figure 10-5. 12 Volt Diagram, Right Front Load Center





Figure 10-6. 12 Volt Diagram, Left Rear Load Center.

#18 Black - Dry Air Switch - water heater





**Right Rear Ld. Ctr.  
Side Bath**

PIN NO.	CIRCUIT BRK.	DESCRIPTION
1	1	16 Ga. White/Green #25 - Kitchen Fluor. Ceiling Lights
2	2	14 Ga. Yellow #27 - Bedroom Fluor Lights/Hall Fluor. Ceiling Lights
3	3	16 Ga. Green/Black #1 - RH Closet Light Switches
4	4	14 Ga. Dark Blue #26 - Bedroom Reading Lights
5	5	16 Ga. Red/Black #3 - Bedroom 12V Outlet
6		14 Ga. Dark Green #22 - Bedroom Chassis Heat Switch
7		<b>16 Ga. Lt. Blue #18 Right Front Ld. Ctr. (Thermostat)</b>
8		16 Ga. Tan #19 - Ign. Wire for Sum/Win Solenoid Valve
9		16 Ga. Red/Black #23 - Winter Solenoid Valve Wire
10		18 Ga. Black #24 - Summer Solenoid Valve Wire
12	1	<b>16 Ga. Orange #18 AC Switch Relay</b>
13	7	<b>14 Ga. Gray #2 Camera Defog</b>

Figure 10-7. 12 Volt Diagram, Right Rear Load Center





Figure 10-8. 12 Volt Diagram, Batteries and Charging Circuits

ITEM NO.	QTY.	S. S. NUMBER	VEHICLE & TRAILER NO.	DESCRIPTION
1	1			Air Compressor
2	1	075929	B-W #22729	Reservoir, 8 x 24 / 1240 Cu. In.
3	4	082078		Reservoir Brackets - 1240 Cu. In.
4	4	053886		Spacer, Air Tank Bracket
5	1	065433	B-W #284171	Valve, Dual Brake, 25
6	1	113347	B-W #229938	Trunking Assy., W/Double Cover, Model# 28938
7	1	094517	B-W #238888	Flr. Bolsters, Dual Brake Valve
8	1	064509	B-W #23212	Roll Pin, Bolster
9	1	064443	B-W #231880	Stop Button
10	1	064443	B-W #231880	Stop Button
11	1	064443	B-W #231880	Stop Button
12	1	064443	B-W #231880	Stop Button
13	1	064443	B-W #231880	Stop Button
14	1	064443	B-W #231880	Stop Button
15	1	064443	B-W #231880	Stop Button
16	1	064443	B-W #231880	Stop Button
17	1	064443	B-W #231880	Stop Button
18	1	064443	B-W #231880	Stop Button
19	1	064443	B-W #231880	Stop Button
20	1	064443	B-W #231880	Stop Button
21	1	064443	B-W #231880	Stop Button
22	1	064443	B-W #231880	Stop Button
23	1	064443	B-W #231880	Stop Button
24	1	064443	B-W #231880	Stop Button
25	1	064443	B-W #231880	Stop Button
26	1	064443	B-W #231880	Stop Button
27	1	064443	B-W #231880	Stop Button
28	1	064443	B-W #231880	Stop Button
29	1	064443	B-W #231880	Stop Button
30	1	064443	B-W #231880	Stop Button
31	1	064443	B-W #231880	Stop Button
32	1	064443	B-W #231880	Stop Button
33	1	064443	B-W #231880	Stop Button
34	1	064443	B-W #231880	Stop Button
35	1	064443	B-W #231880	Stop Button
36	1	064443	B-W #231880	Stop Button
37	1	064443	B-W #231880	Stop Button
38	1	064443	B-W #231880	Stop Button
39	1	064443	B-W #231880	Stop Button
40	1	064443	B-W #231880	Stop Button
41	1	064443	B-W #231880	Stop Button
42	1	064443	B-W #231880	Stop Button
43	1	064443	B-W #231880	Stop Button
44	1	064443	B-W #231880	Stop Button
45	1	064443	B-W #231880	Stop Button
46	1	064443	B-W #231880	Stop Button
47	1	064443	B-W #231880	Stop Button
48	1	064443	B-W #231880	Stop Button
49	1	064443	B-W #231880	Stop Button
50	1	064443	B-W #231880	Stop Button
51	1	064443	B-W #231880	Stop Button
52	1	064443	B-W #231880	Stop Button
53	1	064443	B-W #231880	Stop Button
54	1	064443	B-W #231880	Stop Button
55	1	064443	B-W #231880	Stop Button
56	1	064443	B-W #231880	Stop Button
57	1	064443	B-W #231880	Stop Button
58	1	064443	B-W #231880	Stop Button
59	1	064443	B-W #231880	Stop Button
60	1	064443	B-W #231880	Stop Button
61	1	064443	B-W #231880	Stop Button
62	1	064443	B-W #231880	Stop Button
63	1	064443	B-W #231880	Stop Button
64	1	064443	B-W #231880	Stop Button
65	1	064443	B-W #231880	Stop Button
66	1	064443	B-W #231880	Stop Button
67	1	064443	B-W #231880	Stop Button
68	1	064443	B-W #231880	Stop Button
69	1	064443	B-W #231880	Stop Button
70	1	064443	B-W #231880	Stop Button
71	1	064443	B-W #231880	Stop Button
72	1	064443	B-W #231880	Stop Button
73	1	064443	B-W #231880	Stop Button
74	1	064443	B-W #231880	Stop Button
75	1	064443	B-W #231880	Stop Button
76	1	064443	B-W #231880	Stop Button
77	1	064443	B-W #231880	Stop Button
78	1	064443	B-W #231880	Stop Button
79	1	064443	B-W #231880	Stop Button
80	1	064443	B-W #231880	Stop Button
81	1	064443	B-W #231880	Stop Button
82	1	064443	B-W #231880	Stop Button
83	1	064443	B-W #231880	Stop Button
84	1	064443	B-W #231880	Stop Button
85	1	064443	B-W #231880	Stop Button
86	1	064443	B-W #231880	Stop Button
87	1	064443	B-W #231880	Stop Button
88	1	064443	B-W #231880	Stop Button
89	1	064443	B-W #231880	Stop Button
90	1	064443	B-W #231880	Stop Button
91	1	064443	B-W #231880	Stop Button
92	1	064443	B-W #231880	Stop Button
93	1	064443	B-W #231880	Stop Button
94	1	064443	B-W #231880	Stop Button
95	1	064443	B-W #231880	Stop Button
96	1	064443	B-W #231880	Stop Button
97	1	064443	B-W #231880	Stop Button
98	1	064443	B-W #231880	Stop Button
99	1	064443	B-W #231880	Stop Button
100	1	064443	B-W #231880	Stop Button
101	1	064443	B-W #231880	Stop Button
102	1	064443	B-W #231880	Stop Button
103	1	064443	B-W #231880	Stop Button
104	1	064443	B-W #231880	Stop Button
105	1	064443	B-W #231880	Stop Button
106	1	064443	B-W #231880	Stop Button
107	1	064443	B-W #231880	Stop Button
108	1	064443	B-W #231880	Stop Button
109	1	064443	B-W #231880	Stop Button

Figure 10-12. Air System (Sheet Two)



196

**Figure 10-12. Air System  
(Sheet One)**

(A)

PART NO.	DESCRIPTION	QTY.
1. 0522516	TEE ST. 1/2	12
2. 2224483	ELBOW FPT 1/2	3
3. 2233930	ELBOW ST. 1/2	9
4. 2023539	BUSHING 1/2X3/8	5
5. 2250371	BUSHING 3/8X1/4	1
6. 2027134	BUSHING 1/2X1/4	4
7. 2196459	NIPPLE 1/2 CLOSE	4
8. 3758547	NIPPLE 1/2X1 1/2	1
9. 3764388	NIPPLE 1/2X5	1
10. 3758570	NIPPLE 1/2X4	1
11. 0392308	VALVE CHECK 1/2	3
12. 2027076	NUT FLARE 3/8	13
13. 2027084	NUT FLARE 1/2	16
14. 2027092	NUT FLARE 5/8	8
15. 2027381	TUBE COPPER 3/8	5 FT.
16. 2027399	TUBE COPPER 1/2	32 FT.
17. 2027407	TUBE COPPER 5/8	34 FT.
18. 2274744	TUBE POLYBUTYL 1/4	9 FT.
19. 2234110	TUBE PLASTIC 1/4	12 FT.
20. 2255933	HOSE 1/2	6.5 FT.
21. 2271906	ELBOW 1/2 FPTX 3/8 FL.	1
22. 2235513	ELBOW 1/2 MPT X1/2 FLARE	2
23. 2026706	ELBOW 1/2 MPT X5/8 FLARE	1
24. 2017739	ELBOW ST.1/2 FPT X 5/8 FLARE	1
25. 3741873	ELBOW 1/2 MPT X1/2 HB PLASTIC	2
26. 2027779	ELBOW 3/8 MPT X 1/2 HB	4
27. 2265155	ELBOW 3/8 MPT X3/8 FLARE	1
28. 2274561	TEE 1/2 FL X3/8 FL X1/2 FL	1
29. 2027258	TEE 3/8 FPTX 3/8 FPT X 3/8 FPT	1
30. 2247757	TEE 1/2 HB X 1/4 MPT X 1/2 HB	1
31. 2009298	NIPPLE CLOSE 1/8	1
32. 2017721	CONNECTOR 1/2 FPT X 5/8 FL.	2
33. 2217008	CONNECTOR 1/2 FPT X 1/2 FL	2
34. 0377366	CONNECTOR 1/2 FPT X 3/8 FL	1
35. 2253979	COUPLING 1/4 MPT X 3/8 FL	2
36. 0388231	COUPLING 3/8 MPT X 3/8 FL	1
37. 2245199	COUPLING 3/8 MPT X 1/4 MPT	3
38. 2026472	COUPLING 1/2 MPT X 5/8 FL	3
39. 2260222	COUPLING 1/2 MPT X 1/2 FL	10
40. 2257897	COUPLING 1/2 MPT X 3/8 FL	2
41. 3758596	COUPLING 1/2	1
42. 2216125	CONNECTOR 1/2 MPT X 1/2 HB	4
43. 2017390	VALVE 1/2 FPT X 3/8 FL (TOILET)	1
44. 2264604	VALVE BALL 1/2	1
45. 3765666	ASSY SHOWER FIXTURE	1
46. 3776028	ADAPTER 1/2 X1/2 w1/4 TAP	1
47. 2257903	CROSS 1/2	1
48. 2204634	CONNECTOR 1/4 MPTX 1/4 FERREL	2
49. 2016921	FILTER PUMP GUARD	1
50. 2251122	VALVE	1
51. 2268514	PURIFIER WATER	1
52. 2273712	ACCUMULATOR TANK	1
53. 2016913	PUMP	1
54. 2234284	VALVE WATER HEATER DRAIN	1
55. 3738219	VALVE 3-WAY	1
56. 2264535	VALVE ELBOW	1
57. 3747730	REGULATOR	1
58. 2235216	ELBOW 1/4 MPT X 1/4 TUBE	1
59. 2219319	SWITCH AIR	1
60. 2240236	TANK POTABLE WATER	1
61. 2265544	FILL CITY WATER VALVE	1
62. 3762804	SENSOR DRY TANK	1

3805744





Figure 10-9. Potable Water System


ITEM	PART #	QTY	DESCRIPTION
1	3189984	5	Adapter 3" M.A.L.S
2	2198697	2	Valve Assembly Pump Twist -
3	2230843	3	Ell St. 3" x 90° Long Sweep
4	2235208	1	Tee 3" S x S x S
5	2198711	1	Adapter In-FBX Bayonet Dump Valve
6	2198703	1	Cap & Chain Bayonet Dump Valve Assembly
7	2200040	2	Adapter 2" M.A.L.S
8	2230835	2	Ell St. 2" x 90° Long Sweep
9	2230801	3	Elbow 2" x 90° Long Sweep
10	2199644	4	Elbow 2" x 45°
11	3743291	1	Tee Wye Long Turn Single 2"
12	2200040	1	Adapter Male 2"
13	2221570	1	Plug Threaded 2" ABS
14	0538314	2	Tee Sanitary 2" x 1 1/2" x 1 1/2"
15	2200616	1	Bushing Reducer 2" x 1 1/2"
16	3738903	2	Street Ell 90° x 1 1/2"
17	0417618	2	Tee Sanitary 1 1/2"
18	2230785	3	Elbow 1 1/2" x 90° Bend Vent - ABS
19	2193852	3	Trap "P" with Double Seal Union 1 1/2"
20	2221554	1	Adapter Fitting Cleanout
21	2221588	1	Vent Check #140
22	2221406	1	Adapter Trap Fitting
23	2017499	3	Ell Long Turn 45° x 1 1/2"
24	3741991	1	Trap Adapter - Female with Wash/Nut 1 1/2"
25	3741949	1	Trap Adapter - Female with Wash/Nut 1 1/2" X 1 1/4"
26	2215267	1	Faucet Bathroom #4021 Chateau Lav.
27	0580690	2	Strainer Model D-5036 W/Basket 2" Opening
28	2017002	1	Strainer 1/2 WS Shower
29	2227759	1	Valve Overflow 10-910
30	2264810	1	Outlet Center Continuous Waste
31	3758901	1	Vent, Roof Vac-U-Jet
32	2200606	1	Nipple Half 3" x 1/2"
33	2017218	1	Flange Closet 3 FPT 1000 P
34	2199453	-	Pipe Plumbing Plastic 3"
35	2017317	-	Pipe Plastic 2"
36	2017333	-	Pipe Plastic 1 1/2"
37	0901125	1	Tank Waste Holding Sink
38	0901117	1	Tank Waste Holding Toilet

Plumbing, Drainage WLFC S.B.



Maximum Trap Arm Length; 54"

Figure 10-10. Drainage System



ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	0929554	Tank, LPG	1
2	1019231	Regulator, High, Pressure	1
3	0654277	Tee, 1/4" Street	1
4	0976068	Hose, LPG	1
5	2023232	Coupling, 1/4"	2
6	2027183	Nipple, 1/4" Close	1
7	2026987	Elbow, 1/4 x 3/8 IF	2
8	2026821	Nut, 3/8" IF	2
9	2027381	Tubing, 3/8" Copper	22 ft.
10	2254050	Valve, Range	1
11	3757499	Valve, Furnace	4
12	2245454	Valve, LPG Shut Off	2
13	2259307	Regulator, Low Pressure	2
14	2259315	Valve, Auto, Shut Off	1
15	2260719	Elbow, 1/4 P. x 3/8 Fl.	6
16	2222727	Ell, St. 1/2 P.	2
17	2253979	Connector 1/4 P. x 3/8 Fl.	3
18	2257897	Connector 1/2 P. x 3/8 Fl.	1
19	2240117	Connector 1/8 P. x 3/8 Fl.	1
20	2222735	Nipple, Hex. 1/2 P. x 3/8 P.	5
21	2196459	Nipple, 1/2 Close	5
22	2257905	Cross, 1/2 P.	2
23	2265106	Coupling, Anchor 1/4 P.	1
24	2207157	Cap, 3/8 Fl.	1
25	3743994	Nut, 3/8 Fl. Forged	18
26	2266054	Socket, Quik Disconnect	1
27	2027381	Tubing, 3/8 Copper	

Figure 10-11. Liquid Petroleum Gas System