#24 RED 1/0 TO 50A BRKR. LH FRT CMPT. PNL.
105A BREAKER
1/0
#22 RED 1/0 TO BRK2-2 CMPT. PNL. A
#23 RED 1/0 TO 50A BRKR. OH FRT. CMPT PNL.
105A BREAKER
#25 RED 1/0
DC VOLTS COACH
COACH BATTERY CHARGE
#0 BLU 14GA.
#10 PUR 14GA.
#1 BLU 14GA.
AUX BATT. SOLENOID
D2
#16 YEL 14GA.
TO FRAME RAIL
#37 BLK 1/0
#33 BLK 1/0
TO GENERATOR (GND)
INS. STUD
#31 RED 1/0
INS. STUD
4/0
TO CHASSIS BATTERIES
INS. STUD
#1 YEL 14GA.
D1
#32 RED 1/0
#15 YEL 14GA.
#77 RED 14GA.
#1 BLK 14GA.
#28 RED 1/0
TO GENERATOR STARTER
#41 RED 1/0
#48 TO LEVELING JACK PUMP
#29 RED 1/0
MASTER SOLENOID
#41 WHT 14GA.
#26 RED 1/0
#27 RED 1/0
#30 RED 1/0
DC VOLTS ENGINE
#21 RED 1/0 TO BRK1-2 CMPT. PNL. A
BATTERY ISOLATOR
12V COACH BATTERY
12V COACH BATTERY
12V COACH BATTERY
12V COACH BATTERY
INSTALL ONLY WHEN OPTION #5633 - INVERTER IS REQUESTED.
#2 BLK 14GA.
30A BREAKER
#1 RED 8GA. TO REFRIGERATOR
#2 YEL 14GA.
COACH LOAD
#3 14GA BLU
TO TER STRIP-1 CMPT. PNL. B
#36 RED 1/0
#49 RED 1/0
#2 RED 8GA.
COACH ALT./CHGR. AMPS
#34 BLK 1/0
#35 RED 1/0
#31 ORN/BLK 14GA.
BATTERY CHARGER CURRENT OUTPUT RELAY
85 86 30 87
#3 BLK 14GA.
#25 RED 14GA. TO BAT. CHARGER HI/LO SW.
#45 RED 8GA.
#42 RED 8GA.
INVERTER
GRN
INSTALL ONLY WHEN OPTION #5633 - INVERTER IS REQUESTED.
#47 WHT 6GA.
BONDING WIRE (TO CHASSIS GND)
#38 WHT 8GA.
BATTERY CHARGER
ENGINE BATTERY CHARGE ENABLE SOLENOID
#44 BLU 4GA
#40 RED 1/0
TO ALTERNATOR
#39 WHT 8GA.
BATTERY CHARGER
#43 RED 8GA.
#3 YEL 14GA.

NOTES:
1. COMPONENTS SHOWN ABOVE THE DASHED LINE ARE LOCATED IN THE LH FRT. OUTSIDE COMPARTMENT. (WITH EXCEPTION OF THE GAUGES WHICH ARE LOCATED INSIDE THE COACH IN THE LOWER AND OVERHEAD DASH PANELS)
2. COMPONENTS SHOWN BELOW THE DASHED LINE ARE LOCATED IN THE RH FRT. OUTSIDE COMPARTMENT.

INACTIVATES NO.	3903192
REPLACED BY	3931193

LET.	REVISONS	DR.	APP.	CK.	CCN	DATE	REL.

INACTIVE 7-26-89 PER CCN # 8795

REL.	CCN		SCALE
	8704	BLUE BIRD WANDERLODGE FORT VALLEY, GEORGIA USA	-----

DIAGRAM, WIRING, CHARGING CIRCUIT

1989 WLSP

DR. 4-4-89	BY J. MEYER	SIZE	INACTIVE
APP. 4-6-89	BY C Hallam	B	3929239
CK.	BY		