

	FUSE/BREAKER CIRCUITS	(AMPS)
SK1	LEVEL WARNING; IGN RELAY OH FRT HEADLGT ALERT	15
SK2	RH W/S WIPER	15
SK3	LH W/S WIPER	15
SK4	RADAR DETECTOR; AIR VALVE	15
SK5	SGM CHASSIS A/C & HEAT	30
SK6	A/C HEAT CONTROL	30
SK7	<NOT LISTED>	
SK8	ENG BRK STOPLIGHTS	15
SK9	FOG/DRIVING LIGHTS	15
SK10	ELEC MASTER SW (FILTERED)	30
SK11	BURGLAR ALARM	15
SK12	STEP SYSTEM	15
SK13	CELLULAR PHONE MEMORY	5
SK14	SPARE	
SK15	SPARE	
SK16	SPARE	
SK17	SPARE	
SK18	SPARE	
SK19	O.S. COMPT. LGTS	15
SK20	REAR VIEW CAMERA; ELEC. SEAT LH	15
SK21	SPARE	
SK22	PILOT FLUD. LGT.; DOOR LOCK	15
SK23	RECEPT 12VDC/AIR VENTS	15
SK24	LEVELING JACKS	15
SK25	O.S. MIRROR REMOTE CTRL.; O.S. MIRROR HEAT	15
SK26	AUX AIR COMPRESSOR RELAY	15
SK27	DRIVING/FOG LGTS.	15
SK28	CLEARANCE LIGHTS	15
SK29	POWER AMP, FRT.	30
SK30	PARK/TAIL LGTS PWR	15
SK31	HEADLIGHTS	25
SK32	SUSP. DUMP AIR VALVE; TAG DUMP AIR VALVE	15
SK33	GENERATOR ACTUATOR	30
SK34	STEP LGTS.	15
SK35	AUX BAT/DOOR LOCK LGT	15
SK36	12V FILTER COIL	15
SK37	C.B. RADIO MEMORY	15
SK38	RADIO MEMORY	15
SK39	SPARE	
SK40	SPARE	
SK41	SPARE	
SK42	SPARE	
SK43	EQUALIZER PWR	15
SK44	STEP SYSTEM ENABLE RELAY	15
SK45	CELLULAR PHONE PWR	5
SK46	COMPARTMENT LOCKS	15
SK47	SPARE	
SK48	CB RADIO	15

SK49	SPARE	
SK50	MUSICAL HORN	15
SK51	W/S WIPER COLUMN PWR.	5
SK52	TUNER/CASSETTE	15
SK53	BEDROOM STEREO	15
SK54	SPARE	
SK55	PARKING LIGHT	15
SK56	STOP LIGHTS	15
SK57	HORN	15
SK58	HAZARD LIGHTS; REAR DIRECTIONAL LGTS.	15
SK59	FLASHER; DIRECTIONAL LGTS.	15
SK60	12V FILTER	30
SK61	AUTO GEN START	2
SK62	SPARE	
SK63	UTILITY CMPT. LGT.; A/T SYSTEM HIGH IDLE/PARKING BRAKE PRESS. SW; COOLANT LEVEL	15
SK64	MODULE; NEUTRAL SAFETY RELAY	15
SK65	DDEC ECU PWR.; ATEC ECU PWR	15
SK66	BACK-UP LGTS.; SUSP. DUMP RELAY	15
SK67	UPR. DASH IGNITION; LOW AIR BUZZER; QUICK START	15
SK68	RACOR FILTER; ENGINE FAN	15
SK69	LEVELING JACK IGN/STEP IGN TRIGGER	15
SK70	LWR. DASH IGNITION; AIR DRYER	15
SK71	DIRECTIONAL LGTS. COLUMN SW.	15
SK72	STOP ENGINE BUZZER; TRAN TEMP/STEP LGT	15
BRK1	TO CONSTANT 12V SIDE OF MASTER SWITCH	50
BRK2	TO 105A BREAKER IN LH FRT. OUTSIDE CMPT.	50
BRK3	LINKED TO BRK2	50
BRK4	HEADLIGHTS	15
BRK5	ECU RELAYS	15
BRK6	HI BEAM IND/DRIVING LGTS	15

TERMINAL STRIP CIRCUITS

1	SIGNAL GROUND
2	ABS ACTIVE SIG
3	SPARE
4	SPARE
5	STOP LGTS
6	PARK/TAIL LGTS.
7	BACK-UP LGTS.
8	RH DIRECTIONAL LGTS.
9	LH DIRECTIONAL LGTS.
10	RH FRT. DIRECTIONAL LGTS.
11	LH FRT. DIRECTIONAL LGTS.
12	LO BEAM HEADLIGHTS
13	HI BEAM HEADLIGHTS

RELAY CIRCUITS

K1 RH W/S WIPER LO
K2 LH W/S WIPER LO
K3 RH W/S WIPER HI
K4 LH W/S WIPER HI
K5 NOT USED
K6 DRIVING/FOG LGTS
K7 CLEARANCE LGT ENABLE
K7A CLEARANCE LGT
K8 HEADLGT ALERT
K9 AUX BATT. SOLNOID
K10 ENT. DOOR LOCK
K11 ENT. DOOR LOCK
K12 NOT USED
K13 NOT USED
K14 ENT. STEP SYSTEM
K15 ENT. STEP SYSTEM
K15A ENT. STEP SYSTEM
K16 NOT USED
K17 HI IDLE
K18 BRAKE SW.
K19 ENG BRK STOPLGTS
K20 TRAN OVER TEMP LGT
K21 NOT USED
K22A ENG BRK
K22B ENG BRK
K22C ENG BRK ENABLE (DISCONNECTED?)
K23 REVERSE
K24 NEUTRAL SAFETY
K25 ELEC. HORN
K26 DIRECTIONAL CTRL
K27 DIRECTIONAL CTRL
K28 DIRECTIONAL CTRL
K29 DIRECTIONAL CTRL
K30 DIRECTIONAL CTRL
K31 DIRECTIONAL CTRL
K32 DIRECTIONAL CTRL
K33 DIRECTIONAL CTRL
K34 HEAD LGT. HI BEAM
K35 HEAD LGT. LO BEAM
K36 IGNITION
K37 12V FILTER
K38 SUSP DUMP TIME DELAY
K39 CHASSIS A/C ENG. FAN ENABLE
K40 NOT USED
K41 PARK/TAIL LIGHTS RELAY
K42 AUX BAT DISABLE
K43 REMOTE MIRROR CONTROL LGT